## Top Module Assembly

## Step 1

Place the 3/8 Inch screws and nuts loosely in the holes on the vertical plates (T5, T6, T7, T9) as shown in the picture.

