Step 4

Slide down the frontal plate (T9) until the screws fit in the spacers and tighten.

