

Biometric Technology Provider


How to use Anti_PassBack in Alpeta

ACCESS CONTROL TIME ATTENDANCE MANAGEMENT SOLUTIONS

1. First, make sure all terminals are normal status.








- 2. Terminal Info > Select "Access Allow" or "Access Denied" when network is disconnected.




- 3. Go to the "Anti_PassBack" and Add zone (Below is just an example "IN")
 - ※ ID is only "1000~9999"






4. "IN" is appeared and open to the "Add Enter Terminal"










5. Click both the name (ex. "OUT") and the Right Side (ex. "Terminal OUT") then apply and save it.







6. You can see applied Terminal ID (ex. 1) and equally go to the "Add Exit Terminal"







7. The opposite side is also Apply and save it.






8. Please , click "Validation" if APB setting is normal.







9. Below example is the PassBack error occurs during continuous authentication without going through APB system.





* If User has APB exception , the user can access as usual without going through APB system.

