
Support Team www.unioncomm.co.kr




① From the main screen, select [User] > [Add]. Select 'FAW' as authentication type.

Auth type select






② Select [Auth] > [Edit] button in Face Data (W) Section.






③ Select the connected terminal and [Capture] button to register the face.





4 The terminal shows to try to register the face.





4 Click [Save] to complete.

