

Biometric Technology Provider


How to connect Terminal to Alpeta

ACCESS CONTROL TIME ATTENDANCE MANAGEMENT SOLUTIONS

How to connect Terminal to Alpeta



 Open Alpeta and Go to the "Terminal" and Add Terminal ID







How to connect Terminal to Alpeta

- 2. Go to Terminal Menu > Network > Setting Start (Terminal ID should be same made)
 - ★ Noted that Alpeta is "9003"






How to connect Terminal to Alpeta



3. You can see Terminal Connection from Monitoring



:: WusersWAlics ping 192.168.000.102

ing statistics for 192,168.8.182;

C: WUsersWAlice>

Pinging 192.158.8.182 with 32 bytes of data:

Reply from 192.168.0.101: Destination host unreachable. Reply from 192.168.0.181: Destination host unreachable. Reply from 192.168.0.181: Destination host unreachable. Reply from 192.168.0.181: Destination host unreachable.

Packete: Sent = 4, Received = 4, Lect = E (Ux loce),

- * If terminal is not connected, below is check point.
- 1) Turn off Windows Firewall and Security software (ex. Vaccine)
- 2) Ping Test should be normal like right picture.