UBio-Alpeta

Real-time event process

UNION COMMUNITY

Real-time event transmission method

- : Supports two-way communication between server and client using web socket
- What is the web socket? Web Socket is a structure to do an efficient two-way communication between server and client. It is one of the communication protocol for network and a technical rule for two-way communication defined by the World Wide Web Consortium (W3C) and the Internet Engineering Task Force (IETF), the standardization organizations of the Internet, to define the rules for communication between the server and the client.

How to access to Web Socket

: Access to the Web socket address.

- ws://192.168.0.2:9004/v1/webEntry -> IP address is the server IP installing the Alpeta.

Example of real-time event information data

```
Event message name: WSCmdTerminalLiveInfo
```

```
Received data:

{
    msgId: 1102,
    result: 0,
    body: "[{
        "ID":8,
        "Status":25169945,
        "Type":37
    }]"
    }
```

The data including msqId, result, and body(Json) is sent from server to client.

Name	Value	Description
msgId	1102	The real-time event message ID.
result	0 (Fixed)	Server -> Client (0: Fixed)
body		
ID	8	Terminal ID
Status	25169945	Terminal Status value (Refer to the table 2 below.)
Type	37	Terminal type (Refer to the menu of WSCmdTerminalLiveInfo
		below.)

The types of real-time event

Event name	Event message ID	Description
WSCmdLogoutNotify	1002	Logout
<u>WSCmdLogAuthNotify</u>	1100	Terminal authentication log
<u>WSCmdLogEventNotify</u>	1101	Terminal event log
<u>WSCmdTerminalLiveInfo</u>	1102	Terminal status information
<u>WSCmdServiceStatusNotify</u>	1103	Server status information
WSCmdAuthLogImageNotify	1104	Terminal authentication log image
<u>WSCmdTerminalNoticeSetNotify</u>	1105	Notice for terminal
WSCmdGroupSyncNotify	1106	Change the group information.
WSCmdPositionSyncNotify	1107	Change the position information.
<u>WSCmdTerminalSyncNotify</u>	1108	Change the terminal information.
WSCmdAccessGroupSyncNotify	1109	Change the information of access group.
WSCmdTimezoneSyncNotify	1110	Change the time-zone information.
<u>WSCmdPrivilegeSyncNotify</u>	1112	Change the privilege information.
<u>WSCmdUserMessageSyncNotify</u>	1113	Change the user's message.
<u>WSCmdTerminalLogUploadNotify</u>	1120	The data of importing the terminal log.

WSCmdLogoutNotify (msgId: 1002)

: Sends the logout event from server to web client.

: Received data:

{ msgId: 1002, result: 0, body: "{" UserId ":100000000000000000," Type ":0}"}

Name	Value	Description
msgId	1002	Real-time event message ID
result	0 (Fixed)	Server -> Client (0: Fixed)
body		
UserId	10000000	User ID
Туре	0	The types of logout 0: When the control server to ask log-in is different or when requesting the web log-in newly. 1: Request the automatic log-out by initializing since there wasn't login extension for 30 minutes. 2: When deleting the log-in users

WSCmdLogAuthNotify (msgId: 1100)

: When the user authenticates at the terminal, an event occurs that sends an authentication log to the monitoring page

: Received data:

```
 \{ msgId: 1100, result: 0, body: \{ "IndexKey": 0, "TerminalID": 3, "UserID": "", "UserID": 0, "UserName": "", "UniqueID": "", "EventTime": "2019-12-20 17: 45: 13", "ServerRecordTime": "1970-01-01 00: 00: 00", "AuthType": 2, "AuthResult": 1, "Func": 3, "FuncType": 0, "Card": "", "UserType": 0, "IsPicture": 1, "Property": "1000", "Latitude": 0, "Longitude": 0, "GroupName": "", "PositionName": ""} \}" \}
```

Name	Value	Description
msgId	1100	Real-time event message ID
result	0	Server -> Client (0: Fixed)
body		
IndexKey	0	The index for saving DB (0: Fixed)
TerminalID	8	The registered terminal ID
UserID	"1" or ""	User ID (If unregistered, "")
UserName	"Tom"	User name
UniqueID	"19-0153"	Unique ID
EventTime	"2019-12-20 17:45:13"	Event occurrence time
ServerRecordTime	"1970-01-01 00:00:00"	DB saving time (No use)
AuthType	2	Authentication type
		1: FP 1:1 authentication
		2: FP 1:N authentication
		3: Password authentication
		4: Card authentication
		5: Face 1:1 authentication
		6: Face 1:N authentication
		7: Mobile card
		8: QR code

		11: Request the authentication type of ID or
		Unique ID
AuthResult	1	Authentication result
7 taci il todale		0: Success
		1: Fail
		2: Not available to access
		3: Time out
		4: Capture time out
		5: 1:N time out
		6: Not available for anti-pass back
		7: Duress
		8: Blacklist
Func	3	Function key
Tane		1: F1
		2: F2
		3: Access
		4: F3
		5: F5
		TnA
		11: Attend
		12: Leave
		13: In
		14: Out
		15: Return
		Meal
		21: Menu 1
		22: Menu 2
		23: ****
		24: Menu 3
		25: Menu 4
FuncType	0	Function type (No use)
Card	"A01032" or ""	Authentication card number
UserType	0	User type (0: Fixed)
IsPicture	1	The flag to whether there is an image or not
Property	"1000"	1000 (Fixed)
Latitude	0	The latitude when uploading the authentication
		log from V-Terminal (Smartphone) / (Not
		currently available)
Longitude	0	The longitude when uploading the
, <u>, </u>	_	authentication log from V-Terminal
		(Smartphone) / (Not currently available)
GroupNamo	"Group name"	
GroupName PositionName	"Position name"	Group name Position name
FUSITIONINGINE	FUSICION HAINE	FUSILIUII HAITIE

WSCmdLogEventNotify (msgId: 1101)

: When other events such as door opening or fire occur in the terminal

: Received data:

```
{msgId: 1101, result: 0, body: "{"TerminalID":8,"EventTime":"2019-12-23 10:16:41","Category":2,"Content":131083,"Detail":""}"}
```

Name	Value	Description
msgId	1101	Real-time event message ID
result	0 (Fixed)	Server -> Client (0: Fixed)
body		
TerminalID	8	Terminal ID
EventTime	2019-12-23 10:16:41	Event occurrence time
Category	2	Event category -> 1: Terminal, 2: Door for access, 3: Emergency situation, 4: External signal, 5: System
Content	131083	Event category (Refer to the table 1 below.)
Detail		Detailed information

WSCmdTerminalLiveInfo (msgId: 1102)

: Imports the terminal status information periodically. (Every 10 seconds)

: Received data:

{ msgId: 1102, result: 0, body: "[{"ID":8, "Status":25169945, "Type":37}]"}

Name	Value	Description	
msgId	1102	Real-time event message ID	
result	0 (Fixed)	Server -> Client (0: Fixed)	
body			
ID	8	Terminal ID	
Status	25169945	Terminal status value (<u>Refer to the table 2 below.</u>)	
Type	37	Terminal type information	
		2 : NAC 2500	
		3 : NAC 3000	
		4 : NAC 2500 (4MF)	
		6 : NAC 5000	
		9 : NAC 1500	
		18 : T5	
		19 : T3	
		20 : T1	
		22 : T9	
		23 : FKA2	
		24 : eNCardi	
		25 : T2	
		26 : UBio-X Slim (Nitgen)	
		30 : AC1100	
		31 : AC2000	
		32 : AC2200	
		33: AC5000	
		34 : AC5100	
		35 : AC7000	
		36 : UBio-X Pro Lite	
		37: UBio-X Pro	
		38 : AC6000	
		39: UBioTablet5	
		40 : UBio-X Slim (Virdi)	

WSCmdServiceStatusNotify (msgId: 1103)

: Gets periodically the system status information.

: Received data:

	(when having the data below)				
Name	Value	Details			
msgId	1103	Real-time event message ID			
result	0	Server -> Client (0: Fixed)			
body					
DSInfo					
- ServerID	1	Server ID			
- ServerType	1				
- ServerMode	1				
-t					
- seconds	1576735379				
- nanos	154753900				
- DBStat					
- User					
- curCnt	0	The number of users			
- Term					
- curCnt	8	The number of terminals			
- Auth					
- curCnt	0				
- Sys					
- curCnt	0				
- SystemStat					
- ServerID	1	Server ID			
- totalMemory	7	Total memory capacity			
- usedMemory	73.00	Used memory capacity			
- idleCPU	53	CPU free capacity			
CSInfo		1 /			
- ServerID	11	Server ID			
- totalMemory	7	Total memory capacity			
- usedMemory	73.00	Used memory capacity			
- idleCPU	53	CPU free capacity			
ASInfo					
- ServerID	100	Server ID			
- ServerType	0				
- ServerMode	0				
- t	null				
- DBStat	null				
		1			

- SystemStat		
- ServerID	0	Server ID
- totalMemory	7	Total memory capacity
 usedMemory 	73.00	Used memory capacity
- idleCPU	93506.34	CPU free capacity
FPStatInfo		
- curMinute	2	
- fpTotal	0	The number of server FP authentication
- fpReqCount	[0,0,0,0,0,0,0]	
- fpProcessTime	[0,0,0,0,0,0,0]	
TaskInfo	null	

WSCmdAuthLogImageNotify (msgId: 1104)

When authenticating in terminal while the terminal monitoring detail page is opened, the image taken on the terminal camera is transmitted. (The event doesn't occur when the terminal authentication mode is 'terminal' mode.)

Received data:

```
{msgId: 1104, result: 0, body: "{"header":{"cmdId":1093673220,"uniqueKey":4294967295,"result":0,"DesType":1,"DesID":0, "UserID":0,"brandType":1},"TerminalID":8,"LogIndex":201912000000089,"TerminalLogIndex":0, "EventTime":{"seconds":1577062673},"PictureInfo":{"Type":"jpg","Length":6490,"Data":"/9j/4AAQSk ZJRgABAQAAAQABAAD/2wBDABALDA4MChAODQ4SERATGCgaGBYWGDEjJR0oOjM9PDkzODdASFxOQ
```

(When having the data below)

ERXRTc4UG1RV19iZ2hnPk1xeXBkeFxlZ2P//2Q==..."}}"

Name	Value	Description
msgId	1104	Real-time event message ID
result	0	Server -> Client (0: Fixed)
body		
header		
- cmdId	1093673220	
- uniqueKey	42949672	
- result	0	
- DesType	1	
- DesID	0	
- UserID	0	
- brandType	1	
TerminalID	8	Terminal ID
LogIndex	201912000000089	
TerminalLogIndex	0	
EventTime		
- seconds	1577062673	
PictureInfo		
- Type	jpg	
- Length	6490	
- Data	/9j/4AAQSkZ	

WSCmdTerminalNoticeSetNotify (msgId: 1105)

: When sending the notice from the notice management page to terminal

: Received data :

{ msgId: 1105, result: 0, body: "{"TerminalID":8}"}

Name	Value	Description
msgId	1105	Real-time event message ID
result	0	Server -> Client (0: Fixed)
body		
TerminalID	8	Terminal ID

WSCmdGroupSyncNotify (msgId: 1106)

: When adding the group in the group management page

: Received data :

```
 \{ \  \, \text{msgId: 1106, result: 0, body: "{"SyncType":1,"GroupInfo":{"GroupID":2,"Parent":1, "Name":"test1", "Description":""}}" \}
```

(When having the data below)

Name	Value	Description
msgId	1106	Real-time event message ID
result	0	Server -> Client (0: Fixed)
body		
SyncType	1	Type 1: insert 2: update 3: delete
GroupInfo		
- GroupID	2	Group ID
- Parent	1	The ID of parent group
- Name	test1	Group name
- Description		Description

WSCmdPositionSyncNotify (msgId: 1107)

: When clicking [Apply] button after adding the position in position management page

: Received data :

```
{ msgId: 1107, result: 0, body: "{"SyncType":1,"PositionInfo":{"PositionID":3,"Name":"test456"}}"}
```

Name	Value	Description
msgId	1107	Real-time event message ID
result	0	Server -> Client (0: Fixed)
body		

SyncType	1	Туре	
		1 : insert	
		2 : update	
		3 : delete	
PositionInfo			
- PositionID	3	Position ID	
- Name	test456	Position name	

WSCmdTerminalSyncNotify (msgId: 1108)

: When adding the terminal in terminal management page

: Received data :

```
 \begin{tabular}{ll} \{msgId: 1108, result: 0, body: ``{"SyncType": 1,"TerminalInfo": {"ID": 10, "Name": "10", "GroupCode": 0,"Status": 16,"Type": 0,"FuncType": 0,"IPAddress": "","MacAddress": "", "Version": "","RemoteDoor": 0,"UTCIndex": 0,"Description": ""}}'\end{tabular} \label{table: continuous}
```



Name	Value	Description	
msgId	1108	Real-time event message ID	
result	0	Server -> Client (0: Fixed)	
body			
SyncType	1	Туре	
		1 : insert // add	
		2 : update	
		3 : delete	
		4 : insert // unRegist	
TerminalInfo			
- ID	10	Terminal ID	
- Name	10	Terminal name	
- GroupCode	0	Group code	
- Status	16	Terminal status value, No use	
- Type	0	Terminal type	
- FuncType	0	Function key, No use	
- IPAddress		IP address	
- MacAddress		Mac address	
- Version		Terminal version	
- RemoteDoor	0	Remote door, No use	
- UTCIndex	0	UTC information, No use	
- Description		Description, No use	

WSCmdAccessGroupSyncNotify (msgId: 1109)

: Add the access group in the access group management page

-> The event occurs when clicking [Save] button after setting

: Received data :

```
{ msgId: 1109, result: 0, body: "{"SyncType":1,"AccessGroupInfo":{"ID":3, "Name":"Access group 3","TimezoneID":0}}"}
```

Name	Value	Description	
msgId	1109	Real-time event message ID	
result	0	Server -> Client (0: Fixed)	
body			
SyncType	1	Туре	
		1 : insert	
		2 : update	
		3 : delete	
AccessGroupInfo			
- ID	3	Group ID	
- Name	Access group 3	Group name	
- TimezoneID	0	Time zone ID	

WSCmdTimezoneSyncNotify (msgId: 1110)

: When clicking [Save] button after adding the time zone in time zone management page

: Received data :

	1		
Name	Value	Description	
msgId	1110	Real-time event message ID	
result	0	Server -> Client (0: Fixed)	
body			
SyncType	2	Туре	
		1 : insert	
		2 : update	
		3 : delete	
TimezoneInfo			
- TimezoneID	1	Time zone ID	
- Name	New	Time zone name	
- HolidayID	2	Holiday ID	
- Holiday	1	Holiday (1 : Fixed)	
- Sunday	1	Sunday (1 : Fixed)	
- Monday	1	Monday (1 : Fixed)	
- Tuesday	1	Tuesday (1 : Fixed)	
- Wednesday	1	Wednesday (1 : Fixed)	
- Thursday	1	Thursday (1 : Fixed)	
- Friday	1	Friday (1 : Fixed)	
- Saturday	1	Saturday (1 : Fixed)	

WSCmdPrivilegeSyncNotify (msgId: 1112)

: When clicking [Save] button after adding the privilege in admin management page

: Received data :

```
{msgId: 1112, result: 0, body:
"{"SyncType":1,"PrivilegeInfo":{"PrivilegeID":1237,"Name":"test123","Description":"test1","Monitoring
":{"Permit":0,"Client":0,"TerminalStatus":0,"Auth":0,"Event":0},"Terminal":{"Permit":1,"Regist":1,"Upd
ate":1,"Delete":1,"FW":0,"Option":0,"SetManager":0,"UserFile":0},"User":{"Permit":1,"Regist":1,"Upd
ate":1,"Delete":1,"TerminalUser":0,"RegistAdmin":0},"Group":{"Permit":1,"Regist":1,"Update":1,"Delete":1,"User":0},"Guest":{"Permit":0,"Regist":0,"Update":0,"Delete":0},"Blacklist":{"Permit":0,"Change
```

":0,"Release":0,"Update":0,"Delete":0},"AccessControl":{"Permit":0,"Set":0},"Map":{"Permit":0,"Set":

0},"TNA":{"Permit":0,"Set":0,"Special":0,"Manage":0,"OutState":0,"OutExcRecord":0,"Summary":0,"S endResult":0,"DeleteResult":0},"Log":{"Permit":0,"Delete":0,"BackupRestore":0},"Meal":{"Permit":0," DeleteResult":0,"ViewGroup":0,"ViewPersonal":0,"Set":0},"Option":{"Permit":0,"Local":0,"Server":0,"P assword":0,"Mail":0,"TNA":0},"GroupInfo":{"GroupID":0,"Parent":0,"Name":"","Description":""}}}"}

Name	Value	Description		
msgId	1112	Real-time event message ID		
result	0	Server -> Client (0: Fixed)		
body		(**************************************		
SyncType	1	Туре		
		1 : insert		
		2 : update		
		3 : delete		
PrivilegeInfo				
- PrivilegeID	1237	Privilege ID		
- Name	test123	Privilege name		
- Description	test1	Description		
- Monitoring				
- Permit	0	Whether to permit or not (If checked, 1 : Fixed)		
- Client	0	Client		
- TerminalStatus	0	Terminal status		
- Auth	0	Authentication log		
- Event	0	Event log		
- Terminal				
- Permit	1	(If checked, 1 : Fixed)		
- Regist	1	Registration		
- Update	1	Modification		
- Delete	1	Deletion		
- FW	0	Apply the FW.		
- Option	0	Option setting		
- SetManager	0	Set the admin.		
- UserFile	0	User file		
- User				
- Permit	1	(If checked, 1 : Fixed)		
- Regist	1	Registration		
- Update	1	Modification		
- Delete	1	Deletion		
- TerminalUser	0	Terminal user		
- RegistAdmin	0	User file		
- Group				
- Permit	1	(If checked, 1 : Fixed)		
- Regist	1	Registration		
- Update	1	Modification		
- Delete	1	Deletion		
- User	0	User		
- Guest				
- Permit	0	(If checked, 1 : Fixed)		
- Regist	0	Registration		
- Update	0	Modification		
- Delete	0	Deletion		
- Blacklist				
- Permit	0	(If checked, 1 : Fixed)		
	-			

- Change	0	Modification	
- Release	0	Release	
- Update	0	Change	
- Delete	0	Deletion	
- AccessControl			
- Permit	0	(If checked, 1 : Fixed)	
- Set	0	Registration	
- Map			
- Permit	0	(If checked, 1 : Fixed)	
- Set	0	Set the draft.	
- TNA			
- Permit	0	(If checked, 1 : Fixed)	
- Set	0	Set the TNA.	
- Special	0	Set the special shift.	
- Manage	0	TNA management	
- OutState	0	Search the working status.	
- OutExcRecord	0	Search the exclusion report.	
- Summary	0	Manage the TNA summary.	
- SendResult	0	Send the TNA result.	
- DeleteResult	0	Delete the TNA result.	
- Log			
- Permit	0	(If checked, 1 : Fixed)	
- Delete	0	Deletion	
- BackupRestore	0	Restoration	
- Meal			
- Permit	0	(If checked, 1 : Fixed)	
- DeleteResult	0	Search the meal report.	
- ViewGroup	0	Search the meal by group.	
- ViewPersonal	0	Search the meal by individual.	
- Set	0	Setting	
- Option			
- Permit	0	(If checked, 1 : Fixed)	
- Local	0	Area	
- Server	0	Server	
- Password	0	Password	
- Mail	0	Mail	
- TNA	0	TNA	
- GroupInfo			
- GroupID	0	Group ID	
- Parent	0	The parent group's ID	
- Name		Group name	
- Description		Description	

WSCmdUserMessageSyncNotify (msgId: 1113)

: When adding the user message in user message management page

: Received data:

```
{ msgId: 1113, result: 0, body: "{"SyncType":1,"UserMessageInfo":{"MessageID":2, "Message":"test1234"}}"}
```

Name	Value	Description	
msgId	1113	Real-time event message ID	
result	0	Server -> Client (0: Fixed)	
body			
SyncType	1	Туре	
		1 : insert	
		2 : update	
		3 : delete	
UserMessageInfo			
- MessageID	2	Message ID	
- Message	test1234	Message contents	

WSCmdTerminalLogUploadNotify (msgId: 1120)

: When clicking [Import] after checking the terminal in Terminal log page

: Received data :

{ msgId: 1120, result: 0, body: "{"terminalID":8, "total":2397, "offset":2384, "count":13}"}

Name	Value	Description
msgId	1120	Real-time event message ID
result	0	Server -> Client (0: Fixed)
body		
terminalID	8	Terminal ID
total	2397	The number of total logs.
offset	2384	The number of current log
		(It doesn't import the number of total log of
		terminal but does the number of count in order.
count	13	The number of log to import at once

Table 1 – Event code

Event code	Event name	Event code	Event name
65537	Terminal Disconnected	196614	Panic Sensor End
65538	Terminal Connected	196615	Crisis Sensor Start
65539	Terminal Locked	196616	Crisis Sensor End
65540	Terminal Unlocked	196617	Blacklist authentication trial
65541	Terminal Tamper	196624	Threat
65542	Terminal Attached	196625	System error
65543	Terminal Lockdown	196626	Door warning
131073	Door Open	196627	Door 2 open warning
131074	Door Close	196628	Door 2 emergency warning
131075	Door Unlock	196629	Release the door 2 open warning.
131076	Door Locked	196630	Fire Sensor Start
131077	Door Forced	196631	Panic Sensor Start
131078	Open too long	196632	Panic Sensor End
131079	Door Restored	196633	Fire Sensor End
131080	Lock Error	196640	FP device error
131081	Not Monitoring	196641	DB Error
131083	Door open	196642	RTC Error
131084	Remove the door open.	196643	Touch Error
131088	Operate the door open.	262145	External Sensor 1 Start
131089	Operate to remove the door lock.	262146	External Sensor 1 End
131090	Operate the door lock.	262147	External Sensor 2 Start
131091	Door change	262148	External Sensor 2 End
131092	Open button pressed in Door 1.	262149	External Sensor 3 Start
131093	Door 2 Open	262150	External Sensor 3 End
131094	Door 2 Closed	262151	External Sensor 4 Start
131095	Open button pressed in Door 2.	262152	External Sensor 4 End
131096	Remove the open too long.	327681	Change the FP device setting.
196609	Arm	327682	Change the UI setting.
196610	Disarm	327683	Change the system.
196611	Fire Sensor Start	327684	Change the time.
196612	Fire Sensor End	327685	Change the fixed setting.
196613	Panic Sensor Start	327686	Change the all options.

Table 2 - Alpeta Terminal Status

Status name	SHIFT	Description
TerminalStatusConnect	1 << 0	Connection
		- 0: Disconnection, 1: Connection
TerminalStatusRegist	1 << 4	Registration status - 0: Unregistered, 1:
		Registered
TerminalStatusIDConflict	1 << 5	ID conflict - 0: Normal 1: ID conflict
TerminalStatusInvalidType	1 << 6	The registered terminal type is different.
		- 0: Normal, 1: Different
TerminalStatusSyncUserIDLen	1 << 15	The length of user ID

		- 0: Matched, 1: Different
TerminalStatusSyncMacAddres	1 << 16	Mac Address - 0: Normal, 1: Different
TerminalStatusSyncUserCount	1 << 17	The number of user
		- 0: Normal, 1: Different
TerminalStatusSyncFWVersion	1 << 18	FW version - 0: Normal, 1: Different
TerminalStatusDoor	1 << 7	Door - 0: Closed, 1: Open
TerminalStatusDoorEmergency	1 << 8	Door Forced - 0: Normal, 1: Forced
TerminalStatusDoorOpenWarn	1 << 9	Open too long
		- 0: Normal, 1: Open too long
TerminalStatusDoorLookState	1 << 10	Status - 0: Locked, 1: Open
TerminalStatusDoorLockWorking	1 << 11	Operation - 0: Normal, 1: Abnormal
TerminalStatusDoorNotMonitoring	1 << 23	When door status cannot be monitored
TerminalStatusDoorOpenState	1 << 24	The status of door open
		(By the command of door open)
TerminalStatusLock	1 << 1	Lock - 0: Open, 1: Lock
TerminalStatusLockForce	1 << 2	Lockdown - 0: Normal, 1:Lockdown
TerminalStatusCover	1 << 3	Cover - 0: Attached, 1: Terminal tamper
TerminalStatusWarnFire	1 << 12	Fire - 0: Normal, 1: Fire
TerminalStatusWarnPanic	1 << 13	Panic - 0: Normal, 1: Panic
TerminalStatusWarnCricis	1 << 14	Crisis - 0: Normal, 1: Crisis

	Connection status	Door	Door lock	Warning