

BARCODE → RS232 KONFIG - Seite 2 (Baudraten 1/2)



CFG:BAUD=1200

BAUD_1200: CFG:BAUD=1200



CFG:BAUD=2400

BAUD_2400: CFG:BAUD=2400



CFG:BAUD=4800

BAUD_4800: CFG:BAUD=4800



CFG:BAUD=9600

BAUD_9600: CFG:BAUD=9600



CFG:BAUD=19200

BAUD_19200: CFG:BAUD=19200



CFG:BAUD=38400

BAUD_38400: CFG:BAUD=38400



CFG:BAUD=57600

BAUD_57600: CFG:BAUD=57600