

BARCODE → RS232 KONFIG - Seite 3 (Baudraten 2/2)



CFG:BAUD=115200

BAUD\_115200: CFG:BAUD=115200



CFG:BAUD=230400

BAUD\_230400: CFG:BAUD=230400



CFG:BAUD=460800

BAUD\_460800: CFG:BAUD=460800



CFG:BAUD=250000

BAUD\_250000: CFG:BAUD=250000



CFG:BAUD=500000

BAUD\_500000: CFG:BAUD=500000



CFG:BAUD=1000000

BAUD\_1000000: CFG:BAUD=1000000