## Pet auto feeder control board

## Rev: 1.0

2023-11-22

	Sour ced	Plac ed	References	Value	Footprint	Quantit y
1			C1, C2, C3, C4, C6, C7, C9, C11	100nF	C_0603_1608Metric	8
2			C5	1uF	C_0603_1608Metric	1
3			C8	10uF	C_0603_1608Metric	1
4			C10	330uF	CP_Elec_6.3x7.7	1
5			R1, R2, R3, R6	1k	R_0603_1608Metric	4
6			R4, R5	4.7k	R_0603_1608Metric	2
7			R8, R9	5.1k	R_0603_1608Metric	2
8			R7	100k	R_0603_1608Metric	1
9			U1	Floppy_Board_v1 .0	Floppy board v1.0	1
10			U2	L293D	DIP-16_W7.62mm	1
11			U3	DS3231_RTC_MODU LE	JST_XH_B4B-XH- A_1x04_P2.50mm_Vertical	1
12			U4	oled_0.96"_128x 64px	128x640LED	1
13			U5	CH340N	SOP-8_3.9x4.9mm_P1.27mm	1
14			F1	500mA	Fuse_1206_3216Metric_Pad1.42x1. 75mm_HandSolder	1
15			SW1	B_+	SMD BUTTON 5.1x5.1	1
16			SW2	В	SMD BUTTON 5.1x5.1	1
17			SW3	B_OK	SMD BUTTON 5.1x5.1	1
18			SW4	RESET	SW_Tactile_SPST_NO_Straight_CK_ PTS636Sx25SMTRLFS	1
19			SW5	воото	SW_Tactile_SPST_NO_Straight_CK_ PTS636Sx25SMTRLFS	1
20			H1, H2, H3, H4	MountingHole	MountingHole_3.2mm_M3_Pad	4
21			BZ1	Buzzer	MagneticBuzzer_PUI_AT-0927-TT- 6-R	1
22			JP1	Power selector	SolderJumper- 3_P1.3mm_Open_RoundedPad1.0x1.5 mm	1
23			Q1	PN2222A	TO-92_Inline	1
24			J1	STEPPER	JST_XH_B4B-XH- A_1x04_P2.50mm_Vertical	1
25			J2	EXTERNAL USB-C	JST_XH_B4B-XH- A_1x04_P2.50mm_Vertical	1
26			J3	USB-C_304A- ACP16X	USB_C_304A-ACP16X	1
27			J4	POWER	JST_XH_B2B-XH- A_1x02_P2.50mm_Vertical	1



