# Sensors/Actuators for embedded and intelligent systems

Polytech Nice Sophia

B. Miramond

## Progression of embedded notions

 SI3 – architecture of computers, instruction set, execution principle of Von Neumann machines

 SI4 – Sensors/actuators, real-time processing, embedded AI

• SI5 – hardware-software codesign, SoC, FPGA

## Organisation of the course

- 12 class sessions lecture, 1 hour
- 12 lab sessions, 2 hours => starts 09/02/21
- 3 parts (can be re-organised according to the conditions):
  - 1. Embedded programming and peripherals
    - face-to-face labs for at least half of the students
  - 2. Real-time scheduling
    - exercices can be done remotely
  - 3. Embedded AI on MCU
    - labs can be done remotely
- 3 ratings: test 1, labs, test 2

## Prepare the first lab on DE1-SoC boards

#### • Goal:

- Cross compilation on embedded SoC target
- Peripherals programming
- Programming of interrupts

#### • To prepare:



#### – Linux :

https://download.altera.com/akdlm/software/acdsinst/16.1/196/ib installers/QuartusLiteSetup-16.1.0.196-linux.run

– Windows :

https://download.altera.com/akdlm/software/acdsinst/16.1/196/ib\_installers/QuartusLiteSetup-16.1.0.196-windows.exe


– Prise en charge Cyclone V circuits :

https://download.altera.com/akdlm/software/acdsinst/16.1/196/ib\_installers/cyclonev-16.1.0.196.qdz




# Edge computing

- Lightweight machine learning
- Energy efficient electronic
- Low-power wireless communications
- Bandwith improvements
- Micro-controler programming




# Edge computing

- Reliability
- Privacy
- Latency
- Low-power



# IoT - Internet of Things



## From sensors to actuators

Control Center Sensor Actuator Temperature Sends this Sprinkler turns Control center sensor detects

sends command

to sprinkler.

detect signal to

the control

center.

heat.


#### Sensor to **Actuator** Flow

on and puts


out flame.

## Key elements of IoT


#### Sensors & Actuators



Designation Connectivity



People & Process



Providing Digital information

Wired or Wireless

Computing Local & Cloud Controls/Actions/ Interfaces Multimedia Physical Actions

# Experiment embedded programming

Raspberry Pi 4 B ARM-Cortex-A72 4 x 1,50 GHz 4 Go de RAM






Raspberry Pi Pico

- ARM Cortex M0 x2 133 MHz, 264 Ko SRAM + 2 Mo Flash memory
- 26 GPIO
- 2 × SPI, 2 × I2C, 2 × UART, 3 × ADC 12 bits, 16 × PWM

## **Embedded Dev kits**



ATmega 328 32 KB Flash 2KB SRAM

#### **Arduino Zero**

Architecture

ARMv7 Cortex-M0

Processor

Atmel SAMD21 – 48MHz

RAM

32 KB



## Goals of the course

- Understand the software and hardware mechanisms at play in sensor networks
- Formalize the notion of real time computing
- Study the different types of sensors and actuators
- Understand the principles of embedded processing and associated wireless communications
- Understand the challenges of embedded AI

#### In practice

- Programming SoC microcontroller and peripherals
- Getting started with programming on a real-time OS
- Program sensors/actuators-based systems
- Deploy AI algorithms onto MCU



# The targetted boards

#### **DE1-SoC Board**

Cyclone V SoC 5CSEMA5F31C6 Device Dual-core ARM Cortex-A9 (HPS) 85K Programmable Logic Elements 4,450 Kbits embedded memory

64MB (32Mx16) SDRAM on FPGA side

(2x256Mx16) DDR3 SDRAM on HPS side

128 MB flash



32 bits *ARM Cortex*-M4 @ 80 MHz Flash memory up to 1 Mbyte, up to 128 Kbyte of SRAM


STM32 Nucleo 64 STM32L476

32 bits *ARM Cortex*-M4 @ 80 MHz Flash memory up to 1 Mbyte, Polytech - B Miramond up to 128 Kbyte of SRAM




# PART 1 – THE EMBEDDED SYSTEM PERIPHERALS


# Organisation of the embedded system



# The micro-controler unit (MCU) is a SoC




## Nios-II embedded softcore



	Nios II /f Fast	Nios II /s Standard	Nios II /e Economy	
Pipeline	6 Stage	5 Stage	None	
H/W Multiplier & Barrel Shifter	1 Cycle	3 Cycle	Emulated In Software	
Branch Prediction	Dynamic	Static	None	
Instruction Cache	Configurable	Configurable	None	
Data Cache	Configurable	None	None	
TCM (Instr / Data)	Up to: 4 / 4	Up to: 4 / 0	0 / 0	
Logic Usage (Logic Elements)	1400 - 1800	1200 – 1400	600 – 700	
Custom Instructions		Up to 256		

## ARM Cortex M4 familly

ISA Support	Thumb® / Thumb-2
Pipeline	3-stage
Performance Efficiency	1.25 / 1.50 / 1.89 DMIPS/MHz**
Floating-Point Unit	Optional single precision floating point unit IEEE 754 compliant
Memory Protection	Optional 8 region MPU
Interrupts	1 to 240 physical interrupts
Interrupt Priority Levels	8 to 256 priority levels



## Programming an embedded system

- Cross-compilation
- Limited resources (memory, processor, MMU...)
- Installation on the PC of a compiler dedicated to the ISA
- Download ELF file to the target
  - Direct transfert with JTAG (debugger)
  - Indirect transfert through network
- Standard output redirected to the serial link (JTAG, UART...)

## The peripherals of the MCU



- The on-board system is A micro-controller
  - With its memory (flash + RAM)
  - For code execution
  - and therefore programming
- But in order to interact with the outside world, it requires peripherals
  - Sensors, actuators are peripherals
- The MCU communicates with them through different links
  - On board
    - Communication buses, Interruptions
  - Off board
    - Wired field networks (S2I, SPI, I2C, CAN...)
    - Wireless field networks (Bluetooth, Zigbee, Wifi, LoRA, SigFox...)


## First example: on-board peripherals


- Board: Terasic DE1 SoC
- Processor: Soft-Core Nios2 (on Altera FPGA)
- Cross-compilation
- Tool: Quartus 16.1 Lite edition (Eclipse IDE)
- Execution Bare-metal or Execution with RTOS uC/OS-II
- Peripherals: LEDs, 7-segments, buttons, switches, LCD ...



## What is an FPGA?

## The case of Intel Cyclone® V SE 5CSEMA5F31C6N






# Programming steps during labs

#### 1. FPGA Configuration


- 2. Analysis of memory mapped device addresses
- 3. Preparation of the code in C language
- 4. Access to peripherals by memory addresses
- 5. Cross-compilation under IDE
- 6. Download by JTAG-USB
- 7. Debug by UART




## JTAG - Joint Test Action Group

• IEEE 1149.1: Standard Test Access Port and Boundary-Scan Architecture

JTAG-based debugging is available from the very first instruction after CPU reset, letting it assist with development of early boot software which runs before anything is set up.. Those modules let software developers debug the software of an embedded system directly at the machine instruction level when needed




Quartus JTAG Programmer




# Programming steps during labs

#### 1. FPGA Configuration

- 2. Analysis of memory mapped device addresses
- 3. Preparation of the code in C language
- 4. Access to peripherals by memory addresses
- 5. Cross-compilation under IDE
- 6. Download by JTAG-USB
- 7. Debug by UART



## Compilation steps with GNU C Compiler



several object file formats (sections) have been standardised:

- COFF (Common Object File Format) => unix
- **ELF** (Executable and Linkable Format) => linux
- PE (Portable Executable adapted from COFF) => windows 32 /64
   Polytech B. Miramond

# Structure of an ELF object module

www.x86.org/ftp/manuals/tools/elf.pdf

- Header
  - File name,
  - Size,
  - Start address
- Object space (divided into sections)
  - Binary code
  - Data area
- Table of symbols
  - Symbols that can be used and to be satisfied
- Additional information
  - Authors, tools used, versions, environment...

## Types de contenu

The compiler organizes the program by content types called sections:

.text/.code = binary Instructions

.data = initialised data

= (Block Started by Symbol) uninitialized data .bss


= Read Only Data (Character Strings ...) .rodata

.comment = comments


= symbols table .symtab

The ELF Standard allows you to define as many sections as you want with any name.


Sw tools to read ELF files: **objdump** (binary files) or **readelf** (ELF only)



## Linking sections in memory



#### ELE 101 a Linux executable walk-through CORKAMICOM CORKAMICOM




#### LOADING PROCESS

1HEADER

THE ELF HEADER IS PARSED THE PROGRAM HEADER IS PARSED (SECTIONS ARE NOT USED)

#### 2 MAPPING

THE FILE IS MAPPED IN MEMORY ACCORDING TO ITS SEGMENT(S)



#### 3 EXECUTION

ENTRY IS CALLED

SYSCALLS ARE ACCESSED VIA:

- SYSCALL NUMBER IN THE R7 REGISTER
- CALLING INSTRUCTION SVC

#### TRIVIA

THE ELF WAS FIRST SPECIFIED BY U.S. L. AND U.I. FOR UNIX SYSTEM V. IN 1989

THE ELF IS USED, AMONG OTHERS, IN:

- LINUX, ANDROID, \*BSD, SOLARIS, BEOS
- PSP, PLAYSTATION 2-4, DREAMCAST, GAMECUBE, WII
- VARIOUS OSES MADE BY SAMSUNG, ERICSSON, NOKIA.
- MICROCONTROLLERS FROM ATMEL, TEXAS INSTRUMENTS



## Variable allocation


			.data	.bss	.rodata	Pile
Global	static	Initialzed				
		non init.				
	dyna	init.				
		non init				
Local	static	Init				
		non init				
	dyna	init				
		non init				
G/L	const					

## Variable allocation

			.data	.bss	.rodata	Pile
Global	static	initialized				
		non init.				
	dyna	init.				
		non init				
Local	static	init				
		non init				
	dyna	init				
		non init				
G/L	const					

# Programming steps during labs


- 1. FPGA Configuration
- 2. Analysis of memory mapped device addresses
- 3. Preparation of the code in C language
- 4. Access to peripherals by memory addresses
- 5. Cross-compilation under IDE
- 6. Download by JTAG-USB
- 7. Debug by UART



# HAL the layer to communicate with peripherals


The application program (in C) is based on 2 software layers:

- HAL (Hardware Abstraction Layer) contains the declaration of functions for accessing hardware resources (drivers, processor configuration, Hw initialization, etc.).
  - Example of reading/writing in peripherals:
    - #include "altera\_avalon\_pio\_regs.h"
    - IOWR\_ALTERA\_AVALON\_PIO\_DATA(address, data)
    - data = IORD\_ALTERA\_AVALON\_PIO\_DATA (address)
- The BSP (Board Support Package) contains the specific implementations of the peripherals used on the board




## A micro-controller on FPGA

(details in last year course)




## A micro-controller on FPGA




# Programming with interrupts

- In a SoC, only the processor can initiate communications:
  - With memory, peripherals,
  - He is designated as Master
  - Peripherals like Slave.
- An interrupt is an asynchronous means of communication to indicate to the processor that an event has occurred and that it can therefore initiate the appropriate communication.
- RISC processors have 32 interrupt lines that
  - Are prioritized (from 1 to 32),
  - Can be masked,
  - Must be programmed
- The other method of accessing an asynchronous device is Polling,
  - where the processor reads at regular intervals.
  - Processor time wasted + less reactive



# General architecture of the MCU – PARM example





## Behaviour of hw interrupts

(hardwired in the MCU)

#### The interruption causes a program sequence to be interrupted:

- It causes a change of context to execute the interrupt routine.
- To do this, it empties the pipeline and saves the CPU registers (save context).
- It calls the ISR (jump) and executes its code.
- When ISR returns, the context is restored and program execution resumes.
- If 2 interruptions are triggered, ISRs are executed in order of priority






Masking interrupts

## Programmation of interrupts

- IRQ programming is done in 4 steps:
  - 1. Hiding interruptions (allows or not all IRQs),
  - 2. Initializes the status of the associated device,
  - Record an interrupt routine that associates an IRQ number with a jump address,
  - 4. Coding the Interrupt Service Routine (ISR)
- The code of the routine is a critical (uninterruptible) section. It is therefore subject to several rules:
  - Relatively short code, limiting the interrupt latency,
  - No blocking calls,
  - Reset the interrupt source



```
#include "system.h"
                                          Variable defined as
                                               volatile
#include "altera avalon pio regs.h"
                                          Fonction defined as
#include "alt types.h"
                                                static
                                                             The address of the peripheral is
volatile int edge capture;
                                                              defined as a macro in System.h
static void init_button_pio()
/* Recast the edge_capture pointer to match the alt_irq_register() function prototype. */
void* edge capture ptr = (void*) &edge capture;
/* Enable all 4 button interrupts. */
IOWR ALTERA AVALON PIO IRQ MASK (ADDRESS BASE, 0xf);
/* Reset the edge capture register. */
IOWR_ALTERA_AVALON_PIO_EDGE_CAP (ADDRESS_BASE, 0x0);
/* Register the ISR. */
alt_irq_register( NUMERO_IRQ,edge_capture_ptr,handle_button_interrupts );
```

## Volatile and static keywords

#### Volatile

- Used in the case of variables whose value can change spontaneously:
  - without processor action, memory mapped devices
  - By another task in case of multithreaded software
- This prefix tells the compiler to avoid optimizations that generate a systematic memory read instruction.
  - More often used in embedded programming

#### Static

- On a variable, keeps the value of the local variable (allocation out of stack)
- On a function limits the definition of the symbol inside the object (file)

## Example 1: peripherals

- Example of a 8-bit register mapped at address 0x1234. The code test if the register is non-zero
  - Uint \*ptr= (Uint \*) 0X1234;
  - // wait until non-zero
  - While (\*ptr==0);
  - // do processing after the loop
- Compiler genereates
  - Mov ptr, #1234
  - Mov a, @ptr
  - Loop:
  - Bz loop // infinite loop

- By declaring ptr as volatile, its value is read each time it is used
  - Mov ptr, #1234
  - Loop :
  - Mov a, @ptr
  - Bz loop

## Example 2: interruption handler

 Test end of message on a serial connection (ETX) int etx\_rcvd = false; void mail(){ while(!etx\_rcvd){ // process message // unused code // end of communication

```
void rx_isr(void){
...

If (ETX == rx_char)
        etx_rcvd = TRUE;
...
}
```

**Problem**: the compiler does not understand that the variable can be changed spontaneously in another function, then the loop is considered as infinite

And the code after the loop is not generated in the binary file!

```
#include "system.h"
#include "altera avalon pio regs.h"
#include "alt types.h"
                                                                  Address defined in
static void handle_button_interrupts(void* context, alt_u32 id)
                                                                       system.h
/* Cast context to edge capture's type. It is important that this
be declared volatile to avoid unwanted compiler optimization. */
volatile int* edge capture ptr = (volatile int*) context;
/* Read the edge capture register on the button PIO. Store value. */
*edge capture ptr =IORD ALTERA AVALON PIO EDGE CAP (ADDRESS BASE);
/* Write to the edge capture register to reset it. */
IOWR ALTERA AVALON PIO EDGE CAP (ADDRESS BASE, 0);
/* Read the PIO to delay ISR exit. This is done to prevent a
spurious interrupt in systems with high processor -> pio
latency and fast interrupts. */
IORD ALTERA AVALON PIO EDGE CAP (ADDRESS BASE);
```

## First lab on DE1-SoC boards

#### • Goal:

- Cross compilation on embedded SoC target
- Peripherals programming
- Programming of interrupts

#### • To prepare:



#### – Linux :

https://download.altera.com/akdlm/software/acdsinst/16.1/196/ib\_installers/QuartusLiteSetup-16.1.0.196-linux.run

- Windows:

https://download.altera.com/akdlm/software/acdsinst/16.1/196/ib\_installers/QuartusLiteSetup-16.1.0.196-windows.exe

– Prise en charge Cyclone V circuits :

https://download.altera.com/akdlm/software/acdsinst/16.1/196/ib installers/cyclonev-16.1.0.196.qdz

