

(Source: https://www.google.com/selfdrivingcar/)

Slide credit to Radu Horaud, http://perception.inrialpes.fr

#### Overview

#### Basic principle: Measure depth based

- 1. on illuminating the scene with a controlled light source, and
- 2. then measuring the backscattered light.



#### Overview

#### Basic principle: Measure depth based

- 1. on illuminating the scene with a controlled light source, and
- 2. then measuring the backscattered light.

#### Two classes of sensors:

- 1. Time of Flight (ToF) sensors: Measure depth by estimating the time delay from light emission to light detection.
- 2. Projected-light sensors: Combine the projection of a light pattern with a standard 2D camera and measure depth via triangulation.

Examples - Types of ToF sensors

- Point-wise ToF sensors: mounted on a two-dimensional pan-tilt scanning mechanism, also referred to as Light Detection and Ranging (LIDAR).
- Matricial ToF sensors: estimate depth in a "single shot" using a matrix of ToF sensors (in practice, they use CMOS or CCD image sensors coupled with a lens system).

Examples - Matricial ToF sensors





SR4000 (Swiss Ranger)

(Source: http://www.hizook.com, http://www.mesa-imaging.ch)

Examples – Point-wise ToF sensors





Velodyne HDL-64E & HDL-32E

(Source: http://velodynelidar.com/lidar/lidar.aspx)

Examples – Point-wise ToF sensors (Velodyne usage)





BAIDU self-driving car, NAVYA driverless shuttle (Source: http://velodynelidar.com)

Examples – 3D Flash LIDAR cameras (direct ToF)



TigerEye 3D

(Source: http://www.advancedscientificconcepts.com/products/tigereye.html

Examples - Projected light sensors



#### Microsoft Kinect

(Source: https://de.wikipedia.org/wiki/Kinect)

Examples - Projected light sensors



Asus Xtion Pro Live

(Source: http://vr-zone.com)


# Time-of-Flight (ToF) Principles





Simulated ToF image, using "Blensor" http://blensor.org


#### ToF principles



#### What is the challenge?



#### ToF principles



#### What is the challenge?

It takes  $\approx$  3.3 [ps] to cover a I [mm] path. For such a resolution, we would need a clock, capable of measuring 3.3 [ps] time steps!

#### ToF principles

Working principle: measure the absolute time that a light pulse needs to travel from a target object to a detector.

Pulsed modulation: measure the ToF directly



Source: http://graphics.stanford.edu






Timer

#### ToF principles

Working principle: measure the absolute time that a light pulse needs to travel from a target object to a detector.

Pulsed modulation: measure the ToF directly




Source: http://graphics.stanford.edu

#### ToF principles

Working principle: measure the absolute time that a light pulse needs to travel from a target object to a detector.


Pulsed modulation: measure the ToF directly



#### ToF principles

Working principle: measure the absolute time that a light pulse needs to travel from a target object to a detector.

Pulsed modulation: measure the ToF directly



ToF principles (Pulsed-modulation)

#### Advantages:

- High energy light pulses
  - ⇒ less influence of background illumination
- Illumination and observation directions are collinear



ToF principles (Pulsed-modulation)

#### Advantages:

- High energy light pulses
  - ⇒ less influence of background illumination
- Illumination and observation directions are collinear

#### Disadvantages:

- Arrival time must be measured very precisely
- Needs very short light pulses with fast rise/fall times
- High optical power
- Typically, these ToF sensors use lasers or laser diodes

ToF principles (CW-modulation)

Today, we focus on continuous wave (CW) modulation:

- uses continuous light waves
- detected wave after reflection has shifted phase
- phase shift is proportional to distance from reflected surface








ToF principles (CW-modulation)

Today, we focus on continuous wave (CW) modulation:

- uses continuous light waves
- detected wave after reflection has shifted phase
- phase shift is proportional to distance from reflected surface




14/1

ToF principles (CW-modulation)

Today, we focus on continuous wave (CW) modulation:


- uses continuous light waves
- detected wave after reflection has shifted phase
- phase shift is proportional to distance from reflected surface



ToF principles (CW-modulation)

Today, we focus on continuous wave (CW) modulation:

- uses continuous light waves
- detected wave after reflection has shifted phase
- phase shift is proportional to distance from reflected surface




14/1

ToF principles (CW-modulation)


Today, we focus on continuous wave (CW) modulation:

- uses continuous light waves
- detected wave after reflection has shifted phase
- phase shift is proportional to distance from reflected surface




A way to recover the phase shift is by cross-correlation between the emitted and received signal!

ToF principles (CW-modulation)






ToF principles (CW-modulation)





ToF principles (CW-modulation)



In this illustration, A = 2, a = 5 and bias B = 2.



ToF principles (CW-modulation)

Phase shift recovery through cross-correlation: We know that the relationship between distance d, light speed c and ToF  $\tau$  is

$$d=\frac{1}{2}c\tau$$



ToF principles (CW-modulation)

Phase shift recovery through cross-correlation: We know that the relationship between distance d, light speed c and ToF  $\tau$  is

$$d=\frac{1}{2}c\tau$$

Assuming a constant bias B and a cosine signal with modulation frequency f and amplitude a, the emitted s(t) and received r(t) signals are given as

$$s(t) = a\cos(2\pi ft)$$
 and  $r(t) = A\cos(2\pi f(t-\tau)) + B$ 

ToF principles (CW-modulation)

Phase shift recovery through cross-correlation: We know that the relationship between distance d, light speed c and ToF  $\tau$  is

$$d=\frac{1}{2}c\tau$$

Assuming a constant bias B and a cosine signal with modulation frequency f and amplitude a, the emitted s(t) and received r(t) signals are given as

$$s(t) = a\cos(2\pi ft)$$
 and  $r(t) = A\cos(2\pi f(t-\tau)) + B$ 

B is an offset, due to ambient illumination!

ToF principles (CW-modulation)

Using cross-correlation between the emitted and received signal, we can recover the phase.



ToF principles (CW-modulation)

Using cross-correlation between the emitted and received signal, we can recover the phase.

Let's look at the following integral first:

$$C(x) = \lim_{T \to \infty} \frac{1}{T} \int_{-T/2}^{T/2} r(t) s(t+x) dt$$



ToF principles (CW-modulation)

Using cross-correlation between the emitted and received signal, we can recover the phase.

Let's look at the following integral first:

$$C(x) = \lim_{T \to \infty} \frac{1}{T} \int_{-T/2}^{T/2} r(t) s(t+x) dt$$

The solution to this integral is (the correlation function)

$$C(x) = \frac{aA}{2}\cos(\underbrace{2\pi f \tau}_{\phi} + 2\pi f x) + B$$

ToF principles (4-bucket algorithm)

We can now evaluate C(x) at four selected phases (aka 4-bucket algorithm), i.e.,

$$2\pi f x_0 = 0^{\circ}$$
  
 $2\pi f x_1 = 90^{\circ}$   
 $2\pi f x_2 = 180^{\circ}$   
 $2\pi f x_3 = 270^{\circ}$ 

to recover the three unknowns A, B and  $\tau$ .



#### ToF principles

#### Using standard trigonometric relationships, we obtain

$$\phi = 2\pi f \tau = \tan^{-1} \left( \frac{C(x_3) - C(x_1)}{C(x_0) - C(x_2)} \right)$$

$$A = \frac{1}{2a} \sqrt{(C(x_3) - C(x_1))^2 + (C(x_0) - C(x_2))^2}$$

$$B = 0.25 \sum_{i} C(x_i)$$

ToF principles (phase wrapping)

Can you think of any problems related to that approach?



ToF principles (phase wrapping)

Can you think of any problems related to that approach?

We can easily compute the depth d from the recovered phase as

$$d = \frac{1}{2}\tau c = \frac{1}{2}c\frac{\phi}{2\pi f} = \frac{c}{2f}\frac{\phi}{2\pi}$$



ToF principles (phase wrapping)

Can you think of any problems related to that approach?

We can easily compute the depth d from the recovered phase as

$$d = \frac{1}{2}\tau c = \frac{1}{2}c\frac{\phi}{2\pi f} = \frac{c}{2f}\frac{\phi}{2\pi}$$

This ambiguity is referred to as phase wrapping!

$$d = \left(\frac{\phi}{2\pi} + n\right) d_{\text{max}}, \text{ with } n = 0, 1, 2, \dots$$

Here, n denotes the number of wrappings.

Example: for f = 30 [Mhz], the unambiguous range is 0-5 [m].

ToF principles (phase wrapping)

The CCD sensor plays several roles:


- 1. The incoming photons are converted to electron charges
- 2. Clocking
- 3. Signal processing (i.e., demodulation)


After the demodulation, the signal  $C(\psi)$ , i.e.,

$$C(\psi) = \frac{aA}{2}\cos(2\pi f \tau + \underbrace{2\pi f x}_{\psi}) + B$$

is integrated at four equally-spaced intervals within one modulation period.

ToF principles – From depth to Euclidean coordinates







The ToF camera measures the depth d from the 3D point  $\mathbf{M}$  to the optical center, hence

$$d = \|\mathbf{M}\|$$



ToF principles – From depth to Euclidean coordinates





The ToF camera measures the depth d from the 3D point  $\mathbf{M}$  to the optical center, hence

$$d = \|\mathbf{M}\|$$

We also know (from similar triangles) that

$$\begin{pmatrix} X \\ Y \\ Z \end{pmatrix} = Z \begin{pmatrix} X/Z \\ Y/Z \\ 1 \end{pmatrix} = Z \begin{pmatrix} x \\ y \\ 1 \end{pmatrix}$$

From depth to Euclidean coordinates

Now, the point m has (u, v)-coordinates

$$\mathbf{p} = [u \ v \ 1]^{\top}$$

and (x, y) coordinates

$$\mathbf{m} = [x \ y \ 1]^{\top}$$
 with  $\mathbf{m} = \mathbf{A}^{-1}\mathbf{p}$ .



From depth to Euclidean coordinates

Now, the point m has (u, v)-coordinates

$$\mathbf{p} = [u \ v \ 1]^{\top}$$

and (x, y) coordinates

$$\mathbf{m} = [x \ y \ 1]^{\top}$$
 with  $\mathbf{m} = \mathbf{A}^{-1}\mathbf{p}$ .

Next, we have  $Z = \|\mathbf{M}\| / \|\mathbf{m}\|$  and consequently

$$\begin{pmatrix} X \\ Y \\ Z \end{pmatrix} = Z \begin{pmatrix} x \\ y \\ 1 \end{pmatrix} = \frac{\|\mathbf{M}\|}{\|\mathbf{m}\|} \begin{pmatrix} x \\ y \\ 1 \end{pmatrix} = \frac{d}{\|\mathbf{A}^{-1}\mathbf{p}\|} \mathbf{A}^{-1} \begin{pmatrix} u \\ v \\ 1 \end{pmatrix}$$

#### Distortions

- Phase warping (already covered)
  - ⇒ leads to ambiguities in distance measurements!



#### Distortions

- Phase warping (already covered)
  - $\Rightarrow$  leads to ambiguities in distance measurements!
- Non-ideal sinusoid generation & non-instantaneous sampling
  - ⇒ leads to harmonic distortion in the estimated phase shift!



#### Distortions

- Phase warping (already covered)
  - ⇒ leads to ambiguities in distance measurements!
- Non-ideal sinusoid generation & non-instantaneous sampling
  - ⇒ leads to harmonic distortion in the estimated phase shift!
- Photon-shot noise
  - ⇒ affects the precision of distance measurements

#### Distortions

- Phase warping (already covered)
  - ⇒ leads to ambiguities in distance measurements!
- Non-ideal sinusoid generation & non-instantaneous sampling
  - ⇒ leads to harmonic distortion in the estimated phase shift!
- Photon-shot noise
  - ⇒ affects the precision of distance measurements
- Saturation & Motion blur

Distortions – More details on photon-shot noise

Interestingly, the noise which affects the distance measurement can be approximated by a Gaussian with variance

$$\sigma_d = \frac{c}{4\pi f \sqrt{2}} \frac{\sqrt{B}}{A}$$



Distortions - More details on photon-shot noise

Interestingly, the noise which affects the distance measurement can be approximated by a Gaussian with variance

$$\sigma_d = \frac{c}{4\pi f \sqrt{2}} \frac{\sqrt{B}}{A}$$

#### We observe

- As A gets larger, precision improves
- As B gets larger, precision gets worse
- B depends on background illumination and amplitude A
- An increase in B due to increase in A does not hurt (since  $\sqrt{B}$ )
- Increase  $f \Rightarrow$  better precision, but loss in max. measurable d

Distortions - Other noise sources

### Other noise sources are, e.g.:

- Thermal noise caused by the receiver signal amplifier
- Noise caused by quantization of the received signal



Distortions - Other noise sources

### Other noise sources are, e.g.:

- Thermal noise caused by the receiver signal amplifier
- Noise caused by quantization of the received signal

Usually, better components lead to less noise with the exception of photon-shot noise!



Distortions - Other noise sources

### Other noise sources are, e.g.:

- Thermal noise caused by the receiver signal amplifier
- Noise caused by quantization of the received signal

Usually, better components lead to less noise with the exception of photon-shot noise!

A typical strategy to counteract noise effects is signal averaging over several periods.

Distortions - Signal averaging

Typical averaging intervals are between I [ms] and I00 [ms]. In case of f=30 [Mhz], e.g., we get a period  $\mathcal{T}$  of

$$T = 33.3 \times 10^{-9} \approx 33$$
 [ns]

and consequently, for averaging over I [ms], we cover  $3\times10^4$  periods, or, for I00 [ms],  $3\times10^6$  periods.

The averaging interval length is called the integration time.