
Wired with net labels: labels with the same name are one net. TAPn = connector side of fuse F1nn, CELLn = after it. V− (chip ground) has its own fuse F120.
ADBMS1818 Figure 112, isoSPI filtering per Fig. 104(B). See ../docs/slave-18s-design-basis.md.


U1 ADBMS1818 (64-LQFP_EP, EP = V−)




CELL INPUTS R100–R118: 10 ohm series on C0–C18



C101–C118: 100 nF 100 V, Cn (after 10 ohm) to V−




R201–R218: 33 ohm 1 W balance, cell n node (before 10 ohm) to Sn



SUPPLY: V+ filter, DRIVE NPN -> VREG, VREF1/2



isoSPI BIAS: IBIAS–1k–ICMP–1k–V−



isoSPI PORT A: 2x51 ohm split term + 10 nF CTs




isoSPI PORT B: 2x51 ohm split term + 10 nF CTs




THERMISTORS: 100k to VREF2 + 100 nF, GPIO1–3 cell NTC, GPIO4 onboard




CONNECTORS (JST PH)













TAP FUSES F100–F118: 250 mA on every cell tap, connector side (AN-2093 Fig. 11)




SUPPLY FUSES + TVS F119 top of stack, F120 V−, D301 85 V TVS after F119



ZENER CLAMPS D101–D118: 6.8 V from Cn_F (cathode) to C(n−1)_F, abs max 8 V per pair



TEST POINTS TP1–TP10 Keystone 5015 loops, TP11–TP14 bare 1.5 mm pads (HV, no loop)



MOUNTING HOLES H1–H4: M3, no copper, positions set with the board outline



Not for manufacture
Baseline: ADBMS1818 datasheet Figure 112 typical application

Sheet: /
File: adbms1818-slave-18s.kicad_sch

Title: ADBMS1818 18S slave module

Size: User	Date: 2026-11-06	Rev: 0-draft
KiCad E.D.A. 10.0.6		Id: 1/1