FloodLAMP.bio

KENT CAMP - Do's and Dont's

DO's	DONT's
use 5mL transport or 30mL chub tubes when you need to go in with a pipette	use 15mL or 50mL when you need to go in with a pipette (don't want to contam pipette shaft)
label clean pens and markers w green tape, and keep them clean	use a dirty pen and go back to clean work
label look up racks and PCR plates/strip tubes	assume the lookup is clear, label both look up rack and reaction plate/strips so anyone can properly report results
clean with bleach and then ethanol/alcohol	use only bleach, it leaves residue and the evaporation of the ethanol more reliably leaves surfaces dry
use new TPC for entire camp test session plate	
put remaining TPC back in freezer right away, in indiv ziploc baggie (convention is if it's in a baggie, then it's been used)	leave TPC's out at room temp, or put in cooler with sampled, or put in PCR cold rack (treat as potential source of contam)
change gloves after handling positive controls (TPC or GBD), and quick bleach clean freezer door handle after	
on adding 2ul sample, don't stick shaft of pipette into tube	watch bottom and top of pipette tip to make sure the tip is in the liquid and the shaft is not in the tube
on adding 2ul sample, visually check to verify approx 2ul of liquid is in the tip	assume it's there
when adding samples to strip tubes, do count out loud and have someone looking over your shoulder as an audit	assume you won't get distracted or make mistakes
change gloves after recapping TPC positive control and putting back in baggie	
put dedicated clean weight on strip tubes on black Fisher PCR heat block (figure out what to use for this!)	

contact@floodlamp.bio

CC BY SA

FloodLAMP.bio

DO's	DONT's
label strip tubes on side with 1, 9, 17 etc	forget or rely on super hard to read clear numbers
snap strip tubes to get liquid to bottom	flick or vortex to mix after adding sample

contact@floodlamp.bio

CC BY SA