Functional level	Inicializing command	Does IEEE-488.2 controller perform this operation?	Description
Interface (bus)	IFC	Yes	Messages: - Interface Clear
	REN	Yes	- Remote Enable
Message exchange protocol	DCL	Yes	- Device Clear
Device functions	*RST	Yes	Reset Command
	*CLS	Yes	Cear Status
	STATus:PRESet	Yes	SCPI command to preset status system