

Source code:

```
void main() {  
    TRISB = 0x00; // Set PORTB as output  
    PORTB = 0x00; // Initialize PORTB as OFF state  
  
    while(1) {  
        PORTB.F0 = 1; // RB0 ON  
        PORTB.F1 = 0; // RB1 OFF  
        Delay_ms(1000);  
  
        PORTB.F0 = 0; // RB0 OFF  
        PORTB.F1 = 1; // RB1 ON  
        Delay_ms(1000);  
    }  
}
```

Output:

