

Source code:

```
void main()
{
    unsigned short duty = 0;

    TRISD = 0xFF;
    TRISB = 0x00;
    TRISC.F2 = 0;

    PORTB.F0 = 1;
    PORTB.F1 = 0;

    PWM1_Init(1000);
    PWM1_Start();
    PWM1_Set_Duty(duty);

    while (1)
    {
        if (RD0_bit && duty <= 240)
        {
            Delay_ms(100);
            if (RD0_bit && duty <= 240)
            {
                duty += 10;
                PWM1_Set_Duty(duty);
            }
        }

        if (RD1_bit && duty >= 10)
        {
            Delay_ms(100);
            if (RD1_bit && duty >= 10)
            {
                duty -= 10;
                PWM1_Set_Duty(duty);
            }
        }
    }
}
```

```

    }

    Delay_ms(10);
}
}

```

Output:

