


Location



The screenshot shows the 'Locations' page in the CyberHub ECO.DC application. The left sidebar contains a menu with the following items: Dashboard, Alarms, Locations (highlighted with a red box), Contacts, Analysis, Reports, Account, Administration, Legal, and Help. The main content area has a breadcrumb 'Home / Locations' and a 'Logout' button. Below the breadcrumb is a search bar with the text 'Enter search query...' and a 'Search' button. To the right of the search bar is a filter dropdown menu with the text '- Choose a filter -'. Below the search bar is a table titled 'Locations'. The table has columns: Name, Street, Postal code, City, Country, and State / Province. The first row of the table is 'Demo sitem'. To the right of the 'Demo sitem' row are three buttons: 'View' (highlighted with a red box), 'Edit', and 'Delete'.

CyberHub ECO.DC

admin
admin admin

Dashboard

Alarms

Locations

Contacts

Analysis

Reports

Account

Administration

Legal

Help

Home / Locations

Logout

Enter search query...

Search

- Choose a filter -

Locations

+ Create a new Location

Name	Street	Postal code	City	Country	State / Province
Demo sitem					

View Edit Delete

Location

STULZ

 CyberHub ECO.DC

admin
admin admin ▾

Dashboard

Alarms <

Locations

Contacts

Analysis <

Reports

Account <

Administration <

Legal <

Help


Home / Locations / Demo sitem / Overview

Overview Buildings Rooms Alarms Live Data Energy

Overview

Demo sitem





General Information

Name

Demo sitem

Street

Postal code / City

Country

State / Province

Time zone

Asia/Bangkok ▾

Connected Users ?

admin

Connected Groups ?

AllDevices

← Back

Edit

20.7.3

Location

STULZ

Home / Locations / Demo sitem / Buildings

Logout

Overview

Buildings

Rooms


Alarms

Live Data

Energy

Buildings

+ Add new Building



Leaflet | © OpenStreetMap contributors

Building

View

Edit

Delete

← Back

Location

STULZ

[Overview](#) [Buildings](#) **[Rooms](#)** [Alarms](#) [Live Data](#) [Energy](#)

Rooms

[View list](#) [Add room](#) [Export room](#) [Import room](#)

Building Building ▼

5 - F

 29.800 °C

 No value

Demo room

 Ø 29.800 °C

 Min. 29.800 °C

 Max. 29.800 °C

 No value

[← Back](#)

CyberHub ECO.DC

25

Location

Export room

Please select the room to export:

Room

Demo room

Export options

☐ Only the room

☐ Include entities

☒ Include entities and configurations

Cancel

Export

Import room

Please select the room to import:

Select file

Demo room_10_12_2024.json

Room name

Import options

☐ Only the room

☐ Include entities

☐ Include entities and configurations

Cancel

Import

Location

[Overview](#) [Buildings](#) **[Rooms](#)** [Alarms](#) [Live Data](#) [Energy](#)

Rooms

[View list](#) [Add room](#) [Export room](#) [Import room](#)

Building Building ▼

5 - F

 29.800 °C

 No value

Demo room

 Ø 29.800 °C

 Min. 29.800 °C

 Max. 29.800 °C

 No value

[← Back](#)

Location



Left Click : Rotate , Right Click : Pan , Middle Click : Zoom In/Zoom Out


Location

Live Data Overlay



Location

Heatmap Menu



Location

STULZ

[Overview](#) [Buildings](#) [Rooms](#) [Alarms](#) **[Live Data](#)** [Energy](#)

Live Data

Building Building ▼

 **Demo room**

^ Favorite	Entity Name	Type	Parameter	Value
★	E306-H000	Sensor	Temperature Humidity	29.800 °C 37.000 %rel. H.

[← Back](#)

The logo for Stulz, featuring the word "STULZ" in white, bold, sans-serif capital letters on a red rectangular background.

STULZ

CLIMATE. CUSTOMIZED.

Add Device

Add Device

STULZ

The screenshot displays the STULZ CyberHub ECO.DC interface. The top section, titled 'Locations', features a sidebar with 'Dashboard', 'Alarms', 'Locations' (highlighted with a red box and circle 1), and 'Contacts'. The main area shows a table with columns: Name, Street, Postal code, City, Country, and State / Province. A row for 'Demo sitem' is visible, with 'View', 'Edit' (highlighted with a red box and circle 2), and 'Delete' buttons. A '+ Create a new Location' button is in the top right. The bottom section, titled 'Rooms', has a top navigation bar with 'Overview', 'Buildings', 'Rooms' (highlighted with a red box and circle 3), 'Alarms', 'Live Data', and 'Energy'. The main area shows a 'Rooms' section with a 'Building' dropdown. A '5 - F' room is selected, showing a 'Demo room' details panel (highlighted with a red box and circle 4) with fields for 'Ø', 'Min.', 'Max.', and 'No value'. A 'Back' button is in the bottom right.

Locations

+ Create a new Location

Name	Street	Postal code	City	Country	State / Province
Demo sitem					

View Edit Delete

Overview Buildings Rooms Alarms Live Data Energy

Rooms

View list Add room Export room Import room

Building Building ▼

5 - F

26.700 °C

No value

Demo room

Ø 26.700 °C

Min. 26.700 °C

Max. 26.700 °C


No value

Back

Add Device



Add Device



Add Device

STULZ

Demo room

Edit Mode

Explorer

Copy Deep Copy Delete

General

Name E306-H000

Comment E306-H000

URL

Serial number F810-0000-0000-7130


Inventory number

Position X (in m) 2.2

Position Y (in m) 3.95

Position Z (in m) 3.067

Back Save



The image shows a 3D interface for adding a device to a demo room. On the left, a 3D view of a room contains a kitchen area with a stove and a sink. A red box highlights a small sphere on the floor, with a green arrow pointing to it. A 3D coordinate system is overlaid on the room, with X, Y, and Z axes. The X-axis is red, the Y-axis is blue, and the Z-axis is green. The Z-axis is labeled with 'Z' at both ends. The Y-axis is labeled with 'Y' at both ends. The X-axis is labeled with 'X' at both ends. On the right, a 'General' form is shown with fields for Name, Comment, URL, Serial number, Inventory number, and Position X, Y, and Z. The Name field is filled with 'E306-H000', the Comment field with 'E306-H000', the Serial number field with 'F810-0000-0000-7130', and the Position X, Y, and Z fields with '2.2', '3.95', and '3.067' respectively. The form has a 'Back' button and a 'Save' button at the bottom.

Add Device

Demo room

Edit Mode

Explorer

Copy Deep Copy Delete

Refresh time (in ms) 5000

In-Min 0

In-Max 0

Out-Min 0

Out-Max 100

Tolerance 0

Live data ☒ recorded

Get & Set ☒ Get only ☐ Get & Set ⓘ

Raw 264

Transformed 26.400

Get

Unused parameters Power

Used parameters Temperature

☐ Use in hover menu

Driver Limits

Driver SNMPv1

Domain 192.168.1.60

Port 161

Community public

OID 1.3.6.1.4.1.33688.5.1.1.3.100

Refresh time (in ms) 5000

In-Min 0

Back Save

Add Device

STULZ

Demo room

Edit Mode

Explorer

Copy Deep Copy Delete

Refresh time (in ms) 5000

In-Min 0

In-Max 0

Out-Min 0

Out-Max 1000

Tolerance 0

Live data ☒ recorded

Get & Set ☒ Get only ☐ Get & Set ⓘ

Raw 36 Transformed 36.000

Get

Copy Deep Copy Delete

Data Points

Unused parameters Power +

Used parameters Humidity

☐ Use in hover menu

Driver Limits

Driver SNMPv1

Domain 192.168.1.60

Port 161

Community public

OID 1.3.6.1.4.1.33688.5.1.1.3.191

Refresh time (in ms) 5000

Back Save

Add Device

Demo room

View Mode

Explorer


Name: E306-H000

Comment: E306-H000

Data Points

Humidity	36.000 %rel.H
Temperature	28.800 °C

Back Edit



The image shows a 3D perspective view of a room interior. In the center, there is a dark-colored cabinet or server rack with several doors open. To the right of the cabinet, a green vertical bar and a yellow sphere are highlighted with a red rectangular box. The room has light-colored walls and a tiled floor. On the left side of the interface, there is a control panel with various icons for navigation and settings. At the top right, there is a 'View Mode' button and an 'Explorer' button. On the right side, there is a panel showing the device's name, comment, and data points. At the bottom right, there are 'Back' and 'Edit' buttons.