



DW_fp_div_DG


Floating-Point Divider with Datapath Gating

Version, STAR, and myDesignWare Subscriptions: IP Directory

Features and Benefits

Revision History

- Has the same functionality as DW_fp_div when the component is in normal operation
- Consumes less dynamic power than DW_fp_div when disabled (inputs are active, but the output is not being used)
- The precision format is parameterizable for either IEEE single, double precision, or a user-defined custom format
- Hardware for denormal numbers of IEEE 754 standard is provided.
- Configurable to be fully compliant with the IEEE Std 754-1985 standard



- Configurable for NaN representation compatible with the IEEE Std 754-2008 standard (controlled by the *ieee_compliance* parameter)
- Faithful rounding with 1 ulp error is supported by parameter
- DesignWare datapath generators are employed for better power and QoR

Description

DW_fp_div_DG is a floating-point divider that divides two floating-point operands: a by b to produce a floating-point quotient, z. Also, a control input (DG_ctrl) can disable the component to reduce dynamic power consumption when the component is not in use and inputs are still active.

Table 1-1 Pin Description

Pin Name	Width	Direction	Function
а	(sig_width + exp_width + 1) bits	Input	Dividend
b	(sig_width + exp_width + 1) bits	Input	Divisor
rnd	3 bits	Input	Rounding mode; supports all rounding modes described in the <i>Datapath Floating-Point Overview</i> . The rnd port takes effect only when <i>faithful_round</i> = 0.
z	(sig_width + exp_width + 1) bits	Output	Quotient of A/B

Table 1-1 Pin Description (Continued)

Pin Name	Width	Direction	Function
status	8 bits	Output	 Status flags corresponding to z; for details, see STATUS Flags in the Datapath Floating-Point Overview status[6]: Underflow before rounding (UBR) status flag When enabled by the en_ubr_flag parameter, this flag indicates when the absolute value of a non-zero result, computed as though both the exponent range and the precision of the significand were unbounded, would lie strictly between ±MinNorm (minimum normalized value representable in the FP format defined by sig_width and exp_width). status[7]: Indicates divide-by-zero operation
DG_ctrl	1 bit	Input	Datapath gating control ■ 0: Component is disabled ■ 1: Normal component operation See also "Datapath Gating Control with DG_ctrl" on page 4.

Table 1-2 Parameter Description

Parameter	Values	Description	
sig_width	2 to 253 bits	Word length of fraction field of floating-point numbers $$ a, $$ b, and $$ z	
exp_width	3 to 31 bits	Word length of biased exponent of floating-point numbers a, b, and z	
ieee_compliance	0, 1, or 3	Level of support for the IEEE Std 754 standards:	
	Default: 0	 0: No support for NaNs and denormals; NaNs are considered infinities and denormals are considered zeros 	
		 1: Fully compliant with the IEEE Std 754-1985 standard, including support for NaNs and denormals 	
		■ 2: Reserved	
		■ 3: Fully compliant with the IEEE Std 754-1985 standard plus NaN representation that matches the IEEE Std 754-2008 standard ^a	
		For details, see Compatibility with IEEE Std 754 Standards in the <i>Datapath Floating-Point Overview</i>	

Table 1-2 Parameter Description

Parameter	Values	Description	
faithful_round	0 or 1 Default: 0	Choose either a specific rounding mode (set by ${\tt rnd}$) or a general rounding mode that allows maximum 1 ulp error	
		■ 0: Rounding mode is specific, as set by the rnd port; this choice increases the size of the resulting implementation.	
		■ 1: Rounding mode is general and, for $sig_width \le 23$, allows a maximum of 1 ulp error ^b ; this choice decreases the size of the resulting implementation.	
		When faithful_round = 1, note the following:	
		 The inexact status flag in the output is not meaningful. The UBR status flag (status[6]) is always 0 (disabled). 	
		The other status flags will match one of the possible outputs for the calculation when faithful_round = 0.	
en_ubr_flag	0 or 1	Controls when the UBR flag in status[6] is enabled	
	Default: 0	■ 0: The UBR status flag status[6] is disabled (the value of this flag is always 0).	
		■ 1: When this parameter is 1 and faithful_round = 0, status[6] carries the value of the UBR flag. If faithful_round = 1, even when en_ubr_flag = 1, the UBR flag in status[6] bit is always 0.	

- a. Propagating payload information to the output during the NaN process, which is an optional feature specified in the IEEE Std 754-2008 standard, is not supported.
- b. When *faithful_round* = 1 and *sig_width* > 23, the result can exceed 1 ulp for some corner cases. Configurations tested for this parameter range do not show errors larger than 2 ulps.

Table 1-3 Synthesis Implementations

Implementation Name	Function	License Feature Required
rtl	Datapath gating close to the main inputs (Digit-recurrence Method)	DesignWare (P-2019.03 and later)DesignWare-LP (before P-2019.03)
str	Datapath gating close to the main inputs (Newton-Raphson Method)	DesignWare (P-2019.03 and later)DesignWare-LP (before P-2019.03)
rtl2 ^a	Datapath gating to allow late arrival time of DG_ctrl signal	DesignWare (P-2019.03 and later)DesignWare-LP (before P-2019.03)
str2 ^a	Datapath gating to allow late arrival time of DG_ctrl signal	DesignWare (P-2019.03 and later)DesignWare-LP (before P-2019.03)

a. By default, the rtl2/strl2 implementation is used for synthesis (see "Datapath Gating Control with DG_ctrl" on page 4).

Table 1-4 Simulation Models

Model	Function
DW02.DW_FP_DIV_DG_CFG_SIM	Design unit name for VHDL simulation
dw/dw02/src/DW_fp_div_DG_sim.vhd	VHDL simulation model source code
dw/sim_ver/DW_fp_div_DG.v	Verilog simulation model source code

Datapath Gating Control with DG_ctrl

For DW_fp_div_DG and other combinational components that have the datapath gating feature, the DG_ctrl port is provided to control datapath gating.

When DG ctrl = 1, the component behaves as expected according to activity on the input ports.

When DG ctrl = 0:

- The component is disabled and internal gates are totally or partially isolated to block propagation of switching activity inside the component. This makes the component less sensitive to switching activity on the main ports and reduces dynamic power consumption.
- Values at the output ports are not defined.
- Simulation models set 'X' values at the output ports.

The implementations for DW_fp_div_DG (see Table 1-3 on page 3) perform datapath gating differently:

- The rtl/str implementation places datapath gating as close as possible to the input ports to maximize dynamic power savings when DG_ctrl = 0. However, if the DG_ctrl signal arrives later than the data inputs, timing is degraded and area is increased to recover timing, which can increase power.
- The rtl2/str2 implementation places datapath gating near the middle of the component. This approach is less sensitive to the arrival time of DG_ctlr and has a better chance of meeting timing and still providing dynamic power savings.

By default, the synthesis tool uses the rtl2/str2 implementation, but you can override that. If timing constraints are loose or you know that the signal driving the DG_ctrl port arrives at the same time as other input signals, greater power savings can be attained by using the rtl/str implementation. You can make the override on a global level or on a case-by-case basis, as explained next.

To use the rtl/str implementation globally, you can disable the rtl2/str2 implementation as follows:

■ Design Compiler (before version P-2019.03):

```
set_dont_use {dw_minpower.sldb/DW_fp_div_DG/rtl2
    dw minpower.sldb/DW fp div DG/str2}
```

■ Design Compiler (P-2019.03 and later)

```
set_dont_use {dw_foundation.sldb/DW_fp_div_DG/rt12
   dw foundation.sldb/DW fp div DG/str2}
```

Fusion Compiler:

```
set_synlib_dont_use {dw_foundation/DW_fp_div_DG/rt12
    dw foundation/DW fp div DG/str2}
```

To use the rtl or str implementation for specific instantiated components, use the set_implementation command. For example:

```
set implementation U1 rtl
```

Suppressing Warning Messages During Verilog Simulation

The Verilog simulation model includes macros that allow you to suppress warning messages during simulation.

To suppress all warning messages for all DWBB components, define the DW_SUPPRESS_WARN macro in either of the following ways:

■ Specify the Verilog preprocessing macro in Verilog code:

```
`define DW SUPPRESS WARN
```

• Or, include a command line option to the simulator, such as:

```
+define+DW SUPPRESS WARN (which is used for the Synopsys VCS simulator)
```

The warning messages for this model include the following:

■ If an invalid rounding mode has been detected on rnd, the following message is displayed:

```
WARNING: <instance_path>:
    at time = <timestamp>: Illegal rounding mode.
```

To suppress this message, use the DW_SUPPRESS_WARN macro explained earlier.

Related Topics

- Datapath Floating-Point Overview
- DesignWare Building Blocks User Guide

HDL Usage Through Component Instantiation - VHDL

```
library IEEE, DWARE;
use IEEE.std logic 1164.all;
use DWARE.DWpackages.all;
use DWARE.DW Foundation comp.all;
entity DW fp div DG inst is
      generic (
        inst sig width : POSITIVE := 23;
        inst exp width : POSITIVE := 8;
        inst ieee compliance : INTEGER := 0;
        inst_faithful_round : INTEGER := 0;
        inst en ubr flag : INTEGER := 0
        );
      port (
        inst a : in std logic vector(inst sig width+inst exp width downto 0);
        inst b : in std logic vector(inst sig width+inst exp width downto 0);
        inst rnd: in std logic vector(2 downto 0);
        inst DG ctrl : in std logic;
        z inst : out std logic vector(inst sig width+inst exp width downto 0);
        status inst : out std logic vector(7 downto 0)
        );
    end DW fp div DG inst;
architecture inst of DW fp div DG inst is
begin
    -- Instance of DW fp div DG
   U1 : DW fp div DG
    generic map ( sig width => inst sig width, exp width => inst exp width,
ieee compliance => inst ieee compliance, faithful round => inst faithful round,
en ubr flag => inst en ubr flag )
    port map ( a => inst a, b => inst b, rnd => inst rnd, DG ctrl => inst DG ctrl, z =>
z inst, status => status inst );
end inst;
-- pragma translate off
configuration DW fp div DG inst cfg inst of DW fp div DG inst is
 for inst
 end for; -- inst
end DW fp div DG inst cfg inst;
-- pragma translate on
```

HDL Usage Through Component Instantiation - Verilog

```
module DW fp div DG inst( inst a, inst b, inst rnd, inst DG ctrl, z inst,
          status inst );
parameter sig width = 23;
parameter exp width = 8;
parameter ieee compliance = 0;
parameter faithful round = 0;
parameter en ubr flag = 0;
input [sig_width+exp_width : 0] inst_a;
input [sig width+exp width: 0] inst b;
input [2 : 0] inst_rnd;
input inst DG ctrl;
output [sig width+exp width: 0] z inst;
output [7 : 0] status_inst;
    // Instance of DW fp div DG
    DW fp div DG #(sig width, exp width, ieee compliance, faithful round, en ubr flag)
      U1 ( .a(inst a), .b(inst b), .rnd(inst rnd), .DG ctrl(inst DG ctrl), .z(z inst),
.status(status inst) );
```

endmodule

Revision History

For notes about this release, see the *DesignWare Building Block IP Release Notes*.

For lists of both known and fixed issues for this component, refer to the STAR report.

For a version of this datasheet with visible change bars, click here.

Date	Release	Updates
April 2022	DWBB_202203.1	 Added the description of status[6] to Table 1-1 on page 1 Added the en_ubr_flag parameter to Table 1-2 on page 2 and to the examples on page 6 and page 7
January 2022	DWBB_202106.5	■ Adjusted description of the str implementation in Table 1-3 on page 3
October 2020	DWBB_202009.1	■ For enhanced NaN compatibility with the IEEE Std 754 standards, added a new value for <i>ieee_compliance</i> in Table 1-2 on page 2
July 2020	DWBB_201912.5	 Adjusted the description of the <i>ieee_compliance</i> parameter in Table 1-2 on page 2 Added "Suppressing Warning Messages During Verilog Simulation" on page 5
April 2020	DWBB_201912.3	 Updated the description of rnd in Table 1-1 on page 1 and faithful_round in Table 1-2 on page 2 For STAR 3124396, added a footnote to Table 1-2 on page 2 to update the error range when faithful_round = 1. This update is based on a limitation found during the investigation of STAR 3124396. Also, Table 1-5, "Error Ranges (ε = z − a/b)" was removed.
March 2019	DWBB_201903.0	 Added "Datapath Gating Control with DG_ctrl" on page 4 Clarified some information about minPower Added this Revision History table and the document links on this page

Copyright Notice and Proprietary Information

© 2022 Synopsys, Inc. All rights reserved. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at https://www.synopsys.com/company/legal/trademarks-brands.html.

All other product or company names may be trademarks of their respective owners.

Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

Synopsys, Inc. www.synopsys.com