

DW_inv_sqrt


Reciprocal of Square-Root

Version, STAR, and myDesignWare Subscriptions: IP Directory

Features and Benefits

Revision History

- Parameterized word length
- Combinational implementation to maximize speed
- Easy to pipeline for increased throughput



Description

The DW_inv_sqrt component provides a fixed-precision implementation of the reciprocal square-root of the input value, or $b = (\sqrt{a})^{-1}$.

Input a is a positive fraction in the following fixed-point format $a = (0.a_1a_2a_3a_4a_5...a_{a_width})$, where a_i represents a bit. In order to have a valid output the input must be in the range [1/4, 1], which means that at least one bit in the pair of bits (a_1, a_2) must have a value 1. When the input is outside these bounds, the output is unpredictable.

This component expects to receive as input only the fractional bits of the input a. The MS 0 bit used in the format above was included to indicate that input a represents a value smaller than 1.

With the given input range, the output values satisfy the relation 1 < b < 2 and are delivered in the format $b = (1.b_1b_2b_3b_4b_5...b_{a_width-1})$. The output contains all the bits indicated in this vector (including the fixed one bit at the MSB position).

An important property of this component is that all bits provided at the output are correct. This property is important to simplify rounding operations. In particular, it is consistent with the requirement for the rounding module DW_norm_rnd, provided in the DesignWare Library (for the datasheet, see DW_norm_rnd). Based on this observation, the output has an error $0 < e < 2^{a_width - 1}$. The error is always positive and less than the weight of the unit in the least position (ulp).

A $prec_control$ parameter enables the designer to reduce or increase the internal precision used in the component. When $prec_control = 0$, all the bits required for precise computation are used. This means there are no bits discarded in intermediate steps. A $prec_control = n > 0$ instructs the IP block to remove n LS bits of some internal variables in order to save area. Of course, when this is done, errors are introduced, and the component may not satisfy the conditions for exact rounding. The $prec_control$ parameter provides a trade-off between accuracy and cost.

Table 1-1 Pin Description

Pin Name	Width	Direction	Function
а	a_width bits	Input	Input fractional bits only

Table 1-1 Pin Description (Continued)

Pin Name	Width	Direction	Function
b	a_width bits	Output	Output data
t	1 bit	Output	sticky bit

Table 1-2 Parameter Description

Parameter	Values	Description
a_width	≥ 2	Word length of <i>a</i> and <i>b</i>
prec_control ^a	≤ (a_width - 2) / 2	Controls the number of LS bits that may be removed or added to the internal precision, where 0 implies to keep all the bits

a. Starting in the Z2007.03 release, the DW_inv_sqrt component has a tighter upper bound for the *prec_control* parameter (from *a_width*-2 to (*a_width*-2)/2). If you are using this parameter on an earlier released version of this component, there are two possible consequences when the most recent version is used: (1) the component will not elaborate for the *prec_control* value previously used if the value is now out of range, and (2) the component will not have the same numerical behavior as before for the same *prec_control* value.
 As a rule of thumb to get the same numerical behavior: a previous value x should be mapped to a value y=floor(x-

As a rule of thumb to get the same numerical behavior: a previous value x should be mapped to a value $y=floor(x-(a_width-2)/2)$, if the mapped value y is positive, or 0 otherwise.

Table 1-3 Synthesis Implementations

Implementation Name	Function	License Feature Required
rtl	Implement using the Datapath Generator technology combined with static DesignWare components	DesignWare

Table 1-4 Simulation Models

Model	Function
DW01.DW_INV_SQRT_SIM	Design unit name for VHDL simulation
dw/dw01/src/DW_inv_sqrt_sim.vhd	VHDL simulation model source code
dw/sim_ver/DW_inv_sqrt.v	Verilog simulation model source code

The output *t* (sticky bit) is 1 when there are non-zero bits following the LS bit of the b output. This information is useful for rounding.

A numerical example of the component behavior is given as follows, for $a_width = 10$ bits:

a = 0.01101111001 = 0.4306640625

b = 1.100001100 = 1.5234375

Using infinite precision, the result would be:

 b_{∞} = **1.100001100**00110000110000110000... where the bolded digits represent the digits generated by the component. All of them match the infinite precision result. The output of the DW_inv_sqrt is always less than the infinite precision value, and its error is computed in this example as:

$$Error = b_{\infty} - b \approx 0.000372 < ulp = 2^{-9} \approx 0.001953$$

This component provides a very fast implementation of the inverse square-root function. When exact rounding is not a requirement, you can use the *prec_control* parameter to obtain design trade-offs between area/delay and error. Increasing *prec_control* reduces the area and delay in the design.

Another alternative, when larger errors are allowed, is to use a combination of the DW_div and DW_sqrt components.

Example 1-1 VHDL example:

```
architecture small of inv sqrt is
       signal square root : std logic vector(a width-1 downto 0);
       signal extended input : std logic vector(2*a width-1 downto 0);
       signal numerator: std logic vector(2*a width-1 downto 0);
       signal zero vector1 : std logic vector(a_width-1 downto 0);
       signal zero vector2 : std logic vector(2*a width-2 downto 0);
       signal b int : std logic vector(2*a width-1 downto 0);
begin
-- initialize the vectors
       zero vector1 <= (others => '0');
       zero vector2 <= (others => '0');
-- extend the input since the square root is done for integers and
-- the output has half of the input precision
       extended input <= a & zero vector1;
-- compute the square root of the extended input
square_root <= _std_logic_vector_(DWF_sqrt (unsigned(extended input)));</pre>
-- create the numerator of the integer division to compute inverse value
       numerator <= '1' & zero vector2;
-- perform the division
       b int <= unsigned(numerator) / unsigned(square root);</pre>
-- throw away the MS zeros
       b <= b int (a width-1 downto 0);</pre>
end archname;
```

Example 1-2 Verilog example:

```
module DW inv sqrt (a, b);
parameter a width = 8;
input [a width-1 : 0] a;
output [a width-1 : 0] b;
reg [a width-1: 0] square root;
reg [2*a width-1:0] extended input;
reg [2*a width-1 : 0] numerator;
reg [a_width-1 : 0] zero_vector1;
reg [2*a width-2 : 0] zero vector2;
reg [2*a width-1 : 0] b int;
parameter width = 2*a width;
`include "DW sgrt function.inc"
always @(a)
begin
// initialize the vectors
 zero vector1 = 0;
 zero vector2 = 0;
// create the numerator of the integer division to compute inverse value
 numerator = {1'b1, zero_vector2};
// extend the input since the square root is done for integers and
// the output has half of the input precision
 extended input = {a, zero vector1};
// compute the square root of the extended input
 square root = DWF sqrt uns (extended input);
// perform the division
 b int = numerator / square root;
end
// throw away the MS zeros
 assign b = b int[a width-1 : 0];
endmodule
```

This solution provides a small implementation of the inverse square-root function. However, it is not functionally equivalent to DW_{inv_sqrt} when $prec_control = 0$.

Alternative Implementation of Reciprocal Square Root with DW_lp_multifunc

The reciprocal square root operation can also be implemented by DW_lp_multifunc component, which evaluates the value of reciprocal square root with 1 ulp error bound. There will be 1 ulp difference between the value from DW_lp_multifunc and the value from DW_invsqrt. Performance and area of the synthesis results are different between the DW_invsqrt and reciprocal square root implementation of the DW_lp_multifunc, depending on synthesis constraints, library cells and synthesis environments. By comparing performance and area between the reciprocal square root implementation of DW_lp_multifunc and DW_invsqrt component, the DW_lp_multifunc provides more choices for the better synthesis results. Below is an example of the Verilog description for the reciprocal square root of the DW_lp_multifunc. For more detailed information, see the DW_lp_multifunc datasheet.

```
DW lp multifunc #(op width, 4) U1 (
    .a(a),
    .func(16'h0004),
    .z(z),
    .status(status)
);
```

Related Topics

- Logic Combinational Overview
- DesignWare Building Block IP User Guide

HDL Usage Through Component Instantiation - VHDL

```
library IEEE,DWARE;
use IEEE.std logic 1164.all;
use DWARE.DWpackages.all;
use DWARE.DW foundation comp.all;
entity DW inv sqrt inst is
      generic (
        inst a width : POSITIVE := 8
        );
      port (
        inst_a : in std_logic_vector(inst_a_width-1 downto 0);
        b inst : out std logic vector(inst a width-1 downto 0);
        t_inst : out std_logic
        );
    end DW inv sqrt inst;
architecture inst of DW inv sqrt inst is
begin
    -- Instance of DW_inv_sqrt
    U1 : DW inv sqrt
    generic map ( a width => inst a width )
    port map ( a => inst_a, b => b_inst, t => t_inst );
end inst;
```

HDL Usage Through Component Instantiation - Verilog

```
module DW_inv_sqrt_inst( inst_a, b_inst, t_inst );
parameter a_width = 8;

input [a_width-1 : 0] inst_a;
output [a_width-1 : 0] b_inst;
output t_inst;

// Instance of DW_inv_sqrt
DW_inv_sqrt #(a_width)
U1 ( .a(inst_a), .b(b_inst), .t(t_inst) );
endmodule
```

Revision History

For notes about this release, see the *DesignWare Building Block IP Release Notes*.

For lists of both known and fixed issues for this component, refer to the STAR report.

For a version of this datasheet with visible change bars, click here.

Date	Release	Updates
January 2020	DWBB_201912.1	■ Corrected port names for DW_lp_multifunc in "Alternative Implementation of Reciprocal Square Root with DW_lp_multifunc" on page 5
July 2019	DWBB_201903.3	■ Removed reference to minPower library in "Alternative Implementation of Reciprocal Square Root with DW_lp_multifunc" on page 5
January 2019	DWBB_201806.5	 Updated example in "HDL Usage Through Component Instantiation - VHDL" on page 6 Added this Revision History table and the document links on this page

Copyright Notice and Proprietary Information

© 2022 Synopsys, Inc. All rights reserved. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at https://www.synopsys.com/company/legal/trademarks-brands.html.

All other product or company names may be trademarks of their respective owners.

Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

Synopsys, Inc. www.synopsys.com