DW_bc_1

Boundary Scan Cell Type BC_1

Version, STAR and Download Information: IP Directory

Features and Benefits

Revision History

- IEEE Standard 1149.1 compliant
- Synchronous or asynchronous scan cells with respect to `tck`
- Supports the standard instructions: EXTEST, SAMPLE/PRELOAD, and BYPASS
- Supports the optional instructions INTEST, RUNBIST, CLAMP, and HIGHZ



Description

DW_bc_1 is a boundary scan cell that can be used as a system input cell or as an output cell. When used as an input cell, DW_bc_1 provides control over the inputs to the core logic of the IC. When used as an output cell, DW_bc_1 provides control over the IC output signals. The Boundary Scan Description Language (BSDL) description of this cell is of type BC_1 described in the BSDL package STD_1149_1_1990.

The DW_bc_1 cell can be synchronous or asynchronous with respect to `tck` (Test Clock system pin), depending on the port connections.

The `mode` signal gives the Test Access Port (TAP) instructions control of the boundary scan cell.

Table 1-1 Pin Description

Pin Name	Width	Direction	Function
capture_clk	1 bit	Input	Clocks data into the capture stage
update_clk	1 bit	Input	Clocks data into the update stage
capture_en	1 bit	Input	Enable for data clocked into the capture stage, active low
update_en	1 bit	Input	Enable for data clocked into the update stage, active high
shift_dr	1 bit	Input	Enables the boundary scan chain to shift data one stage toward its serial output (tdo)
mode	1 bit	Input	Determines whether `data_out` is controlled by the boundary scan cell or by the `data_in` signal
si	1 bit	Input	Serial path from the previous boundary scan cell
data_in	1 bit	Input	Input data

Table 1-1 Pin Description (Continued)

Pin Name	Width	Direction	Function
data_out	1 bit	Output	Output data
so	1 bit	Output	Serial path to the next boundary scan cell

Table 1-2 Synthesis Implementations

Implementation Name	Function	License Feature Required
str	Synthesis model	DesignWare or Test-IEEE-STD-1149-1

Table 1-3 Simulation Models

Model	Function
DW04.DW_BC_1_CFG_SIM	Design unit name for VHDL simulation
dw/dw04/src/DW_bc_1_sim.vhd	VHDL simulation model source code
dw/sim_ver/DW_bc_1.v	Verilog simulation model source code

Table 1-4 lists the required values of the `mode` signal for each of the TAP instructions that DW_bc_1 supports.

Table 1-4 Mode Signal Generation for DW_bc_1

Instruction	Mode for Input Cell	Mode for Output Cell
EXTEST	1	1
SAMPLE/PRELOAD	0	0
INTEST	1	1[a]
CLAMP	X	1
RUNBIST	X	1[a]
BYPASS	0	0

a. If you do not want these instructions to drive the output pins with pre-loaded data held in the boundary scan register, then these instructions are not needed to determine the state of the `mode` signal. Instead, the instruction must be added to the output enable logic to force every system output pin to an inactive drive state.

Table 1-5 lists the connections for asynchronous boundary scan chains.

Table 1-5 Port Connections for Asynchronous Boundary Scan Chains

DW_bc_1 Port Name	Connection
capture_clk	clock_dr from TAP controller
update_clk	update_dr from TAP controller
capture_en	Logic zero
update_en	Logic one
shift_dr	shift_dr from TAP controller
mode	Mode generation logic
si	so from previous boundary scan cell
data_in	System input pin for input cells or IC output logic for output cells
data_out	IC input logic for input cells or system output pin for output cells
so	si of next boundary scan cell

Table 1-6 lists the connections for synchronous boundary scan chains.

Table 1-6 Port Connections for Synchronous Boundary Scan Chains

DW_bc_1 Port Name	Connection
capture_clk	tck from system pin
update_clk	tck_n from system pin
capture_en	sync_capture_en from TAP controller
update_en	sync_update_dr from TAP controller
shift_dr	shift_dr from TAP controller
mode	Mode generation logic
si	so from previous boundary scan cell
data_in	System input pin for input cells or IC output logic for output cells
data_out	IC input logic for input cells or system output pin for output cells
so	si of next boundary scan cell

Related Topics

- Application Specific – JTAG Overview
- DesignWare Building Block IP User Guide

HDL Usage Through Component Instantiation - VHDL

```
library IEEE,DWARE;
use IEEE.std_logic_1164.all;
use DWARE.DWpackages.all;
use DWARE.DW_foundation_comp.all;

entity DW_bc_1_inst is
  port (inst_capture_clk : in std_logic;  inst_update_clk  : in std_logic;
        inst_capture_en  : in std_logic;  inst_update_en   : in std_logic;
        inst_shift_dr    : in std_logic;  inst_mode        : in std_logic;
        inst_si          : in std_logic;  inst_data_in     : in std_logic;
        data_out_inst    : out std_logic; so_inst          : out std_logic );
end DW_bc_1_inst;

architecture inst of DW_bc_1_inst is
begin
  -- Instance of DW_bc_1
  U1 : DW_bc_1
    port map (capture_clk => inst_capture_clk,
              update_clk => inst_update_clk,   capture_en => inst_capture_en,
              update_en => inst_update_en,   shift_dr => inst_shift_dr,
              mode => inst_mode,   si => inst_si,   data_in => inst_data_in,
              data_out => data_out_inst,   so => so_inst );
end inst;

-- pragma translate_off
configuration DW_bc_1_inst_cfg_inst of DW_bc_1_inst is
  for inst
  end for; -- inst
end DW_bc_1_inst_cfg_inst;
-- pragma translate_on
```

HDL Usage Through Component Instantiation - Verilog

```
module DW_bc_1_inst(inst_capture_clk, inst_update_clk, inst_capture_en,
                    inst_update_en, inst_shift_dr, inst_mode, inst_si,
                    inst_data_in, data_out_inst, so_inst );

  input inst_capture_clk;
  input inst_update_clk;
  input inst_capture_en;
  input inst_update_en;
  input inst_shift_dr;
  input inst_mode;
  input inst_si;
  input inst_data_in;
  output data_out_inst;
  output so_inst;

  // Instance of DW_bc_1
  DW_bc_1
    U1 (.capture_clk(inst_capture_clk),   .update_clk(inst_update_clk),
        .capture_en(inst_capture_en),   .update_en(inst_update_en),
        .shift_dr(inst_shift_dr),   .mode(inst_mode),   .si(inst_si),
        .data_in(inst_data_in),   .data_out(data_out_inst),   .so(so_inst) );
endmodule
```

Revision History

For notes about this release, see the *DesignWare Building Block IP Release Notes*.

For lists of both known and fixed issues for this component, refer to the STAR report.

For a version of this datasheet with visible change bars, click here.

Date	Release	Updates
January 2019	DWBB_201806.5	■ Updated example in "HDL Usage Through Component Instantiation - VHDL" on page 4 ■ Added this Revision History table and the document links on this page

Copyright Notice and Proprietary Information

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at https://www.synopsys.com/company/legal/trademarks-brands.html.

All other product or company names may be trademarks of their respective owners.

Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

Synopsys, Inc.
www.synopsys.com