BRUSH UNIT N100

OPERATIONS & DRY DRAFTING STEPS

- 1. Position your unit and apply your parking brake. Leave the unit running.
- 2. Chock your rear tires front and back if possible.
- 3. Open fuel line near fuel tank.
- 4. Open foam valve (if needed).
- 5. Turn on Master Disconnect switch to "ON".
- 6. Flip the Ignition toggle switch to "**ON**" position (UP).
- 7. If the engine is cold pull the choke.
- 8. Press the starter and hold till the engine starts.
- 9. Push choke back in if needed.
- 10. Make sure all drains are closed.
- 11. Open/Pull tank to pump.
- 12. Open halfway tank fill valve.
- 13. Twist/Pull throttle to the left to increase to 50 psi

IF DRAFTING

- 14. Check all gaskets on suction hoses.
- 15. Connect suction hose line to suction intake.
- 16. Connect clapper valve to the suction hose.
- 17. Place suction hose into the water source.
- 18. Open your discharge line and close tank fill.
- 19. Close your tank to pump and open Suction intake.
- 20. Crack the primer valve and begin hand pumping until you see your pressure gauge increase. Then close your primer valve.
- 21. Look, Listen, Feel for your draft.
- 22. If you didn't establish a draft. Go back to step 17 after draining water from suction hose.
- 23. Set and monitor pressures, open tank fill if needed to fill onboard tank.
- 24. Once Operations are completed. Close fuel line near fuel tank.