Brush N104-N103-I557-K442 Draft Steps

30-32-35-46

- 1) Place the truck in the park with the parking brake on. Leave the truck running. Chock the wheels.
- 2) Make sure all drains are closed.
- 3) Turn on the power.
- 4) If the engine is cold pull the choke.
- 5) Turn on the ignition.
- 6) Press the starter and hold till the engine starts.
- 7) Pushed back in the choke.
- 8) Open the tank to pump.
- 9) Partly open tank fill.
- 10) Twist the throttle knob to 50 psi.
- 11) Check all gaskets on the suction hose.
- 12) Connect the suction line.
- 13) Place the clapper valve on the suction hose.
- 14) Place the suction hose in the water source.
- 15) Close the tank to pump.
- 16) If you want to have a re-circ line in the water source pull the booster line to the water source and have the bail half open. Open the booster valve and close tank fill. If not tank fill will work just fine
- 17) Open the suction inlet.
- 18) Open valve on hand pump.
- 19) Work the hand pump to expel the air. You will start to see the water travel up the drafting hose.
- 20) Look, listen, and feel for the draft.
- 21) Turn off the valve on our primer line.
- 22) If you closed the tank fill now open it slowly, than close our re-circ line.