Brush N100-N101-N102 Draft steps

40-41-34

- Place the truck in the park with the parking brake on. Leave the truck running.
- 2) Make sure all drains are closed.
- 3) Turn on the power.
- 4) If the engine is cold pull the choke.
- 5) Turn on the ignition.
- 6) Press the starter and hold till the engine starts.
- 7) Pushed back in the choke.
- 8) Open the tank to pump.
- 9) Partly open tank fill.
- 10) Twist the throttle knob to 50 psi.
- 11) Check all gaskets on the suction hose.
- 12) Connect the suction line.
- 13) Place the clapper valve on the suction hose.
- 14) Place the suction hose in the water source.
- 15) Turn the air system to run and fixed.
- 16) Close the tank to pump.
- 17) If you want to have a re-circ line in the water source pull the booster line to the water source and have the bail half open. Open the booster valve and close tank fill. If not tank fill will work just fine
- 18) Open the suction inlet.
- 19) Turn the air on.
- 20) Look, listen, and feel for the draft.
- 21) Once the draft is pulled turn off the air
- 22) If you closed the tank fill now open it slowly, than close booster valve slowly.