Tender Drafting Set up

Place truck into pump and chock your tires (**both wheel chocks if possible**).

Open your tank to pump and crack your tank fill/re-circ line valve.

Set up your 10-20 ft drafting hose (checking for your gaskets) to 2 ½ inlet valve (at pump) and attach your barrel strainer.

Set up 1 ¾ in Re-circ line and attach a nozzle.

Ready for drafting

- 1. Place governor in RPM mode.
- 2. Throttle up to appropriate RPM (1,000 rpm).
- 3. Open 1 % in. Re-circ. line (bail fully open) 30-50 psi
- 4. Transition by opening inlet (**D.S auxiliary inlet**) and **close** Tank to Pump and the tank fill/re-circ. line.
- 5. Pull the primer 30-50 sec. LOOK, LISTEN, FEEL.
- 6. Draft complete. (Water coming in, water going out)
- 7. Reassess, Reassess