

Н


Х

FUNCTION A port = B1 port

A port = B2 port


Disconnect


PWR OPWR





PWR O PWR PWR O PWR PWR O PWR CS FL N MOSI FL MISO FL MISO FL MISO FL MISO FL MISO FL SCLK FL SCLK FL N CS FL N CS

GND












2-WAY JUMPER - POWER SUPPLY SELECT

NOTE: Disconnect power adapter and arduino USB cable prior to changing jumper settings. Risk of electric shock or damage to board.





Arduino 3V3 supply severely limits current -driving from 5V0 input into independent LDO

5V0 500mA Output (USB)





SRAM0 A[17..0] SRAM0_A[17..0] SRAM0 D[15..0] SRAM0 D[15..0] -SRAM0 CS N ← SRAMO US N SRAMO US N SRAMO US N SRAMO HBE N SRAMO LBE N SRAM0 SRAMO WE N -SRAMO_OE_N -SRAMO HBE N -SRAMO_LBE_N -











J4

0 0

• •

• •

0 0