#### installation notes

### to get the plugin running


- copy SDRSharp.EasyScanner.dll into the SDRSharp directry
- edit SDRSharp.exe.config
  - goto <sharpPlugins> section and add one line as described below

```
<sharpPlugins>
  <add key="EasyScanner" value="SDRSharp.EasyScanner.EasyScannerPlugin,SDRSharp.EasyScanner" />
<sharpPlugins>
```


#### Tested with

- WIN7, 64Bit
- SDRSharp Continuous Integration, Last Changed Rev: 1111
- Terratec NOXON DAB/DAB+ USB dongle (rev 1)
- ezcap USB 2.0 DVB-T/DAB/FM dongle

gui elements & short desription - control tab




gui elements & short desription - frequency list tab



Scan list Manager, same operations as frequency manager plugin. only a few changes

- new field for trigger level
- filtered list (=displayed) list is taken as scanlist
- current tuned freugency is highlighted in the list (blue = scan, green = stay tuned)

### states of operation



### version history

- v01 25.01.2013
  - 1st public version (called Scanner Plugin)
- v02 07.02.2013
  - rename to EasyScanner Plugin
  - add peak power bandwidth mode
  - add watchdog timer

#### notes

#### Contact

• haocri@googlemail.com

### EasyScanner Plugin Source Code

• <a href="https://www.assembla.com/code/sdrsoft/subversion/nodes">https://www.assembla.com/code/sdrsoft/subversion/nodes</a>

### EasyScanner Plugin Releases

• https://www.assembla.com/code/sdrsoft/subversion/nodes/trunk/EasyScannerPlugin/release