

WORKING PROCEDURE

PRO-SEC-010A

Procedure for sharpening bit underground

OBJECTIVES

The purpose of this procedure is to define safe methods for sharpening and shaping a drill bit.

APPLICATION

This procedure applies to all employees of MACHINES ROGER INTERNATIONAL.

INTERPRETATION

The staff with authority for the interpretation of this document is the Superintendent Health and Safety. Any request for modification, revision or update must be made to one of this person.

RESPONSIBILITIES

The worker is responsible for his work and must make sure to follow this procedure and follow these instructions. He must also inspect his PPE to ensure that they are in good condition.

PERSONEL PROTECTION EQUIPMENT

- Rubber glove
- Rain overalls
- Visor (shaping)
- Ear protection
- Goggle (sharpening)

PROCEDURE

INSTALLATION

The use of the tripod is required. It must be positioned away from the drill and the spark projection must be considered.

Electrical connections must be hooked to avoid contact with water.

SHAPING

Shaping is the first step. Before starting this step the worker should check the condition of the disc grinder. This must be equipped with an automatic braking system.

The handle and the guard of the disc must be present. You must also check that the switch is working properly.

When shaping the complete wear of all PPE is mandatory including the visor.

SHARPENING THE CARBIDES

For this second step, you must

- 1- Make sure that the water and air supply hoses are firmly attached to the tool;
- 2- That the handle of the air valve is in place and functional;
- 3- Open the air slowly;
- 4- Check the correct operation of the pneumatic sander;
- 5- That the lubrication system is filled.
- 6- Choose the right grinding wheel according to the diameter of the button to be sharpened.

When sanding, the wearing of GOGGLES and all other PPE is mandatory.



Stéphane Tremblay
Surintendant Santé-Sécurité