FRANMARINE UNDERWATER SERVICES PTY LTD

MOORING AND BERTHING

Procedure

MV INTEGRITY III | UVI: 414562

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-INT3-05C
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Integrity III (UVI 414562)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved
01	7 July 2026	M. Hilder	Initial issue	K. Hamilton

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution

This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

TABLE OF CONTENTS

1. PURPOSE AND SCOPE

This procedure establishes safe mooring, berthing, unberthing, and positioning procedures for MV Integrity III, including operations near marine structures.

1.1 Regulatory Reference

Marine Order 504 (2024), Schedule 1, Clause 11(5).

2. GENERAL REQUIREMENTS

- Mooring and berthing operations shall be conducted at safe speed with due regard to wind, current, and tide.
- Fenders shall be deployed on the side of approach before contact with the berth or structure.
- All personnel on deck during berthing shall wear lifejackets.
- Clear communication shall be maintained between master and crew.

3. BERTHING PROCEDURE

3.1 Approach

- Assess wind, current, and traffic. Plan the approach angle and speed.
- Communicate the berthing plan to crew.
- Reduce speed to minimum steerage way. Deploy fenders.

3.2 Making Fast

- Secure bow line first, then stern line.
- Adjust spring lines to prevent surging.
- Verify all lines properly cleated with no chafing. Check fender positions.

3.3 At Berth

- Shut down engines per FUS-SMS-INT3-05B.
- Rig safe means of access per FUS-SMS-INT3-05D.

4. UNBERTHING PROCEDURE

- Start engines per FUS-SMS-INT3-05B. Brief crew.
- Remove means of access. Single up lines.
- Release stern line, then bow line (or as appropriate for conditions).
- Depart at minimum steerage way until clear. Stow fenders and lines.

5. MOORING TO A BUOY

- Approach slowly, heading into wind or current.
- Crew uses boat hook to pick up mooring pendant. Secure to bow cleat.
- Settle astern and verify mooring is holding. Shut down engines.

6. ANCHORING

- Select position with adequate depth, swing room, and shelter.
- Approach heading into wind or current at minimum speed.
- Lower anchor under control. Pay out minimum 5:1 scope (7:1 in heavy weather).
- Set anchor with gentle astern thrust. Take bearings to monitor for dragging.
- Display anchor signal (all-round white light at night; black ball by day).

7. OPERATIONS NEAR MARINE STRUCTURES

7.1 Approach and Positioning

- Use slow, controlled manoeuvring. Deploy fenders.
- Maintain a dedicated helmsman at the controls when alongside a pile or wall.
- Use spring lines or running moor for extended fixed-position operations.
- Be aware of tidal range and clearance above/below structures.

7.2 Over-Side Equipment Handling

- Secure all equipment with lanyards or tethers before deploying over the side.
- Manage electrical cables to prevent entanglement with the propellers.
- Recover equipment before repositioning the vessel.
- All personnel near the gunwale shall wear lifejackets.

8. REFERENCES

- FUS-SMS-INT3-05B Vessel Start-Up and Shut-Down
- FUS-SMS-INT3-05D Means of Access
- FUS-SMS-INT3-05F Navigation and Watchkeeping
- Marine Order 504 (2024), Schedule 1, Clause 11(5)