FRANMARINE UNDERWATER SERVICES PTY LTD

LOSS OF PROPULSION

Emergency Procedure

MV INTEGRITY III | UVI: 414562

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-INT3-06F
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Integrity III (UVI 414562)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved
01	7 July 2026	M. Hilder	Initial issue	K. Hamilton

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution

This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

TABLE OF CONTENTS

1. PURPOSE

This procedure establishes the actions to be taken in the event of a loss of propulsion on MV Integrity III.

1.1 Regulatory Reference

Marine Order 504 (2024), Schedule 1, Clause 12.

2. IMMEDIATE ACTIONS

- Alert all crew.
- Assess the situation. If one engine has failed, the vessel can still navigate on the remaining engine — reduce speed and proceed with caution.
- If both engines have failed, deploy the anchor immediately if in shallow water to prevent drift into a hazard.
- Issue a PAN PAN call on VHF Ch 16 advising of the loss of propulsion, position, number of persons on board, and whether assistance is required.

3. TROUBLESHOOTING

Common causes of propulsion loss:

- Fuel starvation — check fuel level, fuel filter, and fuel line for blockages or air locks.
- Overheating — check cooling tell-tale. If no flow, check for blockage in the water intake.
- Propeller fouled — inspect for rope, net, or debris. If safe and conditions permit, clear the propeller manually.
- Electrical failure — check battery connections and fuses.
- Kill switch activated — check lanyard connection.

4. EMERGENCY ACTIONS

- If the fault cannot be rectified, anchor the vessel in a safe position.
- Request a tow from Marine Rescue NSW, a nearby vessel, or a commercial towing service.
- Ensure all persons are wearing PFDs.
- Display the signals for a vessel not under command (two all-round red lights in a vertical line at night, or two balls in a vertical line by day) if available, or use other means to indicate the vessel is unable to manoeuvre.

5. POST-INCIDENT

- Do not restart engines until the cause is established and rectified.
- Report to the East Coast Operations Superintendent.
- Record all details in the vessel logbook.
- Arrange for inspection and repair before the vessel returns to service.

6. REFERENCES

- FUS-SMS-INT3-06 Emergency Plan
- FUS-SMS-INT3-07 Maintenance
- Marine Order 504 (2024), Schedule 1, Clause 12