FRANMARINE UNDERWATER SERVICES PTY LTD

GROUNDING

Emergency Procedure

MV SEAGULL | UVI: 425689

Marine Order 504 (2024) — Schedule 1 Compliance

Document Number:	FUS-SMS-SGL-06H
Revision:	01
Date:	7 July 2026
Author:	Matthew Hilder
Reviewed By:	Belinda Brooks
Approved By:	Kirby Hamilton
Vessel:	MV Seagull (UVI 425689)

DOCUMENT CONTROL

Revision History

Rev	Date	Author	Description	Approved
01	7 July 2026	M. Hilder	Initial issue	K. Hamilton

Approval

Role	Name	Date
Author	Matthew Hilder	7 July 2026
Reviewed	Belinda Brooks	7 July 2026
Approved	Kirby Hamilton	7 July 2026

Review Frequency

This document shall be reviewed at least every 12 months, or sooner following a significant incident, change of operations, vessel modification, or change in applicable legislation.

Controlled Distribution

This document is a controlled distribution issued from the Franmarine document management system (DMS), which holds the master record, revision history, and approval log. The controlled digital copy is located in the vessel's SharePoint folder. Printed or downloaded copies are uncontrolled; refer to the SMS Document Register for the current revision status.

TABLE OF CONTENTS

1. PURPOSE

This procedure establishes the actions to be taken in the event of MV Seagull running aground.

1.1 Regulatory Reference

Marine Order 504 (2024), Schedule 1, Clause 12.

2. IMMEDIATE ACTIONS

- Stop the engine immediately to prevent further damage and propeller fouling.
- Check for injuries to all persons on board.
- Check for hull damage and water ingress.
- Trim the engine up to protect the propeller and drive unit.
- Assess the tidal state — determine whether the tide is rising or falling.

3. NOTIFICATION

- Issue a PAN PAN on VHF Ch 16 advising of the grounding, position, and vessel status.
- Notify the East Coast Operations Superintendent.
- If in the operational area, advise Sydney VTS on VHF Ch 13.

4. REFLOATING

Attempt to refloat only if:

- The hull is intact and not taking water.
- The tide is rising.
- The bottom is soft (sand or mud) and there is no risk of further hull damage.

Refloating actions:

- Shift weight aft to raise the bow.
- If safe, use the engine in reverse at low power to back off.
- Request a tow from a suitable vessel if own propulsion cannot refloat.
- Do not apply excessive power as this may cause further damage or worsen the grounding.

5. IF UNABLE TO REFLOAT

- Ensure all persons are wearing PFDs.
- Display the signals for a vessel aground (three balls by day; two red lights plus anchor light at night) if available.
- If the vessel is in danger of breaking up or the hull is compromised, prepare to abandon to the shore or another vessel.
- Request professional salvage assistance.

6. POST-INCIDENT

- Once refloated, inspect the hull, drive unit, and running gear for damage before proceeding.
- Proceed at slow speed to the nearest safe berth.
- Record all details in the vessel logbook.
- Complete an incident report.
- Report to AMSA if applicable.

7. REFERENCES

- FUS-SMS-SGL-06 Emergency Plan
- FUS-SMS-SGL-06I Flooding Emergency Procedure
- Marine Order 504 (2024), Schedule 1, Clause 12