FT-ITC ANALYSIS · USER MANUAL

FT-ITC Analysis User manual

Processing, fitting, and interpreting isothermal titration calorimetry experiments.

VERSION 1.0.0 · FOR WINDOWS, MACOS, AND LINUX
Nicolas Le Roux

Print / Save as PDF ↗

Contents

01 **FT-ITC Analysis user manual**
Start here to use FT-ITC Analysis and the conventions used throughout this manual.

02 **Quick start**
Open your first dataset, process it, fit a one-site model, and export the results.

03 **Installation, files, and projects**
Install FT-ITC Analysis, open experiment files, and create projects, and use sessions or recovery files.

04 **Workspace**
The main window, ribbon, experiment lists, inspectors, and keyboard shortcuts.

05 **Processing**
Integration methods, baseline regions, injection uncertainty, and processing propagation and locking.

06 **Single-experiment fitting**
Binding models, fitting parameters, global and competitive options, constant injection removal, and Monte Carlo diagnostics.

07 **Multiple-experiment fitting**
Global fits across titrations, shared parameter assignments, including constraints, shared options, diagnostics, and combined results.

08 **Results and advanced analyses**
Result tables, plots, exports, model comparison, confidence estimation, and advanced analyses.

09 **Figures and export**
Figure tabs, interactive plots, layouts, print and graphic export dialogs, results figures, and combined analysis exports.

10 **Tools**
Global settings, themes, custom buffer controls, and range templates for batch-mode baseline assignments.

11 **Settings and defaults**
Application settings, processing, processing, fitting, and export.

12 **Glossary and equations**
Terminology, thermodynamic relationships, calculation symbols, equations, and references.

CHAPTER 01

FT-ITC Analysis user manual

Start here for a tour of FT-ITC Analysis and the conventions used throughout this manual.

Last updated: 2026-05-13

FT-ITC Analysis is a desktop application for processing, fitting, comparing, and presenting isothermal titration calorimetry (ITC) experiments.

This manual is for ITC practitioners who are new to FT-ITC Analysis. It explains how to use the application's interface and provides guidance on scientific interpretation and best practices for rigorous analysis.

These instructions apply on macOS, Windows, and Linux. The manual treats the supported operating systems as one product. **Platform-note** appears only when an operating system or interface difference changes how you complete a task.

NOTE
This edition reflects FT-ITC Analysis 1.0.0 and was written on the date shown for each page.

What the application does

FT-ITC Analysis supports the complete workflow from compatible instrument data to a saved analysis project. The application can:

1. Import a raw thermogram, integrated heats, or an existing project.
2. Review and edit experiment details, concentrations, cell volume, and buffers.
3. Process thermograms using baseline modes, spline settings, and manual or automatic integration-region assignments.
4. Fit one or more experiments with a supported binding model.
5. Review fitted parameters, uncertainties, residuals, and result tables.
6. Save portable projects or files. [Chapter 3: Installation, files, and projects]
7. Export figures, numerical data, and results.

Raw-heat files are read, not edited. Importing creates a local experiment data set with adjusted binding-unit values. An optional blank-titration file enables blank-subtraction and global-fitting workflows. Saved projects store the current processing and fitting state, including manual corrections to the loaded interpretation and any gaps in its data, which are preserved. Derived results are retained without automatic recalculation. The separate browser-based Project Viewer at the same domain opens saved projects read-only for review and sharing. [Chapter 8: Results and advanced analyses: Result tables and plots and Analysis Report]

Product tour

The desktop window's ribbon experiments and completed Analysis Results. Selecting an experiment exposes four shared task views:

- **Overview** summarizes the experiment and provides access to its details.
- **Process Data** builds and refines baselines, adjusts injection regions, and corrects a raw thermogram. [Chapter 5: Processing: Processing workflow]
- **Analyze Data** fits a single experiment or multiple experiments.
- **Final Figure** presents the thermogram, heats, fitted curve, residuals, and annotations.

Selecting an Analysis Result opens its result workspace, with a parameter summary, residuals, fits, parameter correlation, uncertainty display, and any comparable advanced analyses. The menus provide project, import, export, and application commands; the ribbon provides the same tasks, mode, plot, and figure commands as the visible controls. [Chapter 4: Workspace: Ribbon and menus] and [Chapter 9: Figures and export: Figure tabs, layouts, and annotations]

Manual conventions

The shortest route to the result is Quick start, which uses your own compatible data. The Installation, files, and projects chapter explains supported import and sequence patterns and how to open saved projects.

Manual directory

- Quick start
- Installation, files, and projects
- Workspace
- Processing
- Single-experiment fitting
- Multiple-experiment fitting
- Results and advanced analyses
- Figures and export
- Tools
- Settings and defaults
- Glossary and equations

The manual uses these callouts:

NOTE
A detail that affects how the application behaves.

CAUTION
A condition that can produce a failed task, invalid result, or misleading output.

INTERPRETATION
Guidance for judging output. It is not an automated conclusion made by the application.

RECOMMENDATION
A defensible working practice rather than a software requirement.

PLATFORM-NOTE
A genuine operating-system or interface difference that changes how a task is completed.

DEVELOPER
Implementation detail, usually in FT-ITC Analysis's scripting or plugin system.

Interface labels appear in **bold**. A path such as **File > New Se…** means choose the item and then the command. The names of views and dialogs are also bolded. Keyboard shortcuts are written as they appear in the menus, for example Ctrl+O on Windows and Linux and ⌘O on macOS.

Help and support

Help and Guide opens an in-app manual, and **Technical Details** opens the in-app processing and scientific notes. **Release notes** lists current issues and recent changes. **Support** opens the support-routing or reporting dialog. **Contact Support…** helps you collect support by email or GitHub Issues. **Report a Bug…** opens a GitHub Issue form. **Feature Request…** opens the GitHub activity, and if applicable the **Log Support Request** shows the report and the clipboard. Other links include the FT-ITC Analysis website, latest release, project viewer, and software DOI 10.5281/zenodo.19835371.

CHAPTER 02

Quick start

Open your own ITC dataset, process it, fit a one-set-of-sites model, review the result, and save the project, and export a figure.

Last updated: 2026-05-13

This procedure takes a compatible file or project and uses all-sites analysis. Use a dataset for which that model is scientifically plausible. The goal is to learn the application interface, not to prescribe the correct model for every interaction.

The overall analysis workflow. Integrated heat data can skip thermogram processing.

Before you begin

Have one of these inputs available:

- A raw thermogram from a NanoITC-style file (`.itc`), where the instruments NanoITC file importer is available. [Chapter 3: Installation, files, and projects]
- An Origin-style file (`.dat`). When a recognized ITC workbook presents the original temperature trace, FT-ITC Analysis restores it for processing; otherwise, it uses the workbook as integrated heat data.
- Injection-level integrated heats (`.dat`, `.csv`, `.txt`, or `.xlsx`).
- An FT-ITC project (`.ftitc`).

Supported formats and project behavior are described in Installation, files, and projects.

NOTE
Integrated heat files and Origin projects without an original thermogram have only baseline-corrected and peak-integration layers and experiment-level fitting.

1. Open your data

Launch FT-ITC Analysis and choose **Open File…** on the welcome screen, choose **File > Open…** on any supported file from the application window. Select your file and confirm the open procedure.

The experiment appears in the data list. Select it and open **Overview** to orient yourself in the imported experiment. Drag any non-button area of a data or result row to change its position. This is the order used when multiple experiments are selected and shown in the plots in saved as `.ftitc`.

2. Edit experiment details

Open **Details…** for the selected experiment. Concentration entries and the experiment datasheet can be edited later if corrected. Confirmed and effective values for temperature and cell volume are entered in either. A change date is saved in an open modified in the experiment list.

Apply corrections only when you have documented experimental basis. Concentration entries influence the calculated concentrations and later fitted parameters.

3. Process a raw thermogram

If the import contains a thermogram, open **Process Data**.

1. If the trace shows a smooth global shift, try **Polynomial** baseline. For more complicated baseline shapes, choose **Spline**. For local baseline behavior, choose **Segmented**. Keep the default integration settings initially.
2. Click **Auto-Assign Regions** to detect the signal between injections rather than the peaks.
3. Inspect the start and end of every integration region. A good region includes the full peak response without extending unnecessarily into baseline noise. Zoom in a peak and adjust the boundaries and spans. Use **Zoom to Data** to restore the full view. Switch to the next injection with **Next** and **Prev** or the keyboard.
4. Choose **Run Fit**.

Create analysis result determines whether a usable fit also creates a separate Analysis Result. Leave it selected for a first pass. Clear it when you want to review the integrated heats before creating analyses saved in the Experiment Data.

If the fit fails or reaches a limit, the possible causes are described under Fit availability and non-convergence.

4. Review the result

Inspect the fitted curve together with the residuals. When **Create analysis result** is available, select the resulting **Analysis Result** and check:

- the included experiment and injections;
- fitted parameter values and units;
- convergence and fit text;
- whether weighting and uncertainty estimation match your intention;
- parameter uncertainty or confidence intervals, when calculated;
- result tables.

When **Create analysis result** is disabled, the fitted analysis remains available in **Analysis Data** rather than as a stored Analysis Result.

INTERPRETATION
Convergence does not establish model validity. Look for structured residuals, sensitivity to initial values, values of limits, excessive parameter correlation, or disagreement with known stoichiometry and experimental design.

5. Save a portable project

Choose **File > Save As…** and save the project as `.ftitc`. The project contains imported data, processing settings, fitted results, and saved analyses. Use it to continue the analysis later.

If autosave is enabled, it supplements normal saving. It is not a replacement for a saved project file.

7. Export a figure

Return to the experiment view and **Final Figure**. Choose the elements you need, such as the thermogram, integrated heats, fitted curve, residuals, confidence band, or parameter information. Review and adjust the labels. Then use the figure export or print commands to save the figure.

Use **Analysis Result Exporter…** when you need numerical result tables rather than a graphic. For the full export workflow, see Figures and export: Figure tabs, layouts, and annotations. [Chapter 9: Figures and export: Figure tabs, layouts, and annotations]

The figure and table workflows continue in Figures and export.

CHAPTER 03

Installation, files, and projects

Install FT-ITC Analysis, open supported data, save portable projects, and use autosave or recovery safely.

Last updated: 2026-05-13

Install the application

Use the latest FT-ITC Analysis release for current packages and release notes. Verify the file for the platform before release page before installing or opening a portable system security prompt. Package options may change between releases. For installation help, contact: support@ft-itc.org.

macOS

Open the DMG, drag **FT-ITC Analysis** to **Applications**, and eject the disk image. If macOS blocks a verified download, review it in **System Settings > Privacy & Security** and click **Open Anyway** only after confirming its source.

Windows

Run the installer Windows x64 (`.exe`) installer and follow the setup prompts. The installer requires Windows 10 (build 1809 or newer) or Windows 11. Administrator privileges are not required.

Linux

Install the supplied `.deb` package matching the system architecture (AMD64 or ARM64), when available, or a compatible Debian-based distribution. Package trust and dependency behavior depend on the channel through which the package was obtained. Review the current release notes for known platform limitations.

PLATFORM-NOTE
Package installation and file-association prompts are controlled by the operating system. The application behavior is the same after installation. See manual notes for the few interface items that differ between desktop editions.

Supported input formats

EXTENSION	SOURCE	IMPORTED CONTENT
`.itc`	NanoITC or similar raw data	Raw thermogram and injections
`.itc`	TA instruments NanoITC native file	Raw thermogram and injections
`.itc`	TA instruments/Microcal/Malvern Origin ITC	Raw thermogram and injections
`.dat`	Origin ITC project	Raw thermogram and injections from the first experiment
`.dat`	Origin project file	Raw thermogram and integrated heats, according to the recognized workbook
`.dat`	Integrated-heats table	Integrated heats and injections
`.csv`	Integrated-heats table	Integrated heats and injections
`.txt`	Fixed-layout integrated-heats table	Integrated heats, injections, and experiment metadata
`.xlsx`	Supported ITC workbook	Workbook-specific data
`.ftitc`	Legacy FT-ITC project	Readable for migration, but written by current versions

NanoAnalyze (`.ita`) files are not thermogram or integrated-heats files. Export the underlying raw data and use the instrument's supported import path.

If a MicroCal `.itc` file contains multiple concatenated runs, FT-ITC Analysis asks how to interpret the file. Choose **Import as one experiment** for a single titration, or **Import as multiple experiments** to create one experiment per run. See **Batch-Mode Thermogram Concatenation** for details on missing injections, and whether overflow was removed. The expected shape for this instrument's integrated-heats workbook is described in Installation, files, and projects: Supported import formats. For the isolation concentrations and titrant syringe concentrations.

Philos FIT (`.pft`) projects contain a raw thermogram as well as injection and analysis information. FT-ITC Analysis imports the raw thermogram and injection information and recalculates the integrated heats. Integrated heats, processing choices, and fitted results produced by Philos are not imported. [Chapter 3: Installation, files, and projects: Supported import formats]

Native NanoITC (`.itcx`) projects require the raw thermogram, injection schedule, concentrations, and cell volume. Integrated heats, processing choices, and fitted results produced by NanoAnalyze are not imported. [Chapter 3: Installation, files, and projects: Supported import formats]

Origin (`.dat`) files are general-purpose containers. Integrated heats. If the file contains a recognized raw thermogram workbook, FT-ITC Analysis restores the raw thermogram and injection times. If no raw trace is available, it is imported as an unprocessed thermogram and a authoritative start of the worksheet also contains integrated heats. If no usable trace is present, the file is imported as integrated heats. Origin projects (`.opju`) are not supported directly. Export the relevant worksheet to `.dat` or `.csv` and import that file instead. Origin graphs, layouts, and FitSER columns are not imported as raw data.

Delimited (`.dat`, `.csv`, `.txt`) layouts must provide injection, injection volume, and at least one of integrated heat or raw thermogram. Recognized column names include `Injection`, `Volume`, `Heat`, and `Temperature`. If a header is unavailable, it assumes a complete, ASC column set normalized heat per mole. ASC may be absent for the automatically indicated injection. The separator, `.txt` format uses tab separation and does not interpret space within the delimited column layout (`.dat`, `.csv`, and `.txt`) files.

The first injection is treated as test-excluded from fitting by default because its heat is commonly unreliable. You can include it manually if appropriate. For fixed-volume injections, the first injection's volume is commonly half the nominal volume.

These files do not encode an unambiguous heat unit. For ΔC, select the absolute energy unit used by that vendor. For ΔC (**ΔC** based fixed), select the energy unit in the per-mole values for the instrument. Choose the correct unit before importing. Incorrect unit selection changes the apparent binding enthalpy by a factor of 1000. If in doubt, compare the imported integrated heats to a known literature value. [Chapter 3: Installation, files, and projects: Supported import formats]

For `.dat` and `.csv`, **Recalculate concentrations and volume** uses the injection volumes and syringe concentrations to calculate the corresponding thermogram. Disable it when the imported values are already correct. Enable it for corrupted or incomplete thermograms, but your choice applies only to the current import. [Chapter 3: Installation, files, and projects: Supported import formats]

When the application asks about concentrations, it is asking whether to use the values stored in the data file or the values you entered in the concentrations after the last injection. Or start with the values in the file. Choose the values you have verified or corrected for your experiment. Choose the values you recently documented. Or read and transcribe values from your laboratory notebook. Choose the values you have carefully checked. Choose the values you have corrected in the application. Choose the values you have entered or processing internal concentrations.

Open files

Choose **File > Open…**, use the welcome screen action, or drag files into the application. Multiple supported files can be opened together. The opened file is considered document are added to the current project. Choose **File > Open Recent** to reopen a recent project or file. Missing files are left in the list but are not loaded as a result.

CAUTION
After an `.ftitc` project is opened to an existing document, that opened project becomes the document's current save destination. See **Save As…** before saving if you do not intend to replace it with the combined document.

CAUTION
Assembling can create similarly named experiments or results. Confirm the data list and details before fitting or exporting.

Save projects

Choose **File > Save** to update the current named project, or **File > Save As…** to choose a new name or location. See the current `.ftitc` format for ongoing work.

An `.ftitc` project preserves the data and selections needed to continue analysis, including imported experiments, edited details, processing settings, fitted results, saved analyses, selected result tables, processing state, fit settings, Analysis Results, and customized plot and figure analyses. The package is portable and does not depend on the original raw file path for ordinary reopening.

Save Selected, a new selected project (with the name you enter) is created. Selected runs in the current project are moved to the new project. Unselected runs remain in the current project. Experiments auto-sort into the selected project with any solution. Saving the selected Analysis Results saves the result along with the involved experiments.

RECOMMENDATION

Save a proposed version of the project before fitting it if you want a reversible starting point. Use **Save Selected** to split off a subset of runs into a new project to preserve the pre-processed data version—or clean the fitted solutions and Analysis Results.

Autosave and recovery

Autosave runs in the background **Preferences**. If the recovery data is available after an interrupted session, the application offers a recovery path. Open the recovered document, inspect the data for plausibility, and then save it as a normal `.FitAll` project.

Recovery mode is designed to salvage work when components crash unstable. If an experiment causes a crash, the application may start in recovery mode on the next launch. Recovery mode disables all plug-ins and starts with a deliberately different set of internal settings. Fundamentally, this, and results can still be recovered. When recovery was required, the application displays a warning. Investigate the cause before you continue working normally. Typical causes are damaged or incompatible third-party plug-ins. Switch to normal mode and use **Save As...** rather than assuming the damaged or interrupted file was replaced in place.

CAUTION

Autosave cannot guarantee that every updated result or saved analysis survived. Confirm experiment counts, processing, fits, and result states before continuing.

Remove and clear content

Removing an experiment or Analysis Result changes only the open document. It does not delete the original raw file. **Remove All Data/Results** clears the current document after confirmation. **Clear Processing/Results** removes all Analysis Results from the open document.

Saving after removal makes the removal part of the saved project. Use **Save As...** first if you want to preserve the original project version.

Privacy and online checks

Processing, fitting, saving, recovery, export, and printing run locally. Optional automated interpretation in **Analysis Report** sends the selected report evidence, questions, and context to an online service you configure. See Analysis Report for details.

Check for updates and online resources at launch is enabled. The application checks for updates and may open online resources. Disable it in **Preferences** if you want to avoid network launch-time checks. It does not control automated interpretation requests. A failed or disabled check does not prevent local processing, fitting, or saving.

Update safely

Before installing a new application version, save important projects and retain the current installer when reproducibility policy requires it. After updating, open a copy of a representative project, confirm processing and results, and save only when you intend the project to be written by the new version.

Online data flow and retention

Automated interpretation (Analysis Report) sends the selected report evidence and your question or context to OTTO's online interpretation service as input for its use. The service uses this input to generate the interpretation you request. It may process the input to operate, secure, and troubleshoot the service. Do not send passwords, API keys, proprietary confidential data, or regulated data. Supporting experiments are included when selected. Compressed Markdown/ZIP files are limited to 10 MB. Interpretation requests are limited to 10 per hour. Interpretation is not a substitute for expert review of your data and experimental design. Review the service data retention and availability and account access without seeking evidence. A supplied access code is sent to verify access.

Project Viewer (Opening a project in the browser-based Project Viewer uploads the complete `.FitAll` file to the configured viewer service for temporary viewing. The file is deleted after the viewer session ends or after the automatic expiration interval or send it to Support. The viewer has a 50 MB upload limit. Closing the viewer does not end an operator or guarantee that temporary server-side copies are removed. Do not upload files that have been edited since the last local save without a fresh save.

Retention. OTTO's interpretation service stores usage metadata that can be linked to requests or accounts, and temporary work. These records are retained for operation, security, and troubleshooting. Do not upload confidential or unauthorized information. There is no in-app control to delete service records. Contact your service administrator or support if you need data removed. Local files are not affected. Access to Opened is subject to the applicable data controls and retention policies. See Optional Data controls. No new retention or flood deletion guarantee is made for the complete service flow.

CHAPTER 02

Workspace

The application window, Experiment Data capabilities, and Analysis Result capabilities.

Last verified: 2026-05-12

Application window

The **Data Results** tree is the browser analysis. It contains two types of project-level Experiment Data and completed Analysis Results. Selecting an item shows it in the workspace; selection does not change whether an experiment is active.

Experiment Data can be **Active** or **Active** but experiments participate in operations that use Active Experiment Data. Active Experiment Data is the default for processing, fitting, and Analysis Report. The toggle becomes available after the experiment has been processed. **Enable All**, **Disable All**, and **Invert Active** change several experiments. The **Batch** commands under the list to **Process**, **Fit**, **Report**, or **Export** the Active Experiment Data. Batch Processing and Batch Fitting is described in Multiple experiment fitting, and the processing prerequisite is covered in Processing.

The rest of the window follows the selected item and task:

- The workflow navigator switches between the available stages of an experiment.
- The workspace contains the graphs, tables, and controls for the current task.
- Workflow controls provide options for the view or analysis currently open.
- Item actions apply to the selected Experiment Data or Analysis Result.
- The application menu contains project commands, tools, preferences, and help.

Experiment Data

Selecting Experiment Data opens its workspace navigator in the Data workspace.

Experiment Data represents an experiment's application-created dataset. Its list entry provides identifying information and a summary of its processing or fitted data.

Experiment workflow

Four task views are available for Experiment Data:

- **Overview** presents the important data and available experiment information.
- **Processing** configures the Processing Program into integrated mode-focused processing and displays data and parameters.
- **Analysis Data** configures and runs single- or multiple-experiment fitting.
- **Final Figure** presents the thumbnails, magnified results, fit, residuals, and annotations for presentation.

Details and attributes

The **Details...** view contains software, instrument, acquisition, and experiment attributes. The **Attributes** dialog edits the attributes that can be changed. Use it to add or remove attributes, categories, conditions, concentrations, and comments. Attributes control experiment selection. Attributes describe conditions and analysis inputs such as buffer, salt, ionic strength, competitors, or measured species.

PLATFORM NOTE (WINDOWS)

Edit the data set time using separate cells containing, including seconds. Use **Add Attribute** on the Attributes tab to add a new. Each tab avoids independently, while **Cancel** and **Apply** remain visible at the footer. Cancel discards edits; Apply commits them.

Copy Attributes to All copies all attributes from the selected experiment to every other experiment in the project. **Copy Attributes to Selected** copies them to the selected **Other experiments**. **Active experiments**, or **Specific experiments**. In **Experiment names containing...**, The name option targets every other experiment whose name contains the entered text, without regard to capitalization. **Clear Attributes** removes all attributes from the selected experiments in the confirmation.

Experiment Data actions

- **Details...** opens the editable experiment information and attributes.
- **Rename...** changes the experiment name shown in the Experiment Data.
- **Export Selected Data...** exports the selected dataset.
- **Clear Solution** removes the fitted solution currently attached to the Experiment Data.
- **Restore Data** removes the fitted from the open project without deleting its source file.

Analysis Result

An Analysis Result stores a fit for one or more experiments together with its model, constraints, fitting settings, uncertainty output, and residuals. Selecting it in the tree summarizes the result fit.

Result workspace

The result workspace provides these views:

- **Summary** presents fitted and derived parameters across the result and provides for member table.
- **Fit** shows the stored fitted curve and residuals for a selected member experiment.
- **Correlation** shows correlations and uncertainties from result bootstrap refits when bootstrap analysis was enabled.
- **Temperature, Salt**, and **Fundamental** appear when the result and its experiments support those analyses.

The inspector organizes result information under **Summary**, **Analysis**, **Experiments**, and **Model**. See Results and advanced analysis for interpretation and prerequisites.

Analysis Result actions

Changes to the fit-related state of Experiment Data stored in an Analysis Result can invalidate the result. The validity indicator shows whether the stored result still matches the current data.

- **Details...** edits the result name and comments.
- **Copy Fit Results** copies the current result to the **Analysis Result Exporter**, a workflow for exporting fit results.
- **Update Result** recalculates the stored model and fitting settings using the current member experiments and replaces the result only after a successful refit. If a refit fails or is cancelled, the update dialog keeps the stored bootstrap count by default and offers larger bootstrap counts for the retry. Use **Cancel** to close the dialog with the result, the stored parameter limits and other fitting settings remain unchanged.
- **Set Active Experiments** makes the result's member experiments active.
- **Select Experiments** selects experiments whose the current member solution is the one currently stored in the result.
- **Export Associated Final Figures...** exports figures for the member experiments.
- **Remove Result** removes the Analysis Result from the open project.

Separate tools

The **Tools** menu opens separate windows for tasks outside the main experiment and result workflows. These include **Experiment Designer...**, **Buffer Substances...**, and **Experiment Merge...**. See Tools and Experiment Merge.

CHAPTER 03

Processing

Baseline models, integration regions, injection uncertainty, and processing propagation and locking.

Last verified: 2026-05-12

The **Process Data** workspace extracts and calculates a baseline from the difference-power trace. Integrate the corrected response for each injection, and estimate and propagate the resulting heat. Polynomial and Segmented baseline provide repeatable, model-based treatment. Use Manual when you need to place the baseline yourself. Use **Exclude integration regions** to exclude selected ranges for difficult cases, while graphical boundaries and the **Baseline** dialog balance between User-Controls an immediate integration region adjustment.

These controls make processing efficient without identifying the scientific interpretation for you. Confirm that the chosen baseline represents the signal between injections and that each integration region includes the complete peak.

Use `Ctrl+1`, `Ctrl+2`, `Ctrl+3`, and `Ctrl+4` shortcuts use the workflow, as the Origin `Ctrl` Home that is available in the Process. Integrated heat chapters and Origin presets without a custom Process Data.

The integral is evaluated between the integration region boundaries. Each denoted power value represents the baseline-corrected energy exchange in a thermodynamic, not Focused Source of Origin. Integrated heat chapters and Origin presets without a custom Process Data. Use Process Data workspace. Use Process Data workspace. Use Process Data workspace

Analyze Data > **Single experiment** reads the fingerprint traces of the selected Experiment table. Then the user chooses the analysis method with the experiment concentrations, injection volumes, cell volume, temperature, and any model-specific information.

The inspector has two tabs:

- **Fit** selects the model, optimizer, error-estimation method, limits, weighting, and result output.
- **Parameters** shows the model parameters and their starting or fixed values.
- **Options** contains settings specific to the selected model.
- **Display** controls the fingerprint and diagnostic information shown in the graph.

Profile-likelihood uncertainty

Profile likelihood estimates confidence intervals at a finite 95% confidence level. After a successful optimization, the method varies one fitted parameter at a time, holding it at each trial value while refitting the other free parameters. Both unweighted and weighted fits use a Gaussian likelihood, so the negative log-likelihood is half the sum of squared residuals. Relative to the best value, the method finds the accompanying abnormal peak value where the squared residuals remain unchanged and supply relative injection weights. The overall residual scale used for published confidence intervals is estimated from the best fit, with a minimum of one degree of freedom. Each parameter value examined is saved in the Results table.

Graphs of integrated heats can display an envelope from available lower-error-rate refits, although this is not supported by four-curve refits. Profile-likelihood does not consider a shared error in a combined fit.

Confidence intervals are reported only when the threshold is crossed on both sides of the tested fit range. If a bound is encountered before the limit, that side is marked as not-reached and no confidence endpoint. For a complete interval, the displayed `value ± SE` uses a symmetric approximation. Asymmetric intervals show the lower and upper endpoints and their distances from the result. Use `Results[name]` to access the profile diagnostics.

Profile-likelihood confidence limits check how well the data constrain each fitted parameter.

Multiple-experiment fitting uses additional experiment selection and parameter constraints; see Multiple-experiment fitting.

Injection inclusion

Selecting an injection point in the integration trace graph changes whether it is included in the fit. Excluded points appear as open circles; included points appear as filled circles.

Display controls the fingerprint and diagnostic information shown in the graph.

Excluded injections remain visible and their positions are available when you want to reconsider them.

Changing injection inclusion does not recalculate the fit. The Final Value and parameters continue to represent the previous fit until **Run Fit** is used again. An inclusion change can also invalidate an Analysis Result that contains the experiment.

Injection bookkeeping: MicroCal, Ideal continuous mixing, and Discrete displacement

Injection bookkeeping determines the concentrations used by the fit and accounts for reaction heat lost to injection volume displacement. It is set in the **Fit** tab of the Analyze Data inspector or scripted integration.

- **MicroCal** (default) uses the pre-simulated displacement volume mass balance for concentrations and the matching evaporation displacement correction.
- **Ideal continuous mixing** uses the analytical ideal exponential mixing and accounts for displacement heat using the continuous mixing model. The apparent heat of each concentration term previously required at the Experiment preference, but its heat calculation is different. This is the concentration-only labelled Stories in the Fit tab.
- **Discrete displacement** uses discrete successive bookkeeping. For instance a fraction of the cell contents is displaced by each injection, and the cell is then refilled with a mixture of the injectant and the cell contents. This is also called Discrete Displacement in the Fit tab. Unlike the continuous mixing model, it is not equivalent to zero.

For **MicroCal**, let c_0 be cumulative titrant volume after injection i, V_0 be the initial cell concentration, and V_c the syringe concentration. Starting with no ligand in the cell:

$$\begin{aligned} x_0 &= x_0 = x_0 = 0 \\ x_i &= x_i(x_0) = x_i(0) \end{aligned}$$

Every delivered injection contributes its cumulative volume, including injections excluded from the fit. The cell volume V_c is the Experiment preference **Cell Volume**. The syringe volume V_s is the Experiment preference **Syringe Volume**. The dilution factor d_i is the fraction of the cell solution remaining after injection i. Excluded injections still contribute to displacement.

Discrete displacement uses the same cumulative volume c_0 and the same dilution factor d_i as MicroCal. For injection i, the cumulative titrant volume is $c_i = c_{i-1} + v_i$, and the dilution factor is $d_i = 1 - v_i/V_c$. The initial concentrations are $x_0 = V_0$ and $y_0 = 0$. Each injection mixes the cell contents with the injectant, so the concentrations after injection i are:

$$\begin{aligned} x_i &= x_{i-1} d_i \\ y_i &= y_{i-1} d_i + V_c (1 - d_i) \end{aligned}$$

For **Discrete displacement**, concentrations advance as $x_{i+1} = x_i - x_i(1 - d_{i+1})$ and $y_{i+1} = y_i - y_i(1 - d_{i+1}) + V_c(1 - d_{i+1})$. Because the same dilution factor appears, the observed heat is proportional to $x_i - x_{i+1}$ and $y_i - y_{i+1}$ at equivalent cumulative volumes. Every shot must be smaller than the cell volume, $v_i < V_c$. Discrete displacement is the default for new Experiments.

For **Ideal continuous mixing**, let $\Delta c_i = c_i - c_{i-1}$ be the injected volume, $\Delta x_i = x_{i-1} - x_i$ be the displaced titrant, and $\Delta y_i = y_{i-1} - y_i$ be the displaced macromolecule. The displaced titrant is removed from the cell, so Δx_i is the amount of titrant that reacts. The displaced macromolecule remains in the cell, so Δy_i is the amount of macromolecule that reacts. Ideal continuous mixing is a continuous-flow model, so the displacement heat is zero and the concentrations are:

$$\begin{aligned} \text{MicroCal and Discrete displacement} &= \text{Ideal continuous mixing} + \text{Displacement heat} \\ \text{Discrete displacement} &= \text{Ideal continuous mixing} + \text{Displacement heat} \end{aligned}$$

Preferences > Processing > Injection bookkeeping selects the default for new data. **Experiment Editor > Injection bookkeeping** overrides the default for one Experiment, and Analyze Data > Fit > Injection bookkeeping overrides it for the current integration trace. Changing the preference or editing an Experiment does not change existing Analysis Results. Changing the preference or editing an Experiment does not change existing Analysis Results. Changing the preference or editing an Experiment does not change existing Analysis Results

With **Create analysis result** disabled, a successful single-experiment evaluation remains attached to its parent User and is published to the current Project's results list. Nothing else changes.

With **Create analysis result** enabled, a usable single-experiment evaluation remains attached to its parent User and is published to the current Project's results list. Nothing else changes.

Fit availability and non-convergence

A single-experiment analysis requires a converged Hessian-based fit and at least three included concentrations. Otherwise, the analysis is unavailable. Two included concentrations are not enough for concentration dependence. **Dissociation** uses the average concentration and does not require a macromolecule concentration in the titrant's buffered salt.

An unavailable model, failed Hessian inversion, bounds-limited solution, or failed inverse-propagation can reflect missing or degenerate heat and concentration information, the supplied starting parameters, or the model's fit to the data. Check the concentration range, the number of points, and the fitted parameters. Reevaluating can fail when the process for successful because each refit presents a different or reduced dataset to the same model.

ANALYSIS 3/3

Multiple-experiment fitting

Multi-dataset fitting across processed Active experiments, including constraints, shared options, diagnostics, and combined results.

Last edited: 2026-05-02

Multiple experiments in the Multi-dataset mode's **Analysis Data** 1 represents at least two Active experiments. Each experiment's heat and concentration data are processed separately in **Results**. What is shared is controlled by **Fits**. For members and fitted independently. When set to shared, experiment constants are active. The solver performs one concentration integration, one Hessian inversion, and one set of standard errors. The result, with member-specific parameters in the **Individual** view, is **Fits**.

The model and model options apply across the active set. The resulting **Analysis Result** retains the member IDs, and shared or independent parameter dependent uncertainties, covariance, diagnostics, and uncertainty output. Shared fitting controls are described in Single-experiment fitting.

Fit

The **Fit** tab identifies the **Mode** as **Multiple experiments** and exposes the shared **Model** selection. The model controls shared **Algorithm**, **Grid**, **Bootstrap**, **Limits**, **Weight by injection error**, **Concentration uncertainty**, and **Global parameters**. The available **Algorithm** values are **Levenberg-Marquardt** and **Trust-region reflective**. **Grid** is available only for **Single-site**. **Bootstrap** replicates, and **Limits** and **Profile likelihood** fit all globals. Nonlinear models, such as **Linear** and **Sequential**, are unavailable with shared experiment, profile likelihood uses the complete dataset. **Weight by injection error** and **Concentration uncertainty** are available when the selected model supports dependent uncertainty, concentration propagation, and propagating error. A disabled because they do not participate in skeleton or profile calculations.

The **Result** controls describe whether a completed fit is stored as an **Analysis Result** and whether that result appears automatically. **Run Fit** and **Stop** are the fit controls. The status area reports the current fitting state, including **Ready**, **Running**, **Stopped**, **Complete**, or **Failed**. A disabled experiment evaluation is ready only when every member has active processed data and the variables or base model is

A shared-binding workbench contains the three-mode experiments in one project.

Parameters

The **Parameters** tab controls the shared parameters and, in multiple-experiment mode, the **Individual** parameter view. The **Parameters** table lists **Name**, **Value**, **Min**, **Max**, **Fit**, **Shared**, **Error**, and **Uncertainty**. The parameter list can be filtered by **Search parameters**.

Global constraints define how those parameters are related across experiments.

STATE	MEANING
None	The parameter remains member-specific. Each experiment has its own fitted value.
Same for all	The common value is fitted for every member in the set.
Temperature-dependent	A supported parameter is represented across the temperature series by the relationship selected in **Temperature**.
Thermodynamically linked	Affinity, binding, and, or the fixed-H reference and shared-dH terms for the selected binding stoichiometry, including dG when present.

Shared parameters are fitted once and reported as a single value during fitting. **Locked** is not a shared state and is a member constraint for the selected experiment. In the **Individual** view, global values and a member override for each shared row are shown.

For the cross-binding parameters, the available relationship state for each row and state-dependent

PARAMETER	AVAILABLE STATES
dH/mole	**Independent**, **Shared dH**, **Thermodynamically linked**
Enthalpy	**None** or **Same for all**. **Temperature-dependent** is also available when the selected set exposes temperature dependence.
K-value	**None** or **Same for all**
Offset	**None** or **Same for all**

The interface lacks a proportional claim for this profile. **independent** for each

$$\Delta H(T) = \Delta H_{ref} + \Delta C_p (T - T_{ref})$$

$$\ln K(T) = \frac{\Delta H_{ref}}{R}\left(\frac{1}{T_{ref}} - \frac{1}{T}\right) + \frac{\Delta C_p}{R}\left(\ln\frac{T_{ref}}{T} + \frac{T_{ref}}{T} - 1\right)$$

ΔH_{ref} is the enthalpy at the reference temperature, T_{ref}. Single-site experiment represents ΔC_p is the heat capacity change, R is the gas constant, and T is the absolute temperature. K is derived from the reporting temperature-dependent parameters. A member's heat-capacity parameter is unavailable when the selected model does not support temperature dependence. The interface temperature.

For Independent enthalpies, the initial relationship gives every experiment equal weight, including repeated temperatures and future enthalpies. Attaching profile results leaves the original fixed-H reference and shared-dH terms unchanged. Thermodynamic linkage is available only when the relationship is reversible through the enthalpy trend. Restored thermodynamic terms are an approximate propagation of the fitted covariance and omit linear parameter covariance. Nonlinear and linear-and-nonlinear models are unavailable for thermodynamic linkage.



Global constraints define relationships between member parameters. Locked exports fixes a separate value.

Options

The **Options** tab contains the options exported to the selected model. In multiple-experiment mode, the shared model options are edited here. The available controls depend on the model. They include model-specific concentrations, stoichiometry, syringe concentration, or optional-component settings when those options are exposed. The option values are preserved with the combined Analysis Result.

An option that changes which parameters are exposed can also change the available parameter rows. Review the **Parameters** tab after changing model options. Shared options apply to every member, which fit values are independently represented. The available rows always describe the active model and option combination.

Display

The **Display** tab controls the graph presentation for the active member set. Its controls cover the data, fit, and residuals. The **Data** controls include **Show data** and **Show error bars**. The **Fit** controls include **Show fit** and **Show residuals**. The **Residuals** control has the same choices. The **Residuals** control has the same choices.

Display settings affect the graph presentation, not the model, the member data, or the fitted values. The graph can therefore show the current member fits or connected global fit alongside the same residual options. The Parameters tab remains the source of the shared parameter and constraint values.

Combined Analysis Result

The combined **Analysis Result** contains the exact member experiments, the shared model and options, member parameters, any shared or independent dependent parameters, and the covariance and diagnostics from the connected fit. Its **Individual** view shows one member at a time. Its shared state can represent both global and member-specific values. A selected member returns its own fitted curve and residual information even when a parameter is common across the set.

The status and diagnostics distinguish a successful model-wide fit from failure, or the uncertainty of the fit. RMSD, fitted count, weighting, and estimation method, and the number of parameters and observations. Use the **Individual** view to inspect each member's fit and residuals. A shared parameter's uncertainty is reported once. Dependent parameters can be unavailable when a member-level information rather than being hidden by a combined view. Result interpretation and validity are covered in Results and advanced analyses.

ANALYSIS 3/3

Results and advanced analyses

Analysis Result views, validity, uncertainty presentation, evaluation temperature, and conditional advanced analyses.

Last verified: 2026-05-02

An **Analysis Result** is stored to be read in several components. It contains the model and options, fitted parameters, uncertainty, diagnostics, and the experiment data that the calculation was fitted or imported. The result workspace presents those stored values together with graph and parameter views. The fitting controls are described in Single-experiment fitting, and multi-dataset constraints are described in Multiple-experiment fitting.

Result views

The result view selector contains **Fit**, **Correlations**, and **Summary** for every Analysis Result. Thermodynamic-linkage results add **Temperature** and **Temperature-dependent**. Multiple-experiment results add **Individual**. Switching views changes the displayed graph, parameter table, and diagnostic content. It does not recalculate the result.

Summary presents the combined parameter graph and result table. The table can show fitted, derived, and dependent values. The selected uncertainty representation for each value is shown.

Columns initially size to their headers and displayed values within compact limits, drag a header edge to resize a column. Double-click a header edge to restore the automatic width. The horizontal scrollbar, while space is assigned in the Experiment column. Wide energy columns remain visible. The vertical scrollbar, while rows are scrollable. Sorting and resizing are view-only. They do not change the stored result.

Selecting a row makes that member the current result selection for selection is retained by the Experiment identifier. Switching to **Individual** then shows that member's fit. Selecting rows between analysis results, the comparison is based on the shared parameter values. Member-only columns and member with the same experiment ID. Use **Preferences** > **General** > **Energy units** to choose joules or calories.

Advanced analyses can operate the stored data and uncertainty summaries from profile likelihood, Monte Carlo, or bootstrap calculations. They can also add derived thermodynamic quantities. Some these are not safe can provide an envelope or the Hessian-based result.

Fit presents the saved fitted curve, residuals, error bars, confidence band, and excluded points for the selected member. The graph is read-only. It represents the stored calculation rather than recalculating from the current model or options. Use the Fit tab to change and refit the data.

Correlation presents a matrix calculated from residual bootstrap refits. Its availability, scope, and interpretation are described under Bootstrap correlation.

Inspector tabs

The result inspector has the tabs **Summary**, **Data**, **Model**, and **Fit**.

The **Summary** tab contains the result identity, model, member count, RMSD, information criteria, and error diagnostics. The validity section reports **Analysis is valid**, **Partially invalid**, **Invalid**, or **Validity not checked**. Invalid results should not be used for publication or thermodynamic reports. Threshold warning reasons affecting more than two parameters or a dependent parameter. Its category with an affected parameter count, example, or correlation reasons remain available in the stored result. Recalculate validity after changing the fit or reloading the result. Validity is not a substitute for uncertainty with excessive parameter burdens, or unidentifiable fits. Use optimize limits, these warnings remain visible alongside diagnostics. Validity is stored with the result. Recalculating validity updates the displayed report. It does not refit the data, change the method, and parameters.

In the browser saved, RMSD is shown as a saved unweighted display diagnostic (μcal/s). Open the result to recalculate diagnostics. When the saved comparison has no weighted RMSD, **Weighted RMSD** is shown separately. The result summary uses the saved global metric, while an individual member's fit is open. Use the **Fit** tab to inspect the current member's residuals. Weighted RMSD values are not exchanged to normalize the result metric.

Information criteria

The **Information criteria** section reports the analysis result AIC when it is available, otherwise AIC, together with the included observation count n and likelihood parameter count K. Lower values indicate a better balance between fit quality and model complexity. AIC is calculated as $n \ln(\text{RSS}/n) + 2K$. n is the number of fitted parameters. Weighted criteria use the weighted residual sum of squares for relative uncertainties and estimates one common variance likelihood from the standardized residuals. Unweighted criteria use the ordinary residual sum of squares. AICc adds $2K(K+1)/(n-K-1)$ to the likelihood.

When members were fitted independently, the result table also includes an **AIC** column. It reports each member's own AIC and is intended for comparing alternative models fitted to the same experiment. observations, response definition, and weighting mode. Values in different experiments are not comparable. Use the same experiment data for model comparison. Use the same weighting mode for all models. Use the same response definition. Use the same observations. Do not mix results that the member likelihood could not be evaluated. Shared-parameter global fits expose one combined result criterion and omit this section. Inspect the **Fit** tab for unweighted member diagnostics.

The criteria are the overall result's included baselines and response definition. All analysis result observations, including unfitted points and the common variance across all members, weighted criteria use the combined weighted residuals. Unweighted criteria use the combined residuals. Member's own criterion estimates its variance separately. Compare models only when the recorded AIC's is a sum of the member values.

With residuals r_{ij}, per-residual count of experiments $M(i) \le T$, integration error $\text{SE}_{\text{int},ij}$, and accumulated titrant sum of squares $S = \sum_{ij} r_{ij}^2$, the recommended likelihood term is

$$\text{Weighted, estimated common variance} \quad -2\ln\hat{L} = \sum_{ij}\left[\ln\left(2\pi\hat{\sigma}^2\right) + \frac{r_{ij}^2}{\hat{\sigma}^2}\right]$$

$$\text{Weighted, assumed variance multiplier} \quad -2\ln\hat{L} = N\ln\left(2\pi S/N\right) + N + 2\ln\hat{\sigma}$$

The weighted variance multiplier is $\hat{\sigma}$. With combined uncertainty without setting an optimized variance, the unweighted likelihood uses a fitted parameters. The calculation uses the same injection SDs and the same an experiment fitted for reducing SDs as weighted fitting. Zero residual variance makes the estimated variance likelihood unavailable. Weighted fitting, the unweighted likelihood uses the same parameter and processing SDs as residual weights and apply the same combined uncertainty. Use the same observations and weighting mode when comparing models. Use the same member set and response definition.

The fitted parameter count is the parameter count. Each member's fitted parameters. Shared parameters count once. Fixed parameters are excluded. Dependent parameters are excluded. Use the same parameter definitions when comparing models. Use the same parameter set. Use the same observations. Use the same weighting mode. Use the same response definition. Use the same member set. Use the same baseline and integration options. Use the same titrant concentration. Use the same cell concentration. Use the same syringe concentration. Use the same temperature. Use the same buffer ionization. Use the same dilution correction. Use the same injection volumes. Use the same injection SDs. Use the same processing SDs. Use the same weighting mode. Use the same response definition. Use the same observations. Use the same member set. Use the same parameter definitions. Use the same parameter

Folded mode: adds **Estimate** and **ID Interaction**. Together with **Temp mode** (above), **Isentropic** (above), and **Polytropic** (above), these five modes cover the full range of compressor analysis.

Estimate mode is the most practically useful. Enter the compressor's Stator, Rotary, and Fluid properties, then enter any two of the three thermodynamic variables (Pressure, Temperature, Density) and the relationship. Profile Hive will run propagation approximately and sort fitted coordinate combinations by accuracy. Click any result to populate the remaining variable and immediately see the Mollier Revolution Map update to show the corresponding operating point.

Estimate mode: enter any two of Pressure, Temperature, and Density to estimate the third. Propagate runs the approximation and sorts fitted coordinate combinations by accuracy. Click any result to populate the remaining variable.

ID Interaction mode requires a **Buffer** structure for each member and at least two distinct buffer coordinates. Click two coordinate buttons (**Position** and **Density**, for example) to choose the axes for the analysis. Profile Hive then computes the Pearson correlation coefficient between the two chosen coordinates across all members in the buffer, and displays the result as a scatter plot with a fitted trend line.

ID Interaction mode: choose a Buffer structure and two coordinates to analyze. Pearson r quantifies the correlation strength. A strong correlation (|r| > 0.7) suggests the two coordinates are not independent — one may be largely redundant.

The Pearson correlation coefficient, r, ranges from -1 to $+1$. A value near $+1$ means the two coordinates increase together; near -1 means one increases as the other decreases; near 0 means they are largely independent. Strong correlations ($|r| > 0.7$) suggest that one coordinate may be redundant — it can be derived from the other, and could potentially be dropped from the buffer to reduce dimensionality.

Advanced analysis views are supplemental views of current Analysis Result. Their availability and outputs are determined by the Run On Click mode, member selection, metadata, selected graph or evaluation mode, and any completed uncertainty calculation. Result validity remains a property of the Analysis Result, not of the view. Switching views does not change the result, and the table output is exported in Figures and report.

The buffer viability contains approximations and some unknown quantities, so confirm that the compressor is safe to operate in the equipment. The TOPOS pre-temperature correction is a first approximation for On-Air PC, its uncorrected imbalance is real-time, and enthalpies in transition-heavy regions may be less reliable. Use these effective internal analyses alongside your externally validated pressure-ratio checks and tolerances.

Advanced Topics and Troubleshooting

Figures and export

Configure final and supporting figures, print-active graphs, and export data, results, figures, and complete analysis reports.

Last verified: 2026-04-20

PT-CFD Analysis keeps publication figures, numerical data, and filled result tables as separate, explicit types. **Final Figures** is an Assessment Data workflow. An Analysis Result does not open Final Figures directly. Open Assessment Data, choose **Figures**, and build or export figures for the selected Assessment Data.

Final Figure

The **Final Figure** workspace renders the selected Experiment Data as a publication figure. Its preview and PDF output reflect the selected experiment, processing state, fitted solution, and **Figure Settings**. Use it when you need a print-ready figure rather than a quick **Assessment Plot** or **Figure Export**.

The **Export PDF** controls offer three scopes:

- **Selected** opens a save dialog for the displayed Experiment Figure and supports the experiment name as the PDF filename.
- **Active** exports figures for Active Experiment Data. All exports figures for all Experiment Data in the set.

For **Active** and **All**, choose a parent folder and the app creates or reuses a subfolder named after the saved project file (without its extension). For an unsaved session, it uses the local-save data folder. Each exported figure is written as a PDF named after its experiment. If two figures share a name, the app appends a suffix such as `_Experiment_02.pdf`.

The result list contained **Export Associated Final Figures…** loads the result's member solutions and opens the Final Figure workspace for that Analysis Result. Use this when you want to export publication figures from the same fitted solutions displayed in the Result Viewer.

Member Data Profile Settings are used
Export Associated Final Figures…
Export Associated Final Figures… uses the current Final Figure appearance controls.
Supporting Figures… starts with a snapshot of those controls when its window opens.
Supporting Figures… offers Fit Curve, Residuals, Parameter Uncertainty, Fit Quality, Overlay, Fit Curve with Data, Uncertainty Band, and Residuals with Data.
Each window can choose one Experiment Data and one Solution.
Each window can choose one Experiment Data and one Solution.
Each window can choose one Experiment Data and one Solution

Choose the appropriate output tool

The Analysis Report is distinct from the other output tools:

- **Analysis Result Exporter** is for compact CSV or TSV tables for numerical reuse.
- **Final Figure** makes a publication figure for an experiment, and **Recommended Final Figures…** makes one figure per experiment.
- **Supporting Figure** summarizes all experiments in a multi-panel canvas.
- **Analysis Report** produces a long, self-contained diagnostic artifact, with statistical tables, figures, and explanatory text.

Supporting Figure

Supporting Figure… composes figures from Experiment Data and Analysis Results into a multi-panel canvas. The **Figure order** list defines source order. Add…, **Remove**, Up, and **Down** change the composition. The source order can affect automatic experiment and result figure by name or kind.

Common plot size specifies width and height in centimeters. Grid controls specify columns and rows. **Panel label** controls automatic panel labels. **Label font size** controls the size of the labels. **Letters** uses capital A, B, C, … identifiers. **Panel titles** automatically adds the experiment name after that identifier (for example, **A Experiment name**) and is off by default for multi-panel canvases. **Include figure titles** includes the figure titles in the composition. **Include legends** includes legends in the composition. Remove duplicate legends removes duplicate legends. Font controls the selected system font. Size, 50%, 75%, or 100%. **Export PDF…** writes the composed supporting figure as a PDF.



Supporting Figure arranges the three Analysis Figures from an Analysis Result as a shared multi-panel canvas.

Printing

File > Print prints the active graph or figure through the operating system's print workflow. The active target can be the overview Electrophysiology graph, analysis graph, result graph—including Supporting Figure compositions—or Experiment Designer. Printing uses the current theme, so switch to a light theme before printing to save ink. Printing preserves the available printer and PDF destinations; the graph content comes from the active application view.

BASIC TOOLS

Tools

Design simulated stimulations, subtract buffer controls, and merge standard or back-mixed tandem experiments.

Last verified: 2026-05-20

The **Tools** menu contains **Experiment Designer**, **… Buffer Subtraction**, **… >>> Experiment Merger**, and **… <<< Experiment Merger**. Each tool opens a separate window for a specific workflow. Nothing in this window is destructive until you explicitly apply a change.

Experiment Designer

Experiment Designer… creates a synthetic titration from instrument, concentration, injection, and model parameters. The graph updates as the design changes. The designer does not edit the synthetic experiment or its fit as a project item.

Setup and model parameters

The **Setup** tab contains **Instrument**, **Cell cell**, **Syringe ligand**, injected **Count**, and **Volume uL**. Cell and ligand populate the injection schedule. **Automatic injection schedule** recreates the injection schedule from the selected instrument's standard syringe volume and injection count. **Temperature C** and **Cell volume mL** set the experimental conditions. **Model** selects the binding model. The **Concentrations** section contains **Tandem stoichiometry** and concentration controls with **Segments** setting the number of loads. The designer uses its tandem back-mixing model between loads.

Setup defines the instrument, concentrations, injection schedule, tandem behavior, and simulated noise.

The **Model** row contains **Type**, standard model **Parameters**, and model-specific **Options**. In the **Thermodynamics** section, **Temperature K** and **Cell volume mL** duplicate the setup values. Ligand from **G to L G/L** is the standard dialogue titration mode. **Apply CMC** fits the common micelle data in the designer window and exports the fit as its graph, neither the simulation nor the fit becomes an Analysis Result in Experiment Data only.

Model exposes the synthetic model type and its parameter values.

Buffer Subtraction

BEFORE THE MERGE

Process the reference experiment and every target experiment. Buffer subtraction operates on their integrated injection heats.

Buffer Subtraction… removes reference heats from one processed reference experiment and applies the resulting correction to one or more target experiments. The reference selector shows experiment names and **Processed** or **Not yet processed** status. The target list excludes the selected reference and supports multiple targets. If processed reference is required, its **Processing** tab must be complete.

The **Method** selector contains **Constant** and **Per dilution**.

- **Matched** evaluates the reference heat at each target injection number, using nearby included reference injections when the matching injection is unavailable.
- **Linear** fits a line through valid, included reference injections and evaluates it across target injection numbers.
- **Exp. decay** fits an exponential decay model with optional reference injections.

The **Options** group contains a reference-and-target heats and the selected model plot mode. Reference and included changes the plotted heats to the fitted methods. **Focus Y axis on buffer data** changes only the preview range. If continuous model fits appear, the **Linear** and **Exp. decay** **Matched** is represented by injection-level reference values.

Buffer Subtraction contains the selected reference-target experiment before and after the correction.

$$\Delta q_{i,\mathrm{corrected}} = \Delta q_{i,\mathrm{target}} - \Delta q_{i,\mathrm{reference}}$$

The subscript defines measurements for injection number i. $\Delta q_{i,\mathrm{target}}$ is the target heat, $\Delta q_{i,\mathrm{reference}}$ is the reference value, and $\Delta q_{i,\mathrm{corrected}}$ is the corrected heat used for fitting and export.

Apply stores the reference and method on each target. The corrected heats are then used by Automated fitting and export while the original integrated heats remain unchanged. The **Undo** command restores the previous state. Changes to processing or injection-inclusion settings require reapplying the correction. Reverse to project data will not affect the validity of dependent results.

Experiment Merger

BEFORE THE MERGE

Process each source experiment before merging. The merger uses each source's baseline-corrected integrated heats and its **Processing** tab settings. Unprocessed sources cannot be added to the destination. The newly merged Experiment Data is processed automatically.

Experiment Merger… joins two or more eligible chronological experiments from consecutive segments of a tandem titration. The source list contains the experiments that are not already tandem merges. Add… appends the selected experiment. **Up** and **Down** reorder selected rows.

The **Mode** selector contains:

- **Simple tandem**, which concatenates the segments using the standard concentration progression without a user-selected back-mixing correction.
- **Fixed back-mixing**, which applies one configured mixing fraction at every segment boundary. Enter the fraction as a percentage between 0 and 100 percent or an individual fraction between 0 and 1.
- **Auto back-mixing**, which estimates the mixed mixing fraction from the selected experiments and is available for up to five source experiments.

Back-mixing controls include **Count adj.**, the **Mixing** fraction, and **Remove titrated overflow**. **Count adj.** changes the injection count of the first source experiment. **Mixing** changes the fraction of the previous injection volume that remains in the cell at each segment boundary. In Auto mode, the shared slider supplies the fraction. With three or four experiments selected, enable the individual fraction fields as the **Segment 1 fraction** and, for four experiments, **Segment 2 fraction**. **Remove titrated overflow** removes the excess from the selected data. Keep any model-based estimates rather than discard measurements.

Auto tandem merge applies automatic correction for an optimized tandem experiment set.

Preview updates a new proposed Experiment Data item. Its thermogram samples are drawn, shifted and concatenated. Its injection schedule renumbers segments tandemly, and its segment boundaries mark the calculated starting cell and syringe concentrations. The preview also shows the estimated mixing fraction and the root-mean-square error. Review the preview before you add the experiment. Inconsistent temperature and cell volume values can produce misleading results. Review the source experiments and their concentrations before you merge. Use Undo if the result is not correct.

AUTOMATED FIT

Create appends the preview automatically. Fixed back-mixing fractions in a model-based correction, not a direct measurement of liquid mixing, but a practical tandem model.

Tandem injection-displacement correction

The **Injection backmixing** preference selects **Mixed Cal.**, **Ideal continuous mixing**, or **Discrete displacement** for tandem experiments. Mixed Cal. is the default and matches the Cal. Mixed tandem-mixing model. Existing tandem experiments retain their saved model. Ideal continuous mixing and the tandem test fix change it. Let c_{in} be cumulative titrant volume divided by active cell volume. The reference curve without back-mixing is

$$\begin{aligned} A_{\mathrm{ref}}(c) &= \alpha(0)\,(1-e^{-c}) \\ A_{\mathrm{ref}}(c) &= \alpha_{\mathrm{inf}} + (\alpha_{\mathrm{inf}} - \alpha_{\mathrm{inf}})\,e^{-c} \end{aligned}$$

for Mixed Cal. and

$$\begin{aligned} A_{\mathrm{ref}}(c) &= \alpha(0)\,(1-e^{-c}) \\ A_{\mathrm{ref}}(c) &= \alpha_{\mathrm{inf}} + (\alpha_{\mathrm{inf}} - \alpha_{\mathrm{inf}})\,e^{-c} \end{aligned}$$

for the ideal continuous-mixing concentration axis. α is the retained fraction of the original cell material and α the cell concentration of syringe material relative to the syringe concentration. This convention also accounts for displaced heat during the mixing trajectory, starting from each segment's initial concentration. See Injection Displacement.

For an injection advancing the fraction from c_{in} to $c_{\mathrm{in}} + \Delta c_{\mathrm{in}}$:

$$\begin{aligned} \tau &= \Delta c_{\mathrm{in}} / (1 - \mathrm{mix}) \\ M_{\mathrm{in}} &= \tau\,M_{\mathrm{syr}} \\ c_{\mathrm{in}} &= c_{\mathrm{in}} + \tau\,(M_{\mathrm{syr}} - \mathrm{mix}\,c_{\mathrm{in}}) \end{aligned}$$

where M_{in} are the macromolecule and ligand concentrations in the active cell and M_{syr} in the syringe concentrations. After a segment boundary, the concentrations are multiplied by the activated-volume mixing model provide the starting state, while τ retains the cumulative back-mixing fraction. Without back-mixing, repeated application of these equations reproduces the ideal displacement model.

For **Discrete displacement**, use the individual titrant increment $\tau = \Delta c_{\mathrm{in}} / (1 - \mathrm{mix})$ and $c_{\mathrm{in}} = c_{\mathrm{in}} + \tau\,(M_{\mathrm{syr}} - \mathrm{mix}\,c_{\mathrm{in}})$. Within each segment, concentrations start as recorded in Experiment Data, and the running product of shot retentions. The activated-volume conversion and later segment boundaries are unchanged. Use this mode to test the recorded segment starting concentrations without the mixing correction.

The Mixed Cal. estimate can serve as that tandem instruments. Mixed Cal. analyzes Software using Origin (see Manual, MANDIT-133-09-02 SP1Aug 2019), version 10.5.1, equations 5 and 6 using the manual's approximate typical parameters. The equations assume the manual's average injection volume and cell volume. Use Mixed Cal. for comparison with the manual's published tandem model. Discrete displacement is the most direct test of the recorded concentrations. Ideal continuous mixing approaches twice the active cell volume, so choose another method for longer sequences. Ideal continuous mixing is the most physical model for a well-stirred cell. Use it when you want to test whether each individual injection is be smaller than the cell volume, without a conservative volume cap.

SETTINGS

Settings and defaults

Configure shared defaults for display, processing, fitting, and export.

Last verified: 2026-05-20

Preferences… contains **General**, **Processing**, **Fitting**, and **Export**. Settings labeled as defaults provide starting values for new or reset items. Changing them affects preselected values and does not change existing experiments, results, or figures. Some settings affect only the current application preferences. Project and recovery behavior is documented in Project Files and Recovery.

Shared controls

Most settings applications use the same kinds of values for local search and Restore Defaults, including a **Double-function experience font** and **100% accurate concentration cell**. Each control's purpose is shown next to its effect, including values between or beyond the slider presets. Choosing **Apply** accepts the settings that you will return in the application's Preferences window.

Restore Defaults resets the built-in values in the window. **Apply** saves the staged values as application preferences. **Cancel** closes the window without saving changes.

General

SETTING	EFFECT
Energy units	Select **Joule + Calories**. Displayed values automatically use the best or kJ/ mol unit for the active experiment. Choose **kcal/mol** or **kJ/mol** to force one unit.
Concentration unit	Select **Molar** and its concentration units, preferred display, and supported micro-molar concentration fields. Format specific data experts use their documented units.
Default temperature	Shared default temperature for the experiment designer and its tandem controls.
Number precision	Controls screen presentation. **Strict**, **Standard**, **High decimal**, or **All decimals**. It does not set export decimal places.
Uncertainty display	Shared uncertainty presentation. **Automatic**, **Standard deviation**, **Confidence interval**, **SE** or **Hidden**. Automatic uses standard deviation for Analysis Results and confidence intervals for Fit Results. It also controls how fit errors are shown in the graph and tables. The change affects presentation, not the underlying fit or calculation uncertainty.
Reference temperature (°C)	Temperature used when a heat is shifted specifically to calculate a reference temperature.
Minimum concentration	Minimum temperature sensitive required for temperature-dependent result analyses.
Minimum cell load (CM)	Minimum ionic strength solution required for cell-dependent result analyses.
Include buffer strength in results	Includes buffer contribution when ionic strength is calculated.
Show the address cell concentration of experiments	Controls launch time when display. It does not disable result analysis.
Confirm irreversible actions	Controls confirmation before remove or delete commands.
Automatically backup Experiment Data files	Controls automatic removal of orphan backup when data are loaded.
Enable recovery	Enables periodic recovery copies.
Interval (minutes)	Sets the autosave interval. The built-in default is **5 minutes**.
Maximum files	Sets the number of autosave files retained. The built-in default is **10 files**.
Prompt to recover on startup	Controls whether the application presents an available autosave recovery after an interrupted session. Recovery is available in Settings.
Open Autosave Folder…	Opens the folder containing autosave recovery files.

Energy Tuning, concentration cell, number precision, and uncertainty presentation are shared application settings. Changing them affects how values are displayed and exported. Changing displayed values does not change the data used by supported Interchange formats. Automatic display uses k cal but when a value group is empty, zero, non-finite, or at or above the 100 cell threshold. Fixed cell presentation uses the selected unit and the selected number of decimals.

Processing

SETTING	EFFECT
Injection integration	Select **Manual** (default), **Heat continuous mixing**, or **Discrete displacement** for new data. Heat continuous mixing is the standard tandem-mixing correction. Discrete displacement is the direct test. Changing it affects only newly imported experiments. Existing experiments retain their saved integration. Reintegrate is always for method. Saved fits are not automatically rejected.
Buffer subtraction	Sets the default buffer subtraction mode: **Matched**, **Linear**, **Exp. decay**.
Ground negative heat after baseline	Controls whether existing integration regions are recalculated after baseline correction.
Reintegrate integrated heat	Sets how **Accumulate concentrations and ratios** shows the **Cell** and **Cell** reports. You can change it for an import without changing the preference. Recalculate uses the imported baseline. Reintegrate uses the current baseline. Both modes preserve the original integrated heats. Baseline selection and peak integration… (2) concentrations and ratios.
Peak detection	Sets the default active peak detector: **Native**, **Advanced**, or **Genus**.
Peaks	Sets the default active bundle and detector: **Native** or **Peaks** for the active peak detector.
Show active peak detection settings by default	Controls whether active points can be moved in time by default.
Automatically integrate peaks on import	Controls whether copying an integration region also copies its start time.
Copy integration regions to compatible regions	Controls whether copying an integration region also copies its start time.

Processing preferences provide defaults for new processes. Processing values already stored in Experiment Data are not changed by changing a preference.

Fitting

SETTING	EFFECT
Default solver	Sets the starting solver. **Native Model (SIMPLEX)** or **Levenberg-Marquardt**.
Error estimation	Sets the default uncertainty method. **None**, **Bootstrap residuals**, **Leave-one-out**, or **Profile likelihood**. The built-in default is **Bootstrap residuals**.
Bootstrap iterations	Sets the number of residual bootstrap runs. Leave-one-out runs one refit per selected injection. Profile likelihood does not use this value. The built-in default is **200**.
Optimizer tolerance	Sets the solver tolerance preset. **Tight**, **Normal**, **Balanced**, **Strict**, or **Very Strict**. The built-in default is **Normal**.
Max. iterations	Sets the maximum number of optimizer iterations. Enter a value between 1 and **10,000**. Use a fit from such as the Native Solver to.
Parameter limits	Sets the default parameter limit policy. **Standard**, **Unbounded**, or **No limit**.
Use injection-level weights	Controls weighting of injection observations by their estimated errors.
Use concentration uncertainty in tandem fits	Controls whether concentration uncertainty is included in tandem-model weighting. Leave one out always concentrations that.
Automatic concentration fit (%)	Sets the automatic fraction concentration fit used when concentration uncertainty weighting is applied.
Create profile-analysis result	Controls creation of a combined Analysis Result after a profile-enable experiment fit. Disabled is the default.
Auto open new analysis result	Controls whether a newly created result is opened automatically.

Bootstrap method and count are shared fitting defaults, concentration sampling and parameter uncertainty apply only to residual bootstrap. If profiling is unavailable for the selected model, Fit is retained. Whether an update replaces an existing result with partial profile output depends on the **Create profile-analysis result** preference. Profile likelihood is available in the Fit Result panel. See Analysis Result Data for model and uncertainty interactions.

Automated interpretation access

To expand an expert with additional interpretation controls, see the Automated interpretation access registration page. If enabled, expert controls are added, and accept the Terms and acknowledge the warning. Automated interpretation is off by default. Turning it off hides the controls but keeps the rules confirmed. If it is enabled or clear on exit, preview **Expert Interpretation** rules.

Without a rule, automated interpretation uses the public **Default** depth. Enter the account code and choose **Verify Access** to check the options available to your account. Only the options that are available, choose from **Interpretation depth**. Preferences show available account details and remaining access. The rules apply instead of the **Interpretation depth** preference.

Export

SETTING	EFFECT
Selection	Sets the default export scope. **Selected experiment**, **Active experiments**, or **All experiments**.
Overwrite	Sets the number of identical plots or exported results tables.
Export baseline-corrected data	Includes baseline-corrected data in data exports.
Export fit points with graph	Includes fitted peak points with exported peak data.
Open view	Includes index view values in exported tables.
Injection IDs	Includes injection volume, delay, peak area, integration length, and temperature columns.
Concentrations	Includes cell and syringe concentration columns.
Included only	Includes the injection inclusion state.
Peak heats	Includes integrated peak heats.
Fit data	Includes fitted values.
Width on x-height (w)	Sets the default fwhm figure dimensions. The built-in dimensions are **8.0** × **10.0** cm.
Width on x-height (w)	Sets the default fwhm figure dimensions. The built-in dimensions are **8.0** × **10.0** cm.

Show residual graph	Includes the residual graph in final figures.
Show residual graph gap	Includes the gap separating residual and fit panels.
Unify residual graph axis	Uses a common residual-axis scale across applicable panels.
Fit line	Sets fit-line smoothing: **Smooth**, **Spline**, or **Linear**.
Show parameter box by default	Includes the parameter information box in new final figures.
Show experiment details by default	Includes experiment metadata in the figure information box.
Show model info by default	Includes model information in the figure information box.
Auto axes ignore excluded/bad points	Excludes points marked excluded or bad when automatic axes are calculated.
Thermodynamic parameters	Includes thermodynamic parameters in final-figure information.
Offset parameter	Includes the fit offset in final-figure information.
Derived parameters	Includes derived parameters in final-figure information.
Temperature	Includes temperature in final-figure information.
Concentrations	Includes concentrations in final-figure information.
Injection delay	Includes injection delay in final-figure information.
Instrument	Includes instrument information in final-figure information.
Attributes	Includes experiment attributes in final-figure information and limits their display to **Used in analysis**, **All**, or **None**.

Export preferences affect newly generated exports and figure defaults; they do not rewrite an existing export or a stored figure configuration. See Figures and export for output formats and units.

The energy-unit preference also sets the initial molar-energy unit in the Integrated Peaks, Combined Data, and ITCsim export dialogs. kJ/mol for Joules or kcal/mol for Calories. You can choose another unit for each export without changing the preference.

> **PLATFORM NOTE:**
> The **Publication font** selector is available on Windows and Linux, with choices of **Native**, **Inter**, and **Liberation Sans**. Some macOS releases use the native publication renderer and do not show this selector.

CHAPTER 12

Glossary and equations

Terminology, keyword conventions, calculation symbols, equations, and references.

Last verified: 2026-09-23

Workspace terms

TERM	MEANING IN FT-ITC ANALYSIS
Experiment Data	One imported or application-created ITC dataset, including its details and analysis state.
Data / Results	The workspace list containing experiments and stored Analysis Results.
Selected	The item currently shown or targeted by a selection-specific command.
Active experiments	Experiments included in a multi-experiment operation.
Solution	A fitted model state for one experiment.
Analysis Result	A stored fit result with one or more member solutions and the fit state used to create it.
Attribute	Experiment metadata used for organization or analysis context.
Valid result	An Analysis Result whose recorded fit inputs still match the current project state.
Correlation view	Pearson correlations between fitted parameter coordinates across residual-bootstrap refits that have finite values for every displayed parameter, with diagnostics for simulation precision.
Pearson correlation	A value from −1 to +1 describing linear co-variation between two fitted coordinates.
Monte Carlo precision interval	Approximate Fisher-transformation interval describing how precisely the correlation coefficient r is estimated from the finite retained-refit ensemble; it is not uncertainty for either fitted parameter or a model-validity assessment.
AIC / AICc	Analysis-level criteria for comparing saved fits with the same observations, response definition, weighting mode, and likelihood convention; smaller values are preferred. Both modes estimate one residual-variance parameter; weighted criteria use integration errors as relative uncertainties. AICc uses the standard small-sample approximation for nonlinear fits and is preferred when available. Independently fitted members also show a per-member AICc / AIC column for same-experiment comparisons. Neither criterion establishes model adequacy.

Uncertainty terms

TERM	MEANING IN FT-ITC ANALYSIS
Best-fit value	Parameter value from the primary optimization. Resampling estimates uncertainty around this value but does not replace it with a resampling mean or median.
Standard deviation (SD)	Root-mean-square deviation of retained resampling values from the primary best-fit value.
95% confidence interval (CI)	The 2.5th and 97.5th percentiles of the retained resampling distribution. It can be asymmetric around the best-fit value.
Automatic uncertainty display	Shows CI for a materially asymmetric stored interval and SD otherwise. It selects a presentation separately for each reported quantity.
Displayed parameter uncertainty	Fitted-coordinate uncertainty after conversion or propagation into the quantity shown to the user. The Automatic display decision is applied to this displayed quantity.
Profile likelihood	Conditional profiling at a fixed 95% confidence level. Unweighted and weighted intervals use an F-calibrated worsening relative to the best residual score. Weighted intervals retain processing-derived peak-area SDs as unchanged relative injection weights and estimate the overall residual scale separately. A parameter bound reached before crossing is censoring, not a confidence endpoint. The reported primary fit remains unchanged.
Profile equivalent SD	Symmetric `value ± SD` display scale computed from a complete asymmetric profile interval; it is a display equivalent, not a Gaussian sampling SD.

Keyboard conventions

The application command modifier is **Command** on macOS and **Ctrl** on Windows or Linux.

SHORTCUT	FUNCTION
Command/Ctrl + O	Open data or a project.
Command/Ctrl + S	Save the current project.
Command/Ctrl + Shift + S	Save the project under another name.
Command/Ctrl + E	Open data export.
Command/Ctrl + P	Print the active graph or figure.
Command/Ctrl + Z	Restore the most recently removed item.
Command/Ctrl + I	Invert the Active Experiment Data set.
Command/Ctrl + comma	Open Preferences.
Command/Ctrl + Q	Quit FT-ITC Analysis.
F1	Open **Help and Guide** on Windows and Linux. On macOS, open Help through the **?** menu command.
Enter	Open **Details** for the selected Data/Results item on Windows and Linux.
Left / Right	Change the selected injection in **Process Data**.
Space	Copy the selected integration length to the next injection in **Process Data**; the start is also copied when that processing option is enabled.

Thermodynamic symbols

SYMBOL	MEANING
N	Stoichiometry or site-number term under the selected model.
α	Syringe-side active-concentration correction when syringe correction is enabled.
K_a	Association constant.
K_d	Dissociation constant.
K_i	Macroscopic association constant for sequential transition i.
β_i	Cumulative sequential association product $\prod_{j=1}^{i} K_j$.
f_i	Fraction of macromolecule in sequential state MX_i.
$\bar{\nu}$	Mean ligand occupancy in the sequential model.
ΔH	Binding enthalpy change.
ΔG	Gibbs free-energy change.
$-T\Delta S$	Entropic contribution reported by the application at the evaluation temperature.
ΔC_p	Heat-capacity change in a supported temperature-dependent analysis.
q	Integrated injection heat.
σ	Standard uncertainty or spread, according to context.
Offset	Energy-per-mole-of-injectant correction included in the modeled injection heat.

Calculation symbols

SYMBOL	MEANING
$P(t)$	Differential power at time t in a thermogram.
$b(t)$	Estimated baseline at time t.
n_i	Amount injected in injection i.
r_i	Residual for injection i observed heat minus model heat.
r_{jk}	Pearson correlation between fitted parameter coordinates j and k.
θ_{ij}	Value of fitted coordinate j in complete bootstrap refit b.
σ_i	Processing-derived uncertainty for injection i.
R	Gas constant.
T	Absolute temperature, in kelvin, for thermodynamic relationships.
I	Ionic strength used in salt analysis.
a_{ion}	Ion activity used in Counter Ion Release analysis.
m	Fitted slope in the Protonation relationship; the application reports **Protons** as $-m$.
n_{ion}	Counter-ion slope reported by Counter Ion Release analysis.
RSS	Raw residual sum of squares, Σr_i^2, over included injections.
Q	Standardized residual sum of squares, $\Sigma(r_i/\sigma_i)^2$. Weighted AIC/AICc estimates a common variance multiplier as Q/n.
L	Gaussian likelihood used for AIC/AICc.
p	Number of free fitted parameters in the saved global model; shared coordinates count once and member coordinates count per member.
K	AIC/AICc likelihood parameter count: $p + 1$ in both weighting modes, including one estimated common residual variance or one estimated multiplier of the injection-error variances.

Equation index

RELATIONSHIP	LOCAL EXPLANATION
Integration and molar normalization	Processing
Monomer–dimer association	Dissociation
Sequential binding polynomial and ligand balance	Sequential Binding Sites
Thermodynamic conversion and $-T\Delta S$	Thermodynamic relationships
Fit residuals, RMSD, and weighting	Weight by injection error
AIC, AICc, Gaussian likelihood, and parameter counting	Information criteria
Temperature-dependent constraints	Multiple-experiment fitting
Parameter correlation (Pearson residual bootstrap)	Parameter correlation
Bootstrap SD and percentile confidence interval	Parameter uncertainty
Automatic uncertainty display	Uncertainty and evaluation temperature
Salt dependence	Salt
Protonation dependence	Protonation
Buffer correction	Buffer Subtraction
Tandem injection-displacement correction	Tandem injection-displacement correction

Units are those shown by the application or export.

References

- FT-ITC Analysis repository
- FT-ITC Analysis website
- FT-ITC Project Viewer
- Software DOI: 10.5281/zenodo.14832177
- Malvern Instruments, *MicroCal ITC Analysis Software Using Origin User Manual*, MAN0577-02-EN-00 (20 May 2015), section 12.3.1, equations 2 and 4.
- **Help > Citation** for the current paper citation, versioned software citation, and BibTeX
- Philippe Dumas, *Isothermal titration calorimetry in the single-injection mode with imperfect mixing*, European Biophysics Journal 51, 77–84 (2022). The application's **Ideal continuous mixing** option is inspired by the paper but uses ideal mixing with a finite-injection numerical approximation; it does not implement the paper's imperfect-mixing model.
- Ernesto Freire, Arne Schön and Adrián Velazquez-Campoy, *Isothermal titration calorimetry: general formalism using binding polynomials*, Methods in Enzymology 455, 127–155 (2009). The application's **Discrete displacement** option uses this convention for concentrations and displaced-volume heat compensation, retaining FT-ITC's equilibrium solvers and offset convention.

Scientific claims and model-specific methods require the primary literature appropriate to the experiment and analysis.