
## How to Connect?


- 1. After writing OS, insert the micro SD card to Raspberry Pi.
- 2. Install 4 brass standoffs.



3. Connect the ribbon cable.


Note: Pay attention to the blue bar on the cable when connecting.







4. Fix the Raspberry Pi with 4 screws and then connect the ribbon cable. Then install the stands with 2 screws.



5. Connect the power supply and wait a few seconds, the screen will display.

If the screen doesn't display normally, use a computer to open the following file in the micro SD card. boot/config.txt

Add a "#" in front of "dtoverlay=vc4-fkms-v3d" and save the file. Then turn on Raspberry Pi again. dtoverlay=vc4-kms-v3d → # dtoverlay=vc4-kms-v3d

Having problems? Download the latest tutorial and troubleshooting: http://freenove.com/fnk0078 Need further help? Contact our technical support by email: support@freenove.com