





























WS2812 LED: 1012

Batterij Monitor: 1013

Blaster: 1010 Zoemer: 1046



A:1039

B:1040

X:1038

Y:1041

MENU:1045 **START:**1000

JOY 1:1003 JOY ↔ :1001

Accelero Gyro WSEN-ISDS 12C 0x6B 1021

LCD GC9307 (ST7789) 240*296px

MISO:1008 MOSI:1006

SCLK:1007

-CS:1005 -DC:1004

-RSTn:1048

SDCARD - CS:1014

12C SCL:1018 12C SDA:1009

AUX PWR: 1042



dekimo









