DashboardClient Java Lib. User Manual

Version No: 1.0.3

Release Date: 2024-02-05

Author: funh

Preface

Revision table

Date	Version No.	Change content	Author
2024-02-05	1.0.0	Initial release	funh

Table of Contents

1.	DEL	IVERABLE CONTENT	5
2.	Fun	oction detail	5
	2.1	Dashboard Client	5
	2.2	setRobotMajorVersion	5
	2.3	getRobotMajorVersion	6

1. DELIVERABLE CONTENT

Deliverable content	Description	Dependency
dashboard.jar	Dashboard client java	URCap API 1.11
	implementation,	
	compatible with UR CB3	
	and e-series	
User manual	NA	NA

2. INTEGRATION SNIPPET IN POM

3. FUNCTION DETAIL

3.1 DashboardClient

This is a constructor for creating a DashboardClient instance.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
ipAddress	string	CB3 & CB5	NA	NA	UR robot ip address
Return value	DashboardClient				

Sample code:

```
private DashboardClient dashboardClient = new DashboardClient("127.0.0.1");
```

3.2 setRobotMajorVersion

To set cobot major version to adjust dashboard server.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter
name	type	Compatibility	value	range	description

nb	Integer	CB3 & CB5	5	3 or 5	Cobot major version number, CB3 case: 3 CB5 case: 5
Return value	void			void	

Sample code:

dashboardClient.setRobotMajorVersion(5);

3.3 getRobotMajorVersion

This method will return current cobot generation setting.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
nb	Integer	CB3 & CB5	5	3 or 5	Cobot major version number, CB3 case: 3 CB5 case: 5
Return value	Integer	Current Dashboard instance's cobot generation setting.			generation setting.

Sample code:

Integer majorVersion = dashboardClient.getRobotMajorVersion();

3.4 play

This method complies with Dashboard manual on "play" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter	
name	type	Compatibility	value	range	description	
NA	NA	CB3 & CB5	NA	NA	NA	
Return value	String	Return string is complied with official Dashboard Server manual.				

Sample code:

String result = dashboardClient.play();

3.5 stop

This method complies with Dashboard manual on "stop" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	String	Return string is complied with official Dashboard Server manual.			

Sample code:

```
String result = dashboardClient.stop();
```

3.6 pause

This method complies with Dashboard manual on "pause" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	String	Return string is complied with official Dashboard Server manual.			

Sample code:

```
String result = dashboardClient.pause();
```

3.7 quit

This method complies with Dashboard manual on "quit" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter		
name	type	Compationity	value	range	description		
NA	NA	CB3 & CB5	NA	NA	NA		
Return	String	Return string is complied with official Dashboard Server					
value			manual.				

Sample code:

```
String result = dashboardClient.quit();
```

3.8 shutdown

This method complies with Dashboard manual on "quit" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA

Ī	Return	void	void
	value		

Sample code:

```
dashboardClient.shutdown();
```

3.9 running

This method complies with Dashboard manual on "running" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter	
name	type	Companionity	value	range	description	
NA	NA	CB3 & CB5	NA	NA	NA	
Return	String	Return string is complied with official Dashboard Server				
value				manual.		

Sample code:

```
String result = dashboardClient.running();
```

3.10 robotmode

This method complies with Dashboard manual on "robotmode" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter		
name	type		value	range	description		
NA	NA	CB3 & CB5	NA	NA	NA		
Return	String	Return string is complied with official Dashboard Server					
value				manual.			

Sample code:

```
String result = dashboardClient.robotmode();
```

3.11 loadProgram

This method complies with Dashboard manual on "load + str" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter	
name	type	Compatibility	value	range	description	
str	String	CB3 & CB5	null	null	Name of robot	
					program to load.	
Return	String	Return string is complied with official Dashboard Server				
value				manual.		

Sample code:

```
String result = dashboardClient.loadProgram("test.urp");
```

3.12 getLoadedProgram

This method complies with Dashboard manual on "get load program" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	String	Return strin	g is complie	ed with official manual.	Dashboard Server

Sample code:

```
String result = dashboardClient.getLoadedProgram();
```

3.13 popup

This method complies with Dashboard manual on "popup" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
msg	String	CB3 & CB5	NA	NA	Message to popup.
Return value	void	void			

Sample code:

```
dashboardClient.popup("message to popup.");
```

3.14 closePopup

This method complies with Dashboard manual on "close popup" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	void			Void	

Sample code:

dashboardClient.closePopup();

3.15 addToLog

This method complies with Dashboard manual on "addToLog + str" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter	
name	type	Companionity	value	range	description	
strLog	String	CB3 & CB5	NA	NA	Message to add in	
					Log tab page.	
Return	String	Return string is complied with official Dashboard Server				
value				manual.		

Sample code:

```
String result = dashboardClient.addToLog("message to add in Log");
```

3.16 isProgramSaved

This method complies with Dashboard manual on "isProgramSaved" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	String	Return strin	g is compli	ed with official manual.	Dashboard Server

Sample code:

```
String result = dashboardClient.isProgramSaved();
```

3.17 programState

This method complies with Dashboard manual on "programState" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	String	Return strin	g is complie	ed with official manual.	Dashboard Server

Sample code:

String result = dashboardClient.programState();

3.18 PolyscopeVersion

This method complies with Dashboard manual on "PolyscopeVersion" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description	
NA	NA	CB3 & CB5	NA	NA	NA	
Return	String	Return string is complied with official Dashboard Server				
value				manual.		

Sample code:

```
String result = dashboardClient.PolyscopeVersion();
```

3.19 setOperationalMode

This method complies with Dashboard manual on "set operational mode + mode" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
mode	String	CB5	NA	"manual" or	Set cobot into
				"automatic"	manual or
					automatic mode
Return value	String	If send mode with correct string, it will return string that complied with official Dashboard Server manual.			
				will return "wro it will return "de	ong mode input". precated".

Sample code:

```
String result = dashboardClient.setOperationalMode("manual");
```

3.20 getVariable

This method can extract a target variable value in cobot runtime.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
varName	String	CB3 & CB5	NA	NA	Get variable value in String.

Return	String	Return variable value in String
value		

Sample code:

```
String result = dashboardClient.getVariable("varName");
```

3.21 getOperationalMode

This method complies with Dashboard manual on "set operational mode + mode" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter		
name	type	Compatibility	value	range	description		
NA	NA	CB5	NA	NA	NA		
Return	String	In CB5 case: return string is complied with official Dashboard					
value		Server manual.					
			In CB3 case	e: return "depre	cated".		

Sample code:

```
String result = dashboardClient.getOperationalMode();
```

3.22 clearOperationalMode

This method complies with Dashboard manual on "clear operational mode" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB5	NA	NA	NA
Return value	String		Se	is complied wi rver manual. :: return "depre	th official Dashboard cated".

Sample code:

```
String result = dashboardClient.clearOperationalMode();
```

3.23 setUserRole

This method complies with Dashboard manual on "setUserRole" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
strRole	String	CB3	NA	"programmer"	Role string

				"operator"			
				"none"			
				"locked"			
Return	String	In CB3 case: return string is complied with official Dashboard					
value		Server manual.					
			In CB5 cas	e: return "deprecat	ted".		

Sample code:

```
String result = dashboardClient.setUserRole("operator");
```

3.24 getUserRole

This method complies with Dashboard manual on "getUserRole" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter		
name	type	1	value	range	description		
NA	NA	CB3	NA	NA	NA		
Return	String	In CB3 case: return string is complied with official Dashboard					
value		Server manual.					
			In CB5 case	e: return "depre	cated".		

Sample code:

```
String result = dashboardClient.getUserRole();
```

3.25 powerOn

This method complies with Dashboard manual on "power on" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	void			void	

Sample code:

dashboardClient.powerOn();

3.26 powerOff

This method complies with Dashboard manual on "power on" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter
name	type	Compatibility	value	range	description

NA	NA	CB3 & CB5	NA	NA	NA		
Return	void	void					
value							

Sample code:

```
dashboardClient.powerOff();
```

3.27 brakeRelease

This method complies with Dashboard manual on "brake release" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	void			void	

Sample code:

```
dashboardClient.brakeRelease();
```

3.28 safetyStatus

This method complies with Dashboard manual on "safetystatus" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter		
name	type	Compatibility	value	range	description		
NA	NA	CB5	NA	NA	NA		
Return	String	In CB5 case: return string is complied with official Dashboard					
value		Server manual.					
			In CB3 case	: return "depre	cated".		

Sample code:

```
String result = dashboardClient.safetyStatus();
```

3.29 safetymode

This method complies with Dashboard manual on "safetymode" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description	
NA	NA	CB3	NA	NA	NA	
Return value	String	In CB3 case: return string is complied with official Dashboard Server manual.				

In CB5 case: return "deprecated".	•
-----------------------------------	---

Sample code:

String result = dashboardClient.safetymode();

3.30 unlockProtectiveStop

This method complies with Dashboard manual on "unlock protective stop" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	void	void			

Sample code:

dashboardClient.unlockProtectiveStop();

3.31 closeSafetyPopup

This method complies with Dashboard manual on "close safety popup" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	void	void			

Sample code:

dashboardClient.closeSafetyPopup();

3.32 loadInstallation

This method complies with Dashboard manual on "close safety popup" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description	
strInstallation	String	CB3 & CB5	NA	NA	Name of target installation file	
Return value	String	return string is complied with official Dashboard Server manual.				

Sample code:

```
String result = dashboardClient.loadInstallation("default.installation");
```

3.33 restartSafety

This method complies with Dashboard manual on "restart safety" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
NA	NA	CB3 & CB5	NA	NA	NA
Return value	void	void			

Sample code:

dashboardClient.restartSafety();

3.34 isInRemoteControl

This method complies with Dashboard manual on "is in remote control" command.

Parameter	Parameter	Compatibility	Default	Parameter	Parameter	
name	type	Compatibility	value	range	description	
NA	NA	CB5	NA	NA	NA	
Return	String	In CB5 case: return string is complied with official Dashboard				
value		Server manual.				
		In CB3 case: return "deprecated".				

Sample code:

```
String result = dashboardClient.isInRemoteControl();
```

3.35 getSerialNumber

This method complies with Dashboard manual on "get serial number" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description	
NA	NA	CB3 & CB5	NA	NA	NA	
Return value	String	return string is complied with official Dashboard Server manual.				

Sample code:

```
String result = dashboardClient.getSerialNumber();
```

3.36 getRobotModel

This method complies with Dashboard manual on "get robot model" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description	
NA	NA	CB3 & CB5	NA	NA	NA	
Return value	String	return string is complied with official Dashboard Server manual.				

Sample code:

String result = dashboardClient.getRobotModel();

3.37 generateFlightReport

This method complies with Dashboard manual on "generate flight report + <Type>" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description	
strType	String	CB3 & CB5	NA	NĀ	controller software system	
Return value	String	return string is complied with official Dashboard Server manual.				

Sample code:

String result = dashboardClient.generateFlightReport("system");

3.38 generateSupportFile

This method complies with Dashboard manual on "generate support file + <directoryPath>" command.

Parameter name	Parameter type	Compatibility	Default value	Parameter range	Parameter description
strDirectory	String	CB3 & CB5	NA	NÁ	where represents path to an already existing directory location inside the programs directory.
Return value	String	return string is complied with official Dashboard Server manual.			

Sample code:

```
String result = dashboardClient.generateSuppportFile(".");
//store file inside of default Systems folder.
```