1. Buses

- a. Key characteristic of bus
 - i. Shared transmission medium
 - ii. Anything using the bus must obtain the "right" to use the bus first
- b. Functional groups
 - i. Data lines
 - ii. Address lines
 - 1. Select where to source from, where to send to
 - 2. Could pick different parts of the CPU, memory, or I/O
 - iii. Control lines
 - 1. Control use of data and address lines
 - 2. Variety of signals
 - a. Memory write/read
 - b. I/O write/read
 - c. Transfer ACK (acknowledgment), data has been taken from or placed on bus
 - d. Bus request/grant, to give permission to somebody who wants the bus
 - e. Interrupt request/ACK, will discuss this later
 - f. Clock, same one we've been talking about
 - g. Reset

c. Types of buses

- i. Dedicated permanently assigned to a subset of components, or to one function
 - 1. Example: data bus versus address bus
 - 2. Need more buses to send all information
- ii. Time multiplexed using bus for multiple functions based on clock
 - 1. Send address for first part of clock, then data for second
 - 2. Don't need as many buses, but can't transmit at same speed a dedicated bus can

2. Bus hierarchies

- a. Remember, shared transmission medium
- b. Multiple bus hierarchies
 - i. Same idea as before, create multiple buses
 - ii. Reduce length of entire bus, allow parallel data transfer
 - iii. Traditional
 - 1. CPU \leftrightarrow local bus \leftrightarrow cache \leftrightarrow system bus \leftrightarrow main memory and expansion bus interface
 - 2. Expansion bus interface \leftrightarrow expansion bus \leftrightarrow network and other I/O
 - iv. High performance
 - 1. CPU \leftrightarrow local bus \leftrightarrow cache/bridge \leftrightarrow high-speed bus
 - 2. High-speed bus ↔ main memory
 - 3. High-speed bus ↔ video, network, GPUs, expansion bus interface
 - 4. Expansion bus interface ↔ other I/O
 - v. For high performance, place important devices closer to CPU
 - 1. Skip level of indirection by hooking up directly to high-speed bus



- 3. Bus specifics
 - a. Bus width
 - i. How big are our addresses?
 - ii. How big is our data?
 - 1. Larger bus means transferring more data at once
 - b. Bus clock time
 - i. Bus driven by input clock
 - ii. Determines how much data we can transfer at once
 - iii. Example below, want to determine throughput (bits / second) of a bus
 - 1. 32-bit bus, 1 GHz input clock = 1 ns
 - a. Frequency (Hz) = 1 / seconds (s)
 - b. Giga SI prefix = 10^9 , so 1 GHz = 10^9 Hz
 - c. Invert 1 GHz, which is our frequency
 - d. Inverting this, we get $1/10^9$ Hz = 10^{-9} seconds
 - e. Nano SI prefix = 10⁻⁹, so 10⁻⁹ seconds * (10⁹ nanoseconds / 1 second) = 1 nanosecond
 - 2. Bus cycle takes at least 100 input cycles
 - a. Will take at least 100 clock cycles to do one bus cycle
 - b. So 32 bits / bus cycle * 1 bus cycle / 100 clock cycle = 0.32 bits / clock cycle
 - c. Key word is at least, so this is a theoretical maximum
 - 3. Transfer rate = (bits / bus cycle) * (bus cycles / clock cycle) * (clock cycles / time)
 - a. 32 bits / bus cycle * 1 bus cycles / 100 clock cycles * 1 clock cycle / 1 ns
 - b. $0.32 \text{ bits / ns} * 10^9 \text{ nanoseconds / 1 second} = 3.2 * 10^8 \text{ bits / s}$
 - 4. So $3.2 * 10^8$ bps (bits / s) is our theoretical maximum
 - a. Can turn this into a more reasonable number by converting to megabits
 - 5. Unit prefix confusion
 - a. Official SI prefixes = powers of 10
 - i. Kilo = 10^3 , Mega = 10^6 , Giga = 10^9 , so on
 - ii. For historical reasons computer scientists use these names for the powers of 2 explained below
 - b. Official IEC prefixes = powers of 2
 - i. Kibi = 2^{10} , Mebi = 2^{20} , Gibi = 2^{30}
 - ii. IEC = International Electrotechnical Commission
 - iii. However, we commonly call these prefixes with powers of 2 the other names
 - iv. This confusion is related to what happens when you buy a storage drive and its storage inside your OS is smaller than what was "advertised"
 - 6. Back to converting the bps above
 - a. $3.2 * 10^8$ bits / second * 1 mebibit / 2^{20} bits = ~ 305 mebibits / second
 - b. Or is it megabits?
 - i. Just use bps and you won't need to bother with this
 - 7. 3.2 * 108 bps is the theoretical maximum throughput for this bus

