
## 1. From last time

a. Went over the single bus machine below



- b. Example let's add two memory locations and place result in register file
  - i. Times for each step in parentheses
  - ii. Get value at first memory location (2 clock cycles + time for memory read)
    - 1. Address of first operand placed on bus from IR
      - a.  $IR \rightarrow Bus$
    - 2. MAR takes in value, memory returns desired value to MDR
      - a. Bus  $\rightarrow$  MAR
      - b. Tell memory to read from first operand
      - c. Memory  $\rightarrow$  MDR
    - 3. MDR places its value on bus, X takes in value for temporary storage
      - a.  $MDR \rightarrow Bus$
      - b. Bus  $\rightarrow X$
  - iii. Get value at second memory location (1 clock cycle + time for memory read)
    - 1. Address of second operand placed on bus from IR
      - a.  $IR \rightarrow Bus$
    - 2. MAR takes in value, memory returns desired value to MDR
      - a. Bus  $\rightarrow$  MAR
      - b. Tell memory to read from second operand
      - c. Memory  $\rightarrow$  MDR

- iv. Add things together, place in register file (3 clock cycles + ALU add time + register file write time)
  - 1. MDR places its value on bus
    - a.  $MDR \rightarrow Bus$
  - 2. ALU takes in current value on bus and X, places it output in Z
    - a.  $X \rightarrow ALU$
    - b. Bus  $\rightarrow$  ALU
    - c. Tell ALU to add
    - d. ALU  $\rightarrow$  Z
  - 3. Z places its value on bus, register file takes in value
    - a.  $Z \rightarrow Bus$
    - b. Bus → Register File
  - 4. IR places register address on bus, register file takes in address
    - a. IR  $\rightarrow$  Bus
    - b. Bus → Register File
    - c. Tell register file to write
- c. Can see that one bus is a huge limiting factor
  - i. Lots of contention for the bus, many things want to use it
    - 1. In particular, fetching instructions versus fetching data from memory
      - a. CPU can't do both at once because of the single bus
      - b. Throughput is lower than the CPU can handle, could go much faster
      - c. Known as the von Neumann bottleneck
  - ii. Every time we use the bus for something else, need another clock cycle
    - 1. Cannot place two things at same time on bus in one clock cycle
  - iii. Idea: another bus
    - 1. Works better, but not perfect
    - 2. Good for A = A + B
    - 3. Adds more cost to machine to support another bus
  - iv. Solution: third bus
    - 1. Now we can handle A = B + C
    - 2. Costs even more
    - 3. Three bus CPU takes fewer cycles than one or two buses to execute an instruction
      - a. Still takes more than 1 to do so, though
- d. Couple of reasons why we can't reduce to 1 cycle
  - i. Must increment PC to reach next instruction
    - 1. Requires using the ALU to do so
    - 2. Solution: place an adder by the PC to do only that
  - ii. Complex addressing modes require multiple trips to memory
    - 1. Solve by limiting the instruction set to a load/store architecture
    - 2. ALU instructions can only use registers
    - 3. With all the above, instructions can execute in a single cycle
    - 4. Idea behind RISC



- 2. RISC versus CISC machines
  - a. Review of material from ECS 50
  - b. Back in the 1970s, had dozens of machines and instruction sets
    - i. CISC complex instruction set computer
    - ii. Lots of powerful instructions that did a lot at once
  - c. Different teams at Stanford and Berkeley looked over this
    - i. Looked at making instruction sets simpler
    - ii. Keep only a few instructions that can be done very fast
    - iii. Found that if you implement a program in this method, can be done faster than CISC
  - d. RISC reduced instruction set computer
    - i. Less powerful instructions, and will need more of them to run same program versus CISC
    - ii. However, can make the clock *much* faster to compensate

