

FujiNet-SMS Rev0: edge and tab at 1:1, component side (F.Cu, even pins 2-50), fingers down
Print at 100 % (no fit-to-page) and check the 50 mm ruler. Then lay a real SMS cartridge board
(label side up) on the fingers: every finger and both tab edges should line up within ~0.2 mm,
and the tab must match the console slot opening. Pins 1/2 are at the right as drawn here.

