



NES 72-pin edge drawn by function (finger numbers on the pins). Pin 1 is at the RIGHT seen from the label side with the fingers down (nesdev: NES-EWR0M-01 geometry).
EXP0-9 and SYSTEM CLK are not used. The CIClone (ATTtiny13A) is DNP until its firmware exists.











