ARD1 ARDUINO MEGA2560 R3 RESET AREF PB7/OC0A/OC1C/PCINT7 12 11 10 9 8 PB6/OC1B/PCINT6 A0 PF0/ADC0 A1 PF1/ADC1 A2 PF2/ADC2 A3 PF3/ADC3 A7 PF7/ADC7/TI A6 PF6/ADC6/TI A5 PF5/ADC5/TI A4 PF4/ADC4/T0 PB5/OC1A/PCINT5 PB4/OC2A/PCINT4 TempWaterVolt > TempOilVolt PH6/OC2B PH5/OC4C PF7/ADC7/TDI PH4/OC4B PF6/ADC6/TDO PH3/OC4A PE3/OC3A/AIN1 PF5/ADC5/TMS PF4/ADC4/TCK PG5/OC0B A8 A9 A10 A11 A12 A13 A14 A15 PE5/OC3C/INT5 PK0/ADC8/PCINT16 PE4/OC3B/INT4 TX0 PE1/TXD0/PDO PK1/ADC9/PCINT17 PK2/ADC10/PCINT18 RX0 PE0/RXD0/PCINT8 PK3/ADC11/PCINT19 OME TX3 PK4/ADC12/PCINT20 TX3 PJ1/TXD3/PCINT10 RX3 PJ0/RXD3/PCINT9 TX2 PH1/TXD2 PK5/ADC13/PCINT21 PK6/ADC14/PCINT22 PK7/ADC15/PCINT23 RX2 PH0/RXD2 TX1 PD3/TXD1/INT3 RX1 PD2/RXD1/INT2 SDA PD1/SDA/INT1 SCL PD0/SCL/INT0 DIGITAL -

