# SERVO DRIVER BLOCKS

The project is divided in blocks. Each block join a group os signals and circuits depending on his function. The project is liberated to have reinforced insulation using deutale single isolatios. For that reason, the 4C circuitry is on a cold supply and the output logic is at het supply, BUT take in account that HOT is not 220. It just a name

SDELTA
sigma\_delta.sch

LEM

lem.sch

VBUS MEAS

vbus\_meas.sch

IGBT

inht sch

uC GPIO

uc\_clk\_dbg

AC

IN

uC CLK Dbg

c\_clk\_dba.sch

uC Power

ic nower sch

uC ADC

TEMP

n.sch

UI

CONN

**ENDAT** 

endat.sch

STEP DIR

en dir.sch

QEP

RS485


CAN

Ether NET


ethernet.sch

Ether CAT

ethercat.sch



### USB HOST



 Pablo Slavkin

 dci


 Sheet: /ethernet/

 File: ethernet.sch


 Title: ethernet

 Size: A3
 Date: 2020-01-09
 Rev: 1.0


 KiCad E.D.A. kicad 5.0.2+dfsg1-1
 Id: 2/19




KiCad E.D.A. kicad 5.0.2+dfsg1-1




#### **DECOUPLING FILTERS**





#### Decoupling Capacitors







#### Ferrite Beads Place near U1












#### **BOOTSRAP R's**



#### ADC/DAC DBG OUT




#### SPI FLASH



Dakta Clauda	
Pablo Slavkin	
dci	
Sheet: /uc_clk_dbg/	
File: uc_clk_dbg.sch	
Title: clk	
Size: A3 Date: 2020-01-09	Rev: 1.0
KiCad E.D.A. kicad 5.0.2+dfsg1-1	ld: 6/19
7	


#### Main Power


The same is a control based from the supply directly with a control willing. (2000) proposed from it is the a good officer. If it is the service of the control is the service of the serv





#### **COLD SUPPLY**

It is inteded to use only, I mean ONLY listlide the control board, none of these coopers wires has to leave the board. I isolate every single pin from these supply to go outside, take these in account











#### **HOT SUPPLY**


Take in account that hot doesn't mean that it is referred to high voltage AC socket input path like 220x/380x, it is intended to isolate the uC /logic/user interfase site from accidentally high voltage contact on the hot side and prevent influiries as to make the reinfacced isolation.



Pablo Slavkin	
dci	
Sheet: /ac_in/	
File: ac_in.sch	
Title: AC input	
Size: A3 Date: 2020-01-09	Rev: 1.0
KiCad E.D.A. kicad 5.0.2+dfsg1-1	ld: 7/19


#### PWM OUT -> ISOLATOR -> BUFFER -> FILTER






#### 2 isolated NTC interfase + 1 isolated 1-wire/485

I left 2 isolated analog input to measure until 2 NTC for each motor. If If you need more preciallon or more sessors, I left also an holisted 1-wise/RS465 interface that could manage a lot of 18820 on a bas network.






Pablo Slavkin **dci**  
 Title: gpio

 Size: B
 Date: 2020-01-09

 KiCad E.D.A. kicad 5.0.2+dfsg1-1
 **Rev: 1.0** ld: 9/19


## Differential STEP-DIR input HOT



Pablo Slavkin		
dci		
Sheet: /step_di	r/	
File: step_dir.sc	h	
Title: ENDAT	/BISS Interface	
Size: A3	Date: 2020-01-09	Rev: 1.0
NIC-4 E D.A. 134 E O.3 : 4f4 4		14 40 (40

# 2x Isolated Idifferential ncremental encoder interfase 5v input A-B-I-S


left the Input for two Isolated Incremental encoders. left the 4 signals Input plus two auxiliary output for eny porpous pi



## Isolated CAN interfase

#### **Isolated RS485**


these interfase you could manage isolated RSABS or isolated GPIO or isolated 1—Wire, using SM or 15M as a supply



#### uC GPIO's pins

I've spend hours to choose the GPIO's for each laterfase trying to not creats one to the other, just pay attention if you wanna move some I've used global laters connector to go from one page to another isseed the off-page connector because it's more proue to errors. I know that is not too critotocu. but I've better and fastly for now










controlling and the profession has been above to the controlling and the profession has been above to the controlling and the profession has been above to the controlling and controlling and the controlling


chanlogs: Eve decided to return to a 2x5 terminal block output "cause it match the size of the LEM





LEM\_B\_V





LEM\_A\_W

LEM\_B\_W

The decided to eliminate 1.12M, you could use 3 in line measurement, or 2 in line plus one for all. De reason is use of board and completify

Pablo Slavkin

dci

Sheet: /lem/ File: lem.sch

Title: LEM currente measurement


 Size: A3
 Date: 2020-01-09
 Rev: 1.0

 KiCad E.D.A. kicad 5.0.2+dfsg1-1
 Id: 15/19

#### VBUS -> R divider -> ISO ADC -> uC

t's intended to measure the Vbus, one per motor, but they cold be joined if both motor share same VBus. The Vbus informatio will be used by the control algorith and to drive the break resistor PWM to

The input is expected not to be 220v or 380v. It's supoused to be a isolated low voltage to maintaint the reinforced insulation. In case you can't you could input 220v directly but the isolation would be



Pablo Stavkin

dci

Sheet: /Vbus meas/
File: vbus\_meas.sch


Title: Shunt isolated

Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 16/19

#### **Common Connections**





Pablo Slavkin

dci


Sheet: /connectors/
File: conn.sch

Title: Common connections

Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 17/19

### Isolated sigma delta ADC



Pablo Slavkin

dci


Sheet: /sigma\_delta/
File: sigma\_delta.sch

Title: Shunt Sigma Delta isolated

Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 18/19

#### 2X Isolated diferential ENDAT interface



Pablo Slavkin

dci

Sheet: /endat/
File: endat.sch

Title: ENDAT/BISS Interface

Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 19/19