SERVO DRIVER BLOCKS

The project is divided in blocks. Each block join a group os signals and circuits depending on his function. The project is liberated to have reinforced insulation using deutale single isolatios. For that reason, the 4C circuitry is on a cold supply and the output logic is at het supply, BUT take in account that HOT is not 220. It just a name

SDELTA
sigma_delta.sch

LEM

lem.sch

VBUS MEAS

vbus_meas.sch

IGBT

uC GPIO

uc_gpio.sch

AC

IN

uC CLK Dbg

ıc_clk_dbg.sch

uC Power

c_power.sch

uC ADC **TEMP**

nn.sch

UI

ıi.sch

connectors

CONN

an rs485

ENDAT CAN RS485

QEP


can 485.sc

Ether NET

thernet sch

Ether CAT

ethercat.sch



 Pablo Slavkin

 dci

 Sheet: /ethernet/

 File: ethernet.sch

 Title: ethernet


 Size: A3
 Date: 2020-01-09
 Rev: 1.0


 KiCad E.D.A. kicad 5.0.2+dfsg1-1
 Id: 2/18

KiCad E.D.A. k


uC ADC PINS


Every interfase to the ADC has the responsability to filter it's output before enter ADC pln, for that reason these page just connect to the uC without nothin is the middle







DECOUPLING FILTERS







Decoupling Capacitors







Ferrite Beads Place near U1












MULTI PORPOUSE LEDS




BOOTSRAP R's



DAC DBG OUT



SPI FLASH





Pablo Slavkin dci				
	Sheet: /uc_clk_c File: uc_clk_dbg.			
	Title: clk			
	Size: A3	Date: 2020-01-09		Rev: 1.0
	KiCad E.D.A. kicad 5.0.2+dfsg1-1			ld: 6/18
-	·	7		β

Main Power is case the costrol board have to be supply directly with socket voltage (2009) sopulate these. It's not a good less cases (III life to keep hight voltage exists these controllers beard, but it's a requerience, so I let it as a coption, But you have the low voltage input 15vc and 15vh connections also connection also. The closes to add 2 power supply for Cold and first sides because the control of the control

COLD SUPPLY


It is inteded to use only, I mean ONLY listlide the control board, none of these coopers when has to leave the board. I isolate every single pla from these supply to go outside, take these is account







HOT SUPPLY

Table in account that hot doesn't meen that it is refered to high voltage AC socket input path like 220v/300v. It is intended to isolate the u.c. Account of the control of





PWM OUT -> ISOLATOR -> BUFFER -> FILTER





2 isolated NTC interfase + 1 isolated 1-wire/485






Pablo Slavkin **dci**
 Title: gpio

 Size: B
 Date: 2020-01-09

 KiCad E.D.A. kicad 5.0.2+dfsg1-1

Rev: 1.0 ld: 9/18

2X Isolated ENDAT interface




Pablo Slavkin
dci
Sheet: /endat/
File: endat.sch

Title: ENDAT/BISS Interface
Size: A3 Date: 2020-01-09 Rev: 1.0
KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 10/18

2x Isolated Incremental encoder 5v input A-B-I-S


uent the input for two isotated incremental encouers, left the 4 signals input plus two auxiliary output for eny porpous plus he ability to choose between 5 or 1544



Isolated CAN interfase


Isolated RS485


on a COMMON COMM




uC GPIO's pins

I've spend hours to choose the GPIO's for each laterface trying to not creat one to the other, just pay attention if you wanna move some I've used global labels connector to go from one page to another isseed the off-page connector because it's more proue to errors. I know that is not too critotocu. but I've better and fastly for now













conclusion and yet processes that there was not you fulface, and more processes that the processes of the pr

chanlogs: I've decided to return to a 2x3 terminal block output 'cause it match the size of the LEM









LEM_A_W

LEM_B_W

The decided to eliminate 1 LEM, you could use 3 in the measurement, or 2 in the plas one for all. Se reason in size of board and complexity

Pablo Slavkin
dci
Sheet: /lem/
File: lem.sch

Title: LEM currente measurement


 Size: A3
 Date: 2020-01-09
 Rev: 1.0


 KiCad E.D.A. kicad 5.0.2+dfsg1-1
 Id: 15/18

VBUS -> R divider -> ISO ADC -> uC

It's intended to measure the Vbus, one per motor, but they cold be joined if both motor share same Vbus. The Vbus informatio will be used by the control algorith and to drive the break resistor PWM to protect the rise of the Vbus more than a threshold

he input is expected not to be 220v or 380v. It's supoused to be a isolated low voltage to maintaint the reinforced insulation. In case you can't you could input 220v directly but the isolation would be simple.





Pablo Slavkin

dci


Sheet: /Vbus meas/
File: vbus_meas.sch


Title: Shunt isolated

Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 16/18

Common Connections






Pablo Slavkin dci
Sheet: /connectors/File: conn.sch
 Title: Common connections

 Size: A3
 Date: 2020-01-09

 KiCad E.D.A. kicad 5.0.2+dfsg1-1

Isolated sigma delta ADC

It's Intended for power based chroatery to scapily all the algoris to control based. The control based will use the 50 filter to delare the control based will use the 50 filter to delare the power of the control based o



Pablo Slavkin

dci

Sheet: /sigma_delta/
File: sigma_delta.sch

Title: Shunt Sigma Delta isolated

Size: A3 Date: 2020-01-09 Rev: 1.0

KiCad E.D.A. kicad 5.0.2+dfsg1-1 Id: 18/18