IF 482 Standard ASCII telegram sent from an external time base (e.g. IF 482 MOBALINE/ RS 232 interface, MTC module U 4.1.x or one of the below listed time systems) for automatic time-setting of slave clocks (e.g. BU 190 series) or master clocks HN 425, CTC, MTS, ETC and for master clock modules U 1.2.x in Master Time Center MTC, through the serial interface RS 232 or RS 422.

Time telegram (ASCII) once per second, terminating at the beginning of the designed second in the telegram:

Baud rate: 9600 Bit/s

Data bits 7
Parity: even
Stop bit: 1
Jitter: < 50ms

Format of ASCII telegram string:

Serie	Signification	Sign	HEX
1		0	4F
2	Supervision	Α	41
3	Season	W, S or U ¹⁾	57 or 53
4	Year tens	09	30 39
5	Year unit	09	30 39
6	Month tens	0 or 1	30 or 31
7	Month unit	09	30 39
8	Day tens	03	30 33
9	Day unit	09	30 39
10	Monday Sunday	17	31 37
11	Hours tens	02	30 32
12	Hours unit	09	30 39
13	Minutes tens	0 5	30 35
14	Minutes unit	09	30 39
15	Seconds tens	05	30 35
16	Seconds unit	09	30 39
17	End of telegram	CR	0D

¹⁾ **W**: Standard time, **S**: Season time, **U**: UTC time (not supported from all systems)

Refer to instruction manuals BE-800030 for master clocks HN 425 and HN 425 R, to TE- and BE-800103 for master clock modules U 1.2.0 to U 1.2.2, to TE- and BE-800109 for serial communication module U 4.1.0,

to BE-800161 for CTC master clock or to BE-800196 for MTS.



MOSER-BAER AG. CH-3454 SUMISWALD IF 482 Standard ASCII time telegram

for automatic time-setting of master clocks or slave clocks from an external time base

 $\label{temperature} \mbox{TE-112023.01-IF~482-Standard~ASCII~time~telegram~definition.doc}$

8.6.2004/AK

TE-112 023.01