Electron paramagnetic resonance

Electron paramagnetic resonance (EPR) or electron spin resonance (ESR) spectroscopy is a method for studying materials with <u>unpaired electrons</u>. The basic concepts of EPR are analogous to those of <u>nuclear magnetic resonance</u> (NMR), but the <u>spins</u> excited are those of the electrons instead of the atomic <u>nuclei</u>. EPR spectroscopy is particularly useful for studying metal complexes and organic radicals. EPR was first observed in <u>Kazan State University</u> by <u>Soviet physicist Yevgeny Zavoisky</u> in 1944, [1][2] and was developed independently at the same time by Brebis Bleaney at the University of Oxford.

Contents

Theory

Origin of an EPR signal

Field modulation

Maxwell-Boltzmann distribution

Spectral parameters

The *g* factor

Hyperfine coupling

Multiplicity

Resonance linewidth definition

Applications

High-field high-frequency measurements

Hardware components

Microwave bridge

Reference arm

Magnet

Microwave resonator (cavity)

Pulsed electron paramagnetic resonance

See also

References

External links



EPR spectrometer

Theory

Origin of an EPR signal

Every electron has a <u>magnetic moment</u> and <u>spin quantum number</u> $s=\frac{1}{2}$, with magnetic components $m_{\rm s}=+\frac{1}{2}$ or $m_{\rm s}=-\frac{1}{2}$. In the presence of an external magnetic field with strength B_0 , the electron's magnetic moment aligns itself either antiparallel $(m_{\rm s}=-\frac{1}{2})$ or parallel $(m_{\rm s}=+\frac{1}{2})$ to the field, each alignment having a specific energy due to the Zeeman effect:


$$E = m_s g_e \mu_{\rm B} B_0,$$

where

• g_e is the electron's so-called g-factor (see also the Landé g-factor), $g_e = 2.0023$ for the free electron, [3]


• $\mu_{\rm B}$ is the Bohr magneton.

Therefore, the separation between the lower and the upper state is $\Delta E = g_e \mu_B B_0$ for unpaired free electrons. This equation implies (since both g_e and μ_B are constant) that the splitting of the energy levels is directly proportional to the magnetic field's strength, as shown in the diagram below.



An unpaired electron can change its electron spin by either absorbing or emitting a <u>photon</u> of energy $h\nu$ such that the resonance condition, $h\nu = \Delta E$, is obeyed. This leads to the fundamental equation of EPR spectroscopy: $h\nu = g_e \mu_B B_0$.

Experimentally, this equation permits a large combination of frequency and magnetic field values, but the great majority of EPR measurements are made with microwaves in the 9000–10000 MHz (9–10 GHz) region, with fields corresponding to about 3500 \underline{G} (0.35 \underline{T}). Furthermore, EPR spectra can be generated by either varying the photon frequency incident on a sample while holding the magnetic field constant or doing the reverse. In practice, it is usually the frequency that is kept fixed. A collection of paramagnetic centers, such as free radicals, is exposed to microwaves at a fixed frequency. By increasing an external magnetic field, the gap between the $m_8 = +\frac{1}{2}$ and $m_8 = -\frac{1}{2}$ energy states is widened until it matches the energy of the microwaves, as represented by the double arrow in the diagram above. At this point the unpaired electrons can move between their two spin states. Since there typically are more electrons in the lower state, due to the Maxwell–Boltzmann distribution (see below), there is a net absorption of energy, and it is this absorption that is monitored and converted into a spectrum. The upper spectrum below is the simulated absorption for a system of free electrons in a varying magnetic field. The lower spectrum is the first derivative of the absorption spectrum. The latter is the most common way to record and publish continuous wave EPR spectra.



For the microwave frequency of 9388.2 MHz, the predicted resonance occurs at a magnetic field of about $B_0 = h\nu/g_e\mu_{\rm B} = 0.3350~{\rm T} = 3350~{\rm G}$

Because of electron-nuclear mass differences, the <u>magnetic moment</u> of an electron is substantially larger than the corresponding quantity for any nucleus, so that a <u>much higher</u> electromagnetic frequency is needed to bring about a spin resonance with an electron than with a nucleus, at identical magnetic field strengths. For


example, for the field of 3350 G shown above, spin resonance occurs near 9388.2 MHz for an electron compared to only about 14.3 MHz for ¹H nuclei. (For NMR spectroscopy, the corresponding resonance equation is $h\nu = g_N \mu_N B_0$ where g_N and μ_N depend on the nucleus under study.)

Field modulation

As previously mentioned an EPR spectrum is usually directly measured as the first derivative of the absorption. This is accomplished by using field modulation. A small additional oscillating magnetic field is applied to the external magnetic field at a typical frequency of 100 kHz. [4] By detecting the peak to peak amplitude the first derivative of the absorption is measured. By using phase sensitive detection only signals with the same modulation (100 kHz) are detected. This results in higher signal to noise ratios. Note field modulation is unique to continuous wave EPR measurements and spectra resulting from pulsed experiments are presented as absorption profiles.



In practice, EPR samples consist of collections of many paramagnetic species, and not single isolated paramagnetic centers. If the population of radicals is in thermodynamic equilibrium, its statistical distribution is described by the Maxwell–Boltzmann equation:



The field oscillates between B_1 and B_2 due to the superimposed modulation field at 100 kHz. This causes the absorption intensity to oscillate between I_1 and I_2 . The larger the difference the larger the intensity detected by the detector tuned to 100 kHz (note this can be negative or even 0). As the difference between the two intensities is detected the first derivative of the absorption is detected.

$$rac{n_{
m upper}}{n_{
m lower}} = \exp\left(-rac{E_{
m upper}-E_{
m lower}}{kT}
ight) = \exp\left(-rac{\Delta E}{kT}
ight) = \exp\left(-rac{\epsilon}{kT}
ight) = \exp\left(-rac{h
u}{kT}
ight), \qquad ext{(Eq. 1)}$$

where n_{upper} is the number of paramagnetic centers occupying the upper energy state, k is the Boltzmann constant, and T is the thermodynamic temperature. At 298 K, X-band microwave frequencies ($\nu \approx 9.75$ GHz) give $n_{upper}/n_{lower} \approx 0.998$, meaning that the upper energy level has a slightly smaller population than the lower one. Therefore, transitions from the lower to the higher level are more probable than the reverse, which is why there is a net absorption of energy.

The sensitivity of the EPR method (i.e., the minimal number of detectable spins N_{\min}) depends on the photon frequency ν according to

$$N_{
m min} = rac{k_1 V}{Q_0 k_f
u^2 P^{1/2}}, \qquad {
m (Eq. \ 2)}$$

where k_1 is a constant, V is the sample's volume, Q_0 is the unloaded <u>quality factor</u> of the microwave cavity (sample chamber), k_f is the cavity filling coefficient, and P is the microwave power in the spectrometer cavity. With k_f and P being constants, $N_{\min} \sim (Q_0 \nu^2)^{-1}$, i.e., $N_{\min} \sim \nu^{-\alpha}$, where $\alpha \approx 1.5$. In practice, α can change varying from 0.5 to 4.5 depending on spectrometer characteristics, resonance conditions, and sample size.

A great sensitivity is therefore obtained with a low detection limit N_{\min} and a large number of spins. Therefore, the required parameters are:

- A high spectrometer frequency to maximize the Eq. 2. Common frequencies are discussed below
- A low temperature to decrease the number of spin at the high level of energy as shown in Eq. 1. This
 condition explains why spectra are often recorded on sample at the <u>boiling point</u> of <u>liquid nitrogen</u> or <u>liquid</u>
 helium.

Spectral parameters

In real systems, electrons are normally not solitary, but are associated with one or more atoms. There are several important consequences of this:

- 1. An unpaired electron can gain or lose angular momentum, which can change the value of its g-factor, causing it to differ from g_e . This is especially significant for chemical systems with transition-metal ions.
- 2. Systems with multiple unpaired electrons experience electron—electron interactions that give rise to "fine" structure. This is realized as zero field splitting and exchange coupling, and can be large in magnitude.
- 3. The magnetic moment of a nucleus with a non-zero nuclear spin will affect any unpaired electrons associated with that atom. This leads to the phenomenon of hyperfine coupling, analogous to J-coupling, in NMR, splitting the EPR resonance signal into doublets, triplets and so forth. Additional smaller splittings from nearby nuclei is sometimes termed "superhyperfine" coupling.
- 4. Interactions of an unpaired electron with its environment influence the shape of an EPR spectral line. Line shapes can yield information about, for example, rates of chemical reactions.^[5]
- 5. These effects (*g*-factor, hyperfine coupling, zero field splitting, exchange coupling) in an atom or molecule may not be the same for all orientations of an unpaired electron in an external magnetic field. This <u>anisotropy</u> depends upon the electronic structure of the atom or molecule (e.g., free radical) in question, and so can provide information about the atomic or molecular orbital containing the unpaired electron.

The g factor

Knowledge of the g-factor can give information about a paramagnetic center's electronic structure. An unpaired electron responds not only to a spectrometer's applied magnetic field B_0 but also to any local magnetic fields of atoms or molecules. The effective field B_{eff} experienced by an electron is thus written

$$B_{ ext{eff}} = B_0(1-\sigma),$$

where σ includes the effects of local fields (σ can be positive or negative). Therefore, the $h\nu = g_e \mu_B B_{\text{eff}}$ resonance condition (above) is rewritten as follows:

$$h\nu = g_e \mu_B B_{\text{eff}} = g_e \mu_B B_0 (1 - \sigma).$$

The quantity $g_e(1-\sigma)$ is denoted g and called simply the g-factor, so that the final resonance equation becomes

$$h\nu = g\mu_{\rm B}B_0$$
.

This last equation is used to determine g in an EPR experiment by measuring the field and the frequency at which resonance occurs. If g does not equal g_e , the implication is that the ratio of the unpaired electron's spin magnetic moment to its angular momentum differs from the free-electron value. Since an electron's spin magnetic moment is constant (approximately the Bohr magneton), then the electron must have gained or lost angular momentum through $\underline{\text{spin-orbit coupling}}$. Because the mechanisms of spin-orbit coupling are well understood, the magnitude of the change gives information about the nature of the atomic or molecular orbital containing the unpaired electron.

In general, the g factor is not a <u>number</u> but a second-rank <u>tensor</u> represented by 9 numbers arranged in a 3×3 matrix. The principal axes of this tensor are determined by the local fields, for example, by the local atomic arrangement around the unpaired spin in a solid or in a molecule. Choosing an appropriate coordinate system (say, x,y,z) allows one to "diagonalize" this tensor, thereby reducing the maximal number of its components from 9 to 3: g_{xx} , g_{yy} and g_{zz} . For a single spin experiencing only Zeeman interaction with an external magnetic field, the position of the EPR resonance is given by the expression $g_{xx}B_x + g_{yy}B_y + g_{zz}B_z$. Here B_x , B_y and B_z are the components of the magnetic field vector in the coordinate system (x,y,z); their magnitudes change as the field is rotated, so does the frequency of the resonance. For a large ensemble of randomly oriented spins, the EPR spectrum consists of three peaks of characteristic shape at frequencies $g_{xx}B_0$, $g_{yy}B_0$ and $g_{zz}B_0$: the low-frequency peak is positive in first-derivative spectra, the high-frequency

peak is negative, and the central peak is bipolar. Such situations are commonly observed in powders, and the spectra are therefore called "powder-pattern spectra". In crystals, the number of EPR lines is determined by the number of crystallographically equivalent orientations of the EPR spin (called "EPR center").

Hyperfine coupling

Since the source of an EPR spectrum is a change in an electron's spin state, the EPR spectrum for a radical (S = 1/2 system) would consist of one line. Greater complexity arises because the spin couples with nearby nuclear spins. The magnitude of the coupling is proportional to the magnetic moment of the coupled nuclei and depends on the mechanism of the coupling. Coupling is mediated by two processes, dipolar (through space) and isotropic (through bond).

This coupling introduces additional energy states and, in turn, multi-lined spectra. In such cases, the spacing between the EPR spectral lines indicates the degree of interaction between the unpaired electron and the perturbing nuclei. The <u>hyperfine coupling</u> constant of a nucleus is directly related to the spectral line spacing and, in the simplest cases, is essentially the spacing itself. [6]


Two common mechanisms by which electrons and nuclei interact are the Fermi contact interaction and by dipolar interaction. The former applies largely to the case of isotropic interactions (independent of sample orientation in a magnetic field) and the latter to the case of anisotropic interactions (spectra dependent on sample orientation in a magnetic field). Spin polarization is a third mechanism for interactions between an unpaired electron and a nuclear spin, being especially important for π -electron organic radicals, such as the benzene radical anion. The symbols "a" or "A" are used for isotropic hyperfine coupling constants, while "B" is usually employed for anisotropic hyperfine coupling constants.

In many cases, the isotropic hyperfine splitting pattern for a radical freely tumbling in a solution (isotropic system) can be predicted.

Multiplicity

- For a radical having M equivalent nuclei, each with a spin of I, the number of EPR lines expected is 2MI + 1. As an example, the methyl radical, CH₃, has three ¹H nuclei, each with I = 1/2, and so the number of lines expected is 2MI + 1 = 2(3)(1/2) + 1 = 4, which is as observed.
- For a radical having M₁ equivalent nuclei, each with a spin of I₁, and a group of M₂ equivalent nuclei, each with a spin of I₂, the number of lines expected is (2M₁I₁ + 1) (2M₂I₂ + 1). As an example, the methoxymethyl radical, H₂C(OCH₃) has two equivalent ¹H nuclei, each with I = 1/2 and three equivalent ¹H nuclei each with I = 1/2, and so the number of lines expected is (2M₁I₁ + 1) (2M₂I₂ + 1) = [2(2)(1/2) + 1] [2(3)(1/2) + 1] = 3×4 = 12, again as observed.
- The above can be extended to predict the number of lines for any number of nuclei.

While it is easy to predict the number of lines, the reverse problem, unraveling a complex multi-line EPR spectrum and assigning the various spacings to specific nuclei, is more difficult.



Simulated EPR spectra of the methyl and methoxymethyl radicals

In the often encountered case of I=1/2 nuclei (e.g., ^1H , ^{19}F , ^{31}P), the line intensities produced by a population of radicals, each possessing M equivalent nuclei, will follow <u>Pascal's triangle</u>. For example, the spectrum at the right shows that the three ^1H nuclei of the CH_3 radical give rise to 2MI+1=2(3)(1/2)+1=4 lines with a 1:3:3:1 ratio. The line spacing gives a hyperfine coupling constant of $a_{\text{H}}=23$ G for each of the three ^1H nuclei. Note again that the lines in this spectrum are *first derivatives* of absorptions.

As a second example, the methoxymethyl radical, H_3COCH_2 the OCH_2 center will give an overall 1:2:1 EPR pattern, each component of which is further split by the three methoxy hydrogens into a 1:3:3:1 pattern to give a total of $3\times4=12$ lines, a triplet of quartets. A simulation of the observed EPR spectrum is shown and agrees with the 12-line prediction and the expected line intensities. Note that the smaller coupling constant (smaller line spacing) is due to the three methoxy hydrogens, while the larger coupling constant (line spacing) is from the two hydrogens bonded directly to the carbon atom bearing the unpaired electron. It is often the case that coupling constants decrease in size with distance from a radical's unpaired electron, but there are some notable exceptions, such as the ethyl radical (CH_2CH_3).

Resonance linewidth definition

Resonance linewidths are defined in terms of the magnetic induction B and its corresponding units, and are measured along the x axis of an EPR spectrum, from a line's center to a chosen reference point of the line. These defined widths are called <u>halfwidths</u> and possess some advantages: for asymmetric lines, values of left and right halfwidth can be given. The halfwidth ΔB_h is the distance measured from the line's center to the point in which <u>absorption</u> value has half of maximal absorption value in the center of <u>resonance</u> line. First inclination width $\Delta B_{1/2}$ is a distance from center of the line to the point of maximal absorption curve inclination. In practice, a full definition of linewidth is used. For symmetric lines, halfwidth $\Delta B_{1/2} = 2\Delta B_h$, and full inclination width $\Delta B_{\max} = 2\Delta B_{1s}$.

Applications

EPR/ESR spectroscopy is used in various branches of science, such as biology, chemistry and physics, for the detection and identification of free radicals in the solid, liquid, or gaseous state, [8] and in paramagnetic centers such as F-centers. EPR is a sensitive, specific method for studying both radicals formed in chemical reactions and the reactions themselves. For example, when ice (solid H₂O) is decomposed by exposure to highenergy radiation, radicals such as H, OH, and HO_2 are produced. Such radicals can be identified and studied by EPR. Organic and inorganic radicals can be detected in electrochemical systems and in materials exposed to UV light. In many cases, the reactions to make the radicals and the subsequent reactions of the radicals are of interest, while in other cases EPR is used to provide information on a radical's geometry and the orbital of the unpaired electron. EPR/ESR spectroscopy is also used in geology and archaeology as a dating tool. It can be applied to a wide range of materials such as carbonates, sulfates, phosphates, silica or other silicates.[9]



This low-temperature ESR-STM in the Center for Quantum

Nanoscience is one of the first
STMs globally to measure electron spin resonance on single atoms.

Electron paramagnetic resonance (EPR) has proven itself as a useful tool in homogeneous catalysis research for characterization of paramagnetic complexes and reactive intermediates. [10] EPR spectroscopy is a particularly useful tool to investigate their electronic structures, which is fundamental to understand their reactivity.

Medical and biological applications of EPR also exist. Although radicals are very reactive, and so do not normally occur in high concentrations in biology, special reagents have been developed to spin-label molecules of interest. These reagents are particularly useful in biological systems. Specially-designed nonreactive radical molecules can attach to specific sites in a biological cell, and EPR spectra can then give information on the environment of these so-called spin labels or spin probes. Spin-labeled fatty acids have been extensively used to study dynamic organisation of lipids in biological membranes, [11] lipid-protein interactions and temperature of transition of gel to liquid crystalline phases.

A type of <u>dosimetry</u> system has been designed for reference standards and routine use in medicine, based on EPR signals of radicals from irradiated polycrystalline α -alanine (the alanine deamination radical, the hydrogen abstraction radical, and the $(CO^-(OH))=C(CH_3)NH_2^+$ radical). This method is suitable for

measuring gamma and X-rays, electrons, protons, and high-linear energy transfer (LET) radiation of doses in the 1 Gy to 100 kGy range. 14

EPR/ESR spectroscopy can be applied only to systems in which the balance between radical decay and radical formation keeps the free radicals concentration above the detection limit of the spectrometer used. This can be a particularly severe problem in studying reactions in liquids. An alternative approach is to slow down reactions by studying samples held at cryogenic temperatures, such as 77 K (liquid nitrogen) or 4.2 K (liquid helium). An example of this work is the study of radical reactions in single crystals of amino acids exposed to x-rays, work that sometimes leads to activation energies and rate constants for radical reactions.

The study of radiation-induced free radicals in biological substances (for cancer research) poses the additional problem that tissue contains water, and water (due to its <u>electric dipole moment</u>) has a strong absorption band in the microwave region used in EPR spectrometers.

EPR/ESR also has been used by archaeologists for the dating of teeth. Radiation damage over long periods of time creates free radicals in tooth enamel, which can then be examined by EPR and, after proper calibration, dated. Alternatively, material extracted from the teeth of people during dental procedures can be used to quantify their cumulative exposure to ionizing radiation. People exposed to radiation from the Chernobyl disaster have been examined by this method. [15][16]

Radiation-sterilized foods have been examined with EPR spectroscopy, aiming to develop methods to determine whether a food sample has been irradiated and to what dose. [17]

EPR can be used to measure microviscosity and micropolarity within drug delivery systems as well as the characterization of colloidal drug carriers. [18]

EPR/ESR spectroscopy has been used to measure properties of <u>crude oil</u>, in particular <u>asphaltene</u> and <u>vanadium</u> content. EPR measurement of asphaltene content is a function of spin density and solvent polarity. Prior work dating to the 1960s has demonstrated the ability to measure vanadium content to sub-ppm levels. [19]

In the field of <u>quantum computing</u>, <u>pulsed EPR</u> is used to control the state of electron spin <u>qubits</u> in materials such as diamond, silicon and gallium arsenide.

High-field high-frequency measurements

High-field high-frequency EPR measurements are sometimes needed to detect subtle spectroscopic details. However, for many years the use of electromagnets to produce the needed fields above 1.5 T was impossible, due principally to limitations of traditional magnet materials. The first multifunctional millimeter EPR spectrometer with a superconducting solenoid was described in the early 1970s by Prof. Y. S. Lebedev's group (Russian Institute of Chemical Physics, Moscow) in collaboration with L. G. Oranski's group (Ukrainian Physics and Technics Institute, Donetsk), which began working in the Institute of Problems of Chemical Physics, Chernogolovka around 1975. [20] Two decades later, a W-band EPR spectrometer was produced as a small commercial line by the German Bruker Company, initiating the expansion of W-band EPR techniques into medium-sized academic laboratories.


Waveband	L	S	С	X	Р	K	Q	U	V	E	W	F	D	_	J	_
λ/mm	300	100	75	30	20	12.5	8.5	6	4.6	4	3.2	2.7	2.1	1.6	1.1	0.83
$ u/\mathrm{GHz}$	1	3	4	10	15	24	35	50	65	75	95	111	140	190	285	360
$B_0/{ m T}$	0.03	0.11	0.14	0.33	0.54	0.86	1.25	1.8	2.3	2.7	3.5	3.9	4.9	6.8	10.2	12.8

The EPR waveband is stipulated by the frequency or wavelength of a spectrometer's microwave source (see Table).

EPR experiments often are conducted at X and, less commonly, Q bands, mainly due to the ready availability of the necessary microwave components (which originally were developed for <u>radar</u> applications). A second reason for widespread X and Q band measurements is that electromagnets can reliably generate fields up to

about 1 tesla. However, the low spectral resolution over g-factor at these wavebands limits the study of paramagnetic centers with comparatively low anisotropic magnetic parameters. Measurements at $\nu > 40$ GHz, in the millimeter wavelength region, offer the following advantages:

- 1. EPR spectra are simplified due to the reduction of second-order effects at high fields.
- 2. Increase in orientation selectivity and sensitivity in the investigation of disordered systems.
- 3. The informativity and precision of <u>pulse methods</u>, e.g., <u>ENDOR</u> also increase at high magnetic fields.
- 4. Accessibility of spin systems with larger zero-field splitting due to the larger microwave quantum energy $h\nu$.
- 5. The higher spectral resolution over g-factor, which increases with irradiation frequency ν and external magnetic field B_0 . This is used to investigate the structure, polarity, and dynamics of radical microenvironments in spin-modified organic and biological systems through the <u>spin label</u> and probe method. The figure shows how spectral resolution improves with increasing frequency.
- 6. Saturation of paramagnetic centers occurs at a comparatively low microwave polarizing field B_1 , due to the exponential dependence of the number of excited spins on the radiation frequency ν . This effect can be successfully used to study the relaxation and dynamics of paramagnetic centers as well as of superslow motion in the systems under study.
- 7. The cross-relaxation of paramagnetic centers decreases dramatically at high magnetic fields, making it easier to obtain more-precise and more-complete information about the system under study.^[20]



Variation in the EPR spectrum of the <u>TEMPO</u> nitroxide radical as the microwave band (energy of excitation) changes. [20] Note the improved resolution as frequency rises (neglecting the influence of *g* strain).

This was demonstrated experimentally in the study of various biological, polymeric and model systems at D-band EPR. [21]

Hardware components

Microwave bridge

The microwave bridge contains both the microwave source and the detector. [22] Older spectrometers used a vacuum tube called a klystron to generate microwaves, but modern spectrometers use a Gunn diode. Immediately after the microwave source there is an isolator which serves to attenuate any reflections back to the source which would result in fluctuations in the microwave frequency. [23] The microwave power from the source is then passed through a directional coupler which splits the microwave power into two paths, one directed towards the cavity and the other the reference arm. Along both paths there is a variable attenuator that facilitates the precise control of the flow of microwave power. This in turn allows for accurate control over the intensity of the microwaves subjected to the sample. On the reference arm, after the variable attenuator there is a phase shifter that sets a defined phase relationship between the reference and reflected signal which permits phase sensitive detection.

Most EPR spectrometers are reflection spectrometers, meaning that the detector should only be exposed to microwave radiation coming back from the cavity. This is achieved by the use of a device known as the circulator which directs the microwave radiation (from the branch that is heading towards the cavity) into the cavity. Reflected microwave radiation (after absorption by the sample) is then passed through the circulator towards the detector, ensuring it does not go back to the microwave source. The reference signal and reflected signal are combined and passed to the detector diode which converts the microwave power into an electrical current.

Reference arm

At low energies (less than 1 μ W) the diode current is proportional to the microwave power and the detector is referred to as a <u>square-law detector</u>. At higher power levels (greater than 1 mW) the diode current is proportional to the square root of the microwave power and the detector is called a linear detector. In order to obtain optimal sensitivity as well as quantitative information the diode should be operating within the linear region. To ensure the detector is operating at that level the reference arm serves to provide a "bias".

Magnet

In an EPR spectrometer the magnetic assembly includes the magnet with a dedicated power supply as well as a field sensor or regulator such as a <u>Hall probe</u>. EPR spectrometers use one of two types of magnet which is determined by the operating microwave frequency (which determine the range of magnetic field strengths required). The first is an electromagnet which are generally capable of generating field strengths of up to 1.5 T making them suitable for measurements using the Q-band frequency. In order to generate field strengths appropriate for W-band and higher frequency operation superconducting magnets are employed. The magnetic field is homogeneous across the sample volume and has a high stability at static field.

Microwave resonator (cavity)

The microwave resonator is designed to enhance the microwave magnetic field at the sample in order to induce EPR transitions. It is a metal box with a rectangular or cylindrical shape that resonates with microwaves (like an organ pipe with sound waves). At the resonance frequency of the cavity microwaves remain inside the cavity and are not reflected back. Resonance means the cavity stores microwave energy and its ability to do this is given by the quality factor Q, defined by the following equation:


$$Q = rac{2\pi ({
m energy\ stored})}{({
m energy\ dissipated})}$$

The higher the value of Q the higher the sensitivity of the spectrometer. The energy dissipated is the energy lost in one microwave period. Energy may be lost to the side walls of the cavity as microwaves may generate currents which in turn generate heat. A consequence of resonance is the creation of a standing wave inside the cavity. Electromagnetic standing waves have their electric and magnetic field components exactly out of phase. This provides an advantage as the electric field provides non-resonant absorption of the microwaves, which in turn increases the dissipated energy and reduces Q. To achieve the largest signals and hence sensitivity the sample is positioned such that it lies within the magnetic field maximum and the electric field minimum. When the magnetic field strength is such that an absorption event occurs, the value of Q will be reduced due to the extra energy loss. This results in a change of impedance which serves to stop the cavity from being critically coupled. This means microwaves will now be reflected back to the detector (in the microwave bridge) where an EPR signal is detected. [24]

Pulsed electron paramagnetic resonance

The dynamics of electron spins are best studied with pulsed measurements. [25] Microwave pulses typically 10–100 ns long are used to control the spins in the Bloch sphere. The spin-lattice relaxation time can be measured with an inversion recovery experiment.

As with pulsed NMR, the Hahn echo is central to many pulsed EPR experiments. A Hahn echo decay experiment can be used to measure the dephasing time, as shown in the animation below. The size of the echo is recorded for different spacings of the two pulses. This reveals the decoherence, which is not refocused by the π pulse. In simple cases, an exponential decay is measured, which is described by the T_2 time.



Pulsed electron paramagnetic resonance could be advanced into <u>electron nuclear double resonance</u> spectroscopy (ENDOR), which utilizes waves in the radio frequencies. Since different nuclei with unpaired electrons respond to different wavelengths, radio frequencies are required at times. Since the results of the ENDOR gives the coupling resonance between the nuclei and the unpaired electron, the relationship between them can be determined.

See also

- Electric dipole spin resonance
- Ferromagnetic resonance
- Dynamic nuclear polarisation
- Spin label
- Site-directed spin labeling
- Spin trapping
- EDMR
- Optically detected magnetic resonance

References

- 1. Zavoisky E (1945). "Spin-magnetic resonance in paramagnetics". Fizicheskii Zhurnal. 9: 211–245.
- 2. Zavoisky E (1944). Paramagnetic Absorption in Perpendicular and Parallel Fields for Salts, Solutions and Metals (PhD thesis).
- Odom B, Hanneke D, D'Urso B, Gabrielse G (July 2006). "New measurement of the electron magnetic moment using a one-electron quantum cyclotron". *Physical Review Letters*. 97 (3): 030801. Bibcode:2006PhRvL..97c0801O (https://ui.adsabs.harvard.edu/abs/2006PhRvL..97c0801O). doi:10.1103/PhysRevLett.97.030801 (https://doi.org/10.1103%2FPhysRevLett.97.030801). PMID 16907490 (https://pubmed.ncbi.nlm.nih.gov/16907490).
- Chechik V, Carter E, Murphy D (2016-07-14). Electron Paramagnetic Resonance (https://www.amazon.co.uk/d/Books/Electron-Paramagnetic-Resonance-Chemistry-Primers/0198727607/ref=sr_1_1?ie=UTF8&qid=1492443665&sr=8-1&keywords=electron+paramagnetic+resonance). New York, NY: OUP Oxford. ISBN 978-0-19-872760-6.