Gas chromatography

Gas chromatography (GC) is a common type of chromatography used in analytical chemistry for separating and analyzing compounds that can be vaporized without decomposition. Typical uses of GC include testing the purity of a particular substance, or separating the different components of a mixture. In preparative chromatography, GC can be used to prepare pure compounds from a mixture.

Gas chromatography is also sometimes known as **vapor-phase chromatography** (VPC), or **gas-liquid partition chromatography** (GLPC). These alternative names, as well as their respective abbreviations, are frequently used in scientific literature. [2]

Gas chromatography is the process of separating compounds in a mixture by injecting a gaseous or liquid sample into a mobile phase, typically called the carrier gas, and passing the gas through a stationary phase. The mobile phase is usually an inert gas or an unreactive gas such as helium, argon, nitrogen or hydrogen. The stationary phase is a microscopic layer of viscous liquid on a surface of solid particles on an inert solid support inside a piece of glass or metal tubing called a column. The surface of the solid particles may also act as the stationary phase in some columns. The glass or metal column through which the gas phase passes is located in an oven where the temperature of the gas can be controlled and the eluent coming off the column is monitored by a computerized detector.

Contents

History

GC analysis

Physical components

Autosamplers

Inlets

Detectors

Methods

Carrier gas selection and flow rates

Stationary compound selection

Inlet types and flow rates

Sample size and injection technique

Sample injection

Column selection

Column temperature and temperature program

Data reduction and analysis

Gas chromatography



A gas chromatograph with a headspace sampler

Acronym	GC
Classification	Chromatography
Analytes	Organic Inorganic Must be volatile
Other techniques	
Related	Thin layer chromatography High performance liquid chromatography
Hyphenated	Gas chromatography-

mass spectrometry

Qualitative analysis
Quantitative analysis

Applications

See also

References

External links

History



Gas chromatograph

Chromatography dates to 1903 in the work of the Russian scientist, Mikhail Semenovich Tswett, [5] who separated plant pigments via liquid column chromatography. German physical chemist Erika Cremer in 1947 together with Austrian graduate student Fritz Prior developed the theoretical foundations of GC and built the first liquid-gas chromatograph, but her work was deemed irrelevant and was ignored for a long time. [6] English chemists Archer Martin and Richard Synge received a Nobel Prize in 1952 for the invention of partition chromatography in the 1940s, laying the foundations of gas chromatography. [7] The popularity of gas chromatography quickly rose after the development of the flame ionization detector. [8]

GC analysis

A **gas chromatograph** is a chemical analysis instrument for separating chemicals in a complex sample. A gas chromatograph is made up of a narrow flow-through tube, known as the column, through which the sample passes in a gas stream (the carrier gas) at different rates depending on their various chemical and physical properties and their interaction with a specific column lining or filling, called the 'stationary phase'. As the chemicals exit the end of the column, they are detected and identified electronically. The function of the stationary phase in the column is to separate different components, causing each one to exit the column at a different time. Other parameters that can be used to alter the order or time of retention are the carrier gas flow rate, column length and the temperature.

In a GC analysis, a known volume of gaseous or liquid <u>analyte</u> is injected through a rubber disk and into a hot, temperature controlled, port attached to the column. [4] As the carrier gas transports the analyte molecules through the column, there is <u>adsorption</u> of the analyte <u>molecules</u> either onto the column walls or onto packing materials (stationary phase) in the column to give separation. [4] Since each type of molecule has a different rate of progression, the various components of the analyte mixture are separated as they progress along the column and reach the end of the column at different times (retention time). A




Diagram of a gas chromatograph.

detector is used to monitor the time at which each component reaches the outlet and ultimately the amount of that component can be determined. [1] Generally, substances are identified (qualitatively) by the order in which they elute from the column and by the retention time of the analyte in the column. [4]

Physical components

Autosamplers

The autosampler provides the means to introduce a sample automatically into the inlets. Manual insertion of the sample is possible but is no longer common. Automatic insertion provides better reproducibility and time-optimization.

Different kinds of autosamplers exist. Autosamplers can be classified in relation to sample capacity (auto-injectors vs. autosamplers, where auto-injectors can work a small number of samples), to robotic technologies (XYZ robot [9] vs. rotating robot – the most common), or to analysis:

- Liquid
- Static head-space by syringe technology
- Dynamic head-space by transfer-line technology
- Solid phase microextraction (SPME)




An autosampler for liquid or gaseous samples based on a microsyringe

Inlets

The column inlet (or injector) provides the means to introduce a sample into a continuous flow of carrier gas. The inlet is a piece of hardware attached to the column head.

Common inlet types are:

S/SL (split/splitless) injector; a sample is introduced into a heated small chamber via a syringe through a septum – the heat facilitates <u>volatilization</u> of the sample and sample matrix. The carrier gas then either sweeps the entirety (splitless mode) or a portion (split mode) of the sample into the column.



Split/splitless inlet.

- In split mode, a part of the sample/carrier gas mixture in the injection chamber is exhausted through the split vent. Split injection is preferred when working with samples with high analyte concentrations (>0.1%) whereas splitless injection is best suited for trace analysis with low amounts of analytes (<0.01%). In splitless mode the split valve opens after a pre-set amount of time to purge heavier elements that would otherwise contaminate the system. This pre-set (splitless) time should be optimized, the shorter time (e.g., 0.2 min) ensures less tailing but loss in response, the longer time (2 min) increases tailing but also signal. [10]
- On-column inlet; the sample is here introduced directly into the column in its entirety without heat, or at a temperature below the boiling point of the solvent. The low temperature condenses the sample into a narrow zone. The column and inlet can then be heated, releasing the sample into the gas phase. This ensures the lowest possible temperature for chromatography and keeps samples from decomposing above their boiling point.
- PTV injector; Temperature-programmed sample introduction was first described by Vogt in 1979. Originally Vogt developed the technique as a method for the introduction of large sample volumes (up to 250 μL) in capillary GC. Vogt introduced the sample into the liner at a controlled injection rate. The temperature of the liner was chosen slightly below the boiling point of the solvent. The low-boiling solvent was continuously evaporated and vented through the split line. Based on this technique, Poy developed the programmed temperature vaporising injector; PTV. By introducing the sample at a low initial liner temperature many of the disadvantages of the classic hot injection techniques could be circumvented.
- Gas source inlet or gas switching valve; gaseous samples in collection bottles are connected to what is most commonly a six-port switching valve. The carrier gas flow is not interrupted while a

- sample can be expanded into a previously evacuated sample loop. Upon switching, the contents of the sample loop are inserted into the carrier gas stream.
- P/T (Purge-and-Trap) system; An inert gas is bubbled through an aqueous sample causing insoluble volatile chemicals to be purged from the matrix. The volatiles are 'trapped' on an absorbent column (known as a trap or concentrator) at ambient temperature. The trap is then heated and the volatiles are directed into the carrier gas stream. Samples requiring preconcentration or purification can be introduced via such a system, usually hooked up to the S/SL port.

The choice of carrier gas (mobile phase) is important. Hydrogen has a range of flow rates that are comparable to helium in efficiency. However, helium may be more efficient and provide the best separation if flow rates are optimized. Helium is non-flammable and works with a greater number of detectors and older instruments. Therefore, helium is the most common carrier gas used. However, the price of helium has gone up considerably over recent years, causing an increasing number of chromatographers to switch to hydrogen gas. Historical use, rather than rational consideration, may contribute to the continued preferential use of helium.

Detectors

Commonly used detectors are the <u>flame ionization detector</u> (FID) and the <u>thermal conductivity detector</u> (TCD). While TCDs are beneficial in that they are non-destructive, its low detection limit for most analytes inhibits widespread use. [1] FIDs are sensitive primarily to hydrocarbons, and are more sensitive to them than TCD. [4] FIDs cannot detect water or carbon dioxide which make them ideal for environmental organic analyte analysis. [1] FID is two to three times more sensitive to analyte detection than TCD. [1]

Thermal conductivity detector (TCD) relies on the thermal conductivity of matter passing around a thin wire of tungsten-rhenium with a current traveling through it. [4] In this set up helium or nitrogen serve as the carrier gas because of their relatively high thermal conductivity which keep the filament cool and maintain uniform resistivity and electrical efficiency of the filament. [4][11] When analyte molecules elute from the column, mixed with carrier gas, the thermal conductivity decreases while there is an increase in filament temperature and resistivity resulting in fluctuations in voltage ultimately causing a detector response. [4][11] Detector sensitivity is proportional to filament current while it is inversely proportional to the immediate environmental temperature of that detector as well as flow rate of the carrier gas. [4]

In a <u>flame ionization detector</u> (FID), electrodes are placed adjacent to a flame fueled by hydrogen / air near the exit of the column, and when carbon containing compounds exit the column they are pyrolyzed by the flame. This detector works only for organic / hydrocarbon containing compounds due to the ability of the carbons to form cations and electrons upon pyrolysis which generates a current between the electrodes. The increase in current is translated and appears as a peak in a chromatogram. FIDs have low detection limits (a few picograms per second) but they are unable to generate ions from <u>carbonyl</u> containing carbons. FID compatible carrier gasses include helium, hydrogen, nitrogen, and argon. [4][11]

Alkali flame detector (AFD) or alkali flame ionization detector (AFID) has high sensitivity to nitrogen and phosphorus, similar to NPD. However, the alkaline metal ions are supplied with the hydrogen gas, rather than a bead above the flame. For this reason AFD does not suffer the "fatigue" of the NPD, but provides a constant sensitivity over long period of time. In addition, when alkali ions are not added to the flame, AFD operates like a standard FID. A catalytic combustion detector (CCD) measures combustible hydrocarbons and hydrogen. Discharge ionization detector (DID) uses a high-voltage electric discharge to produce ions.

The <u>polyarc reactor</u> is an add-on to new or existing GC-FID instruments that converts all organic compounds to methane molecules prior to their detection by the FID. This technique can be used to improve the response of the FID and allow for the detection of many more carbon-containing compounds. The complete conversion of compounds to methane and the now equivalent response in the detector also eliminates the need for calibrations and standards because response factors are all equivalent to those of methane. This allows for the rapid analysis of complex mixtures that contain molecules where standards are not available.

Flame photometric detector (FPD) uses a photomultiplier tube to detect spectral lines of the compounds as they are burned in a flame. Compounds eluting off the column are carried into a hydrogen fueled flame which excites specific elements in the molecules, and the excited elements (P,S, Halogens, Some Metals) emit light of specific characteristic wavelengths. The emitted light is filtered and detected by a photomultiplier tube. In particular, phosphorus emission is around 510–536 nm and sulfur emission is at 394 nm. With an atomic emission detector (AED), a sample eluting from a column enters a chamber which is energized by microwaves that induce a plasma. The plasma causes the analyte sample to decompose and certain elements generate an atomic emission spectra. The atomic emission spectra is diffracted by a diffraction grating and detected by a series of photomultiplier tubes or photo diodes.

Electron capture detector (ECD) uses a radioactive beta particle (electron) source to measure the degree of electron capture. ECD are used for the detection of molecules containing electronegative / withdrawing elements and functional groups like halogens, carbonyl, nitriles, nitro groups, and organometalics. [4][11] In this type of detector either nitrogen or 5% methane in argon is used as the mobile phase carrier gas. [4][11] The carrier gas passes between two electrodes placed at the end of the column, and adjacent to the cathode (negative electrode) resides a radioactive foil such as 63Ni. [4][11] The radioactive foil emits a beta particle (electron) which collides with and ionizes the carrier gas to generate more ions resulting in a current. [4][11] When analyte molecules with electronegative / withdrawing elements or functional groups electrons are captured which results in a decrease in current generating a detector response. [4][11]

Nitrogen—phosphorus detector (NPD), a form of thermionic detector where nitrogen and phosphorus alter the work function on a specially coated bead and a resulting current is measured.

Dry electrolytic conductivity detector (DELCD) uses an air phase and high temperature (v. Coulsen) to measure chlorinated compounds.

Mass spectrometer (MS), also called GC-MS; highly effective and sensitive, even in a small quantity of sample. This detector can be used to identify the analytes in chromatograms by their mass spectrum. Some GC-MS are connected to an NMR spectrometer which acts as a backup detector. This combination is known as GC-MS-NMR. Some GC-MS-NMR are connected to an infrared spectrophotometer which acts as a backup detector. This combination is known as GC-MS-NMR-IR. It must, however, be stressed this is very rare as most analyses needed can be concluded via purely GC-MS.

Vacuum ultraviolet (VUV) represents the most recent development in gas chromatography detectors. Most chemical species absorb and have unique gas phase absorption cross sections in the approximately 120–240 nm VUV wavelength range monitored. Where absorption cross sections are known for analytes, the VUV detector is capable of absolute determination (without calibration) of the number of molecules present in the flow cell in the absence of chemical interferences. [14]

<u>Olfactometric detector</u>, also called GC-O, uses a human assessor to analyse the odour activity of compounds. With an odour port or a sniffing port, the quality of the odour, the intensity of the odour and the duration of the odour activity of a compound can be assessed.

Other detectors include the Hall electrolytic conductivity detector (ElCD), helium ionization detector (HID), infrared detector (IRD), photo-ionization detector (PID), pulsed discharge ionization detector (PDD), and thermionic ionization detector (TID). [15]

Methods

The method is the collection of conditions in which the GC operates for a given analysis. Method development is the process of determining what conditions are adequate and/or ideal for the analysis required.

Conditions which can be varied to accommodate a required analysis include inlet temperature, detector temperature, column temperature and temperature program, carrier gas and carrier gas flow rates, the column's stationary phase, diameter and length, inlet type and flow rates, sample size and injection technique. Depending on the detector(s) (see below) installed on the GC, there may be a number of detector conditions that can also be varied. Some GCs also include valves which can change the route of sample and carrier flow. The timing of the opening and closing of these valves can be important to method development.

Carrier gas selection and flow rates

Typical carrier gases include <u>helium</u>, <u>nitrogen</u>, <u>argon</u>, and <u>hydrogen</u>. [4][1] Which gas to use is usually determined by the detector being used, for example, a <u>DID</u> requires helium as the carrier gas. [1] When analyzing gas samples the carrier is also selected based on the sample's matrix, for example, when analyzing a mixture in argon, an argon carrier is preferred because

This image above shows the interior of a GeoStrata
Technologies Eclipse Gas
Chromatograph that runs
continuously in three-minute
cycles. Two valves are used to
switch the test gas into the sample
loop. After filling the sample loop
with test gas, the valves are
switched again applying carrier
gas pressure to the sample loop
and forcing the sample through the
column for separation.

the argon in the sample does not show up on the chromatogram. Safety and availability can also influence carrier selection.

The purity of the carrier gas is also frequently determined by the detector, though the level of sensitivity needed can also play a significant role. Typically, purities of 99.995% or higher are used. The most common purity grades required by modern instruments for the majority of sensitivities are 5.0 grades, or 99.999% pure meaning that there is a total of 10 ppm of impurities in the carrier gas that could affect the results. The highest purity grades in common use are 6.0 grades, but the need for detection at very low levels in some forensic and environmental applications has driven the need for carrier gases at 7.0 grade purity and these are now commercially available. Trade names for typical purities include "Zero Grade," "Ultra-High Purity (UHP) Grade," "4.5 Grade" and "5.0 Grade."

The carrier gas linear velocity affects the analysis in the same way that temperature does (see above). The higher the linear velocity the faster the analysis, but the lower the separation between analytes. Selecting the linear velocity is therefore the same compromise between the level of separation and length of analysis as selecting the column temperature. The linear velocity will be implemented by means of the carrier gas flow rate, with regards to the inner diameter of the column.

With GCs made before the 1990s, carrier flow rate was controlled indirectly by controlling the carrier inlet pressure, or "column head pressure." The actual flow rate was measured at the outlet of the column or the detector with an electronic flow meter, or a bubble flow meter, and could be an involved, time consuming, and frustrating process. It was not possible to vary the pressure setting during the run, and thus the flow was essentially constant during the analysis. The relation between flow rate and inlet pressure is calculated with Poiseuille's equation for compressible fluids.

Many modern GCs, however, electronically measure the flow rate, and electronically control the carrier gas pressure to set the flow rate. Consequently, carrier pressures and flow rates can be adjusted during the run, creating pressure/flow programs similar to temperature programs.

Stationary compound selection

The <u>polarity</u> of the solute is crucial for the choice of stationary compound, which in an optimal case would have a similar polarity as the solute. Common stationary phases in open tubular columns are cyanopropylphenyl dimethyl polysiloxane, carbowax polyethyleneglycol, biscyanopropyl cyanopropylphenyl polysiloxane and diphenyl dimethyl polysiloxane. For packed columns more options are available. [4]


Inlet types and flow rates

The choice of inlet type and injection technique depends on if the sample is in liquid, gas, adsorbed, or solid form, and on whether a solvent matrix is present that has to be vaporized. Dissolved samples can be introduced directly onto the column via a COC injector, if the conditions are well known; if a solvent matrix has to be vaporized and partially removed, a S/SL injector is used (most common injection technique); gaseous samples (e.g., air cylinders) are usually injected using a gas switching valve system; adsorbed samples (e.g., on adsorbent tubes) are introduced using either an external (on-line or off-line) desorption apparatus such as a purge-and-trap system, or are desorbed in the injector (SPME applications).

Sample size and injection technique

Sample injection

The real chromatographic analysis starts with the introduction of the sample onto the column. The development of capillary gas chromatography resulted in many practical problems with the injection technique. The technique of on-column injection, often used with packed columns, is usually not possible with capillary columns. In the injection system in the capillary gas chromatograph the amount injected should not overload the column and the width of the injected plug should be small compared to the spreading due to the chromatographic process. Failure to comply with this latter requirement will reduce the separation capability of the column. As a general rule, the volume injected, $V_{\rm inj}$, and the volume of the detector cell, $V_{\rm det}$, should be



The rule of ten in gas chromatography

about 1/10 of the volume occupied by the portion of sample containing the molecules of interest (analytes) when they exit the column.

Some general requirements which a good injection technique should fulfill are that it should be possible to obtain the column's optimum separation efficiency, it should allow accurate and reproducible injections of small amounts of representative samples, it should induce no change in sample composition, it should not exhibit discrimination based on differences in boiling point, polarity, concentration or thermal/catalytic stability, and it should be applicable for trace analysis as well as for undiluted samples.

However, there are a number of problems inherent in the use of syringes for injection. Even the best syringes claim an accuracy of only 3%, and in unskilled hands, errors are much larger. The needle may cut small pieces of rubber from the septum as it injects sample through it. These can block the

needle and prevent the syringe filling the next time it is used. It may not be obvious that this has happened. A fraction of the sample may get trapped in the rubber, to be released during subsequent injections. This can give rise to ghost peaks in the chromatogram. There may be selective loss of the more volatile components of the sample by evaporation from the tip of the needle. [16]

Column selection

The choice of column depends on the sample and the active measured. The main chemical attribute regarded when choosing a column is the <u>polarity</u> of the mixture, but <u>functional groups</u> can play a large part in column selection. The polarity of the sample must closely match the polarity of the column stationary phase to increase <u>resolution</u> and separation while reducing run time. The separation and run time also depends on the film thickness (of the stationary phase), the column diameter and the column length.

Column temperature and temperature program

The column(s) in a GC are contained in an oven, the temperature of which is precisely controlled electronically. (When discussing the "temperature of the column," an analyst is technically referring to the temperature of the column oven. The distinction, however, is not important and will not subsequently be made in this article.)

The rate at which a sample passes through the column is directly proportional to the temperature of the column. The higher the column temperature, the faster the sample moves through the column. However, the faster a sample moves through the column, the less it interacts with the stationary phase, and the less the analytes are separated.



A gas chromatography oven, open to show a capillary column

In general, the column temperature is selected to compromise between the length of the analysis and the level of separation.

A method which holds the column at the same temperature for the entire analysis is called "isothermal." Most methods, however, increase the column temperature during the analysis, the initial temperature, rate of temperature increase (the temperature "ramp"), and final temperature are called the temperature program.

A temperature program allows analytes that elute early in the analysis to separate adequately, while shortening the time it takes for late-eluting analytes to pass through the column.

Data reduction and analysis

Qualitative analysis

Generally, chromatographic data is presented as a graph of detector response (y-axis) against retention time (x-axis), which is called a chromatogram. This provides a spectrum of peaks for a sample representing the <u>analytes</u> present in a sample eluting from the column at different times. Retention time can be used to identify analytes if the method conditions are constant. Also, the pattern of peaks will be constant for a sample under constant conditions and can identify complex mixtures of analytes. However, in most modern applications, the GC is connected to a <u>mass</u> spectrometer or similar detector that is capable of identifying the analytes represented by the peaks.

Quantitative analysis

The area under a peak is proportional to the amount of analyte present in the chromatogram. By calculating the area of the peak using the mathematical function of <u>integration</u>, the concentration of an analyte in the original sample can be determined. Concentration can be calculated using a <u>calibration curve</u> created by finding the response for a series of concentrations of analyte, or by determining the <u>relative response factor</u> of an analyte. The relative response factor is the expected ratio of an analyte to an <u>internal standard</u> (or <u>external standard</u>) and is calculated by finding the response of a known amount of analyte and a constant amount of internal standard (a chemical added to the sample at a constant concentration, with a distinct retention time to the analyte).

In most modern <u>GC-MS</u> systems, computer <u>software</u> is used to draw and integrate peaks, and match MS spectra to library spectra.

Applications

In general, substances that vaporize below 300 °C (and therefore are stable up to that temperature) can be measured quantitatively. The samples are also required to be <u>salt-free</u>; they should not contain <u>ions</u>. Very minute amounts of a substance can be measured, but it is often required that the sample <u>must</u> be measured in comparison to a sample containing the pure, suspected substance known as a reference standard.

Various temperature programs can be used to make the readings more meaningful; for example to differentiate between substances that behave similarly during the GC process.

Professionals working with GC analyze the content of a chemical product, for example in assuring the quality of products in the chemical industry; or measuring toxic substances in soil, air or water. GC is very accurate if used properly and can measure <u>picomoles</u> of a substance in a 1 ml liquid sample, or parts-per-billion concentrations in gaseous samples.

In practical courses at colleges, students sometimes get acquainted to the GC by studying the contents of Lavender oil or measuring the ethylene that is secreted by Nicotiana benthamiana plants after artificially injuring their leaves. These GC analyse hydrocarbons (C2-C40+). In a typical experiment, a packed column is used to separate the light gases, which are then detected with a TCD. The hydrocarbons are separated using a capillary column and detected with a FID. A complication with light gas analyses that include H₂ is that He, which is the most common and most sensitive inert carrier (sensitivity is proportional to molecular mass) has an almost identical thermal conductivity to hydrogen (it is the difference in thermal conductivity between two separate filaments in a Wheatstone Bridge type arrangement that shows when a component has been eluted). For this reason, dual TCD instruments used with a separate channel for hydrogen that uses nitrogen as a carrier are common. Argon is often used when analysing gas phase chemistry reactions such as F-T synthesis so that a single carrier gas can be used rather than two separate ones. The sensitivity is reduced, but this is a trade off for simplicity in the gas supply.

Gas chromatography is used extensively in <u>forensic science</u>. Disciplines as diverse as solid drug dose (pre-consumption form) identification and quantification, arson investigation, paint chip analysis, and toxicology cases, employ GC to identify and quantify various biological specimens and crime-scene evidence.

See also

- Analytical chemistry
- Chromatography
- Gas chromatography–mass spectrometry