

Debugging Dead OF Channels

You have verified
by looking at a waveform
(e.g. with liftof-tui)
that a signal does not
show a typical SiPM pulse

Make sure that after debugging
all cables are connected as\ they are supposed to

Power cycle RAT and check again

RAT OFF!

Reseat power connector
on SiPM side
Obviously after each
debugging step turn RAT ON
verify that the liftof-rb clients
are running and check again!

RAT OFF! Check which RAT the neighbor paddle connects to and make sure that is off, too!

Swap power cable with
neighbor paddle, SiPM side

Good signal!

Power-Debugging

The SiPM is fine!

At this point
either the cable or
the PB channel
is bad!
LEAVE the cable swap
at SiPM side!

RAT OFF!

Swap PB channel with
neighbor PB channel on RAT

No pulse

Bad power cable!
Report! Possibly it might
be replaced with spare!

Good signal!

The PB channel is bad!
Report! This is a more severe issue!

No pulse!

SiPM-Debugging

Either the HG
connection or the SiPM
might be bad!

RAT OFF! (to be extra sure
and also prevent
damage due to
static discharge)

Swap HG cable with
neighbor paddle!

Good signal!

The HG cable is bad! Report!

No pulse!

The SiPM might be bad.
Connect with a scope
to HG and LG.
Get help if needed!