

Maintenance sheet version 10 for accumulation area (single mast, two levels)

Station name	DY2_SF
People present	JJ, APA
Purpose	Maintenance / installation / take-down / quick visit / emergency
Date	20/5-2024

Notes: Install a new power solution and a SF

No logybox ID

AWS to do list		Check after maintenance			
Part	Shipped? (Y/N)	Replaced? (Y/N)	Number shipped/arrival	Number departure	
Radiometer	N				Clean? Y / N
Iridium modem IMEI number	N		300534064286800		
Inclinometer/compass	N		Attached to the radiometer? Y / N		
Satellite antenna	Y				
Wind sensor upper	N		Black box pointing toward the radiometer (i.e., along the boom)? Y / N		
Wind sensor lower	N		Black box pointing same direction as the radiometer? Y / N		
Temperature / humidity assembly upper	N		Fan spins? Y / N Sounds, OK? Y / N		
Temperature / humidity assembly lower	N		Fan spins? Y / N Sounds, OK? Y / N		
Sonic ranger upper	Y (geolux)		Old sensor with new membrane? Y / N		
Sonic ranger lower	N		Old sensor with new membrane? Y / N		
Thermistor string	N				
Solar panel	Y		Clean? Y / N NB: is not effective when partially covered		
GPS antenna	N		At top of logger enclosure? Y / N		
Logger box ID	Y		CR1000 or CR1000X? ID number:		
Logger enclosure	Y		Replaced (including everything inside)? Y / N New desiccant bags? Y / N		
Battery box + windmill	Y		New box? Y / N New desiccant bags? Y / N		
Mast extension inserted?	Y		How many inserted? How long? Notes:		
Mast	Y		New mast? Y / N New sensor boom? Y / N		

Station name	DY2_SF
Date	20/5-2024 JJ, APA

Metadata maintenance

	Arrival	Departure
Time difference between logger clock and UTC ($\pm$ mm:ss)		0
Download data to PC and/or change SD card (wait for green light)	Y / N	Y / N
Name of logger program	snowfox power station v4.1	
Screen dump of values in fast scan mode	Y / N	Y / N
Photos of mast, sensors, logger box wiring etc. (more is better)	Y / N	Y / N
Mast tilt towards radiometer (- if looking up)	°	°
Mast tilt across boom looking from radiometer (- if clockwise)	°	°
Upper boom direction with radiometer relative to north	° true/magn.	° true/magn.
Lower boom perpendicular to upper boom. If not, measure.	Y / N °	Y / N °
Box on upper wind sensor exactly same direction as radiometer? If not, measure.	Y / N °	Y / N °
Box on lower wind sensor exactly same direction as radiometer? If not, measure.	Y / N °	Y / N °
Upper temperature / humidity height (bottom of casing – surface)	cm	cm
Lower temperature / humidity height (bottom of casing – surface)	cm	cm
Upper sonic ranger height (bottom of casing – surface)	cm	cm
Lower sonic ranger height (bottom of casing – surface)	cm	cm
Length of thermistor string on surface from surface marking	cm	cm
Apparent damage to sensors? If yes, which?	Y / N	Y / N

Notes:

installation
 no wind, will ^{blades} not turning but turning towards the wind (rotating)
 solar panel facing south
 snowfox tube starts 2m from mast directly away from AWS mast (on a line)

Must-do at next visit:

compact on mast extended: 285 stake
 225 cm to logger box bottom
 → reinsert battery in compact logger box