

Maintenance sheet version 9 for accumulation area (single mast, two levels)

Station name	NEM
People present	NBK, CLAN, KDM, ARM, RAV
Purpose	Maintenance (installation) take-down / quick visit / emergency
Date	20.6.22

Notes: There is shipped a lufft assembly mount that should be used on the upper Lufft
One anemometer shipped, replaced the one that does not work

LO REPLACED BOTH OF EACH

AWS to do list		Check after maintenance			
Part	Shipped? (Y/N)	Replaced? (Y/N)	Number shipped/arrival	Number departure	
Radiometer	N	Y		213148	Clean? ☒ Y / N <i>NEW</i>
Iridium modem IMEI number	N	N		300534062417910	
Inclinometer/compass	N	Y	Attached to the radiometer? Y / N		
Satellite antenna	N	X N	REUSED		
Wind sensor upper	Y/N	Y	Black box pointing toward the radiometer (i.e., along the boom)? ☒ Y / N		
Wind sensor lower	Y/N	Y	Black box pointing same direction as the radiometer? ☒ Y / N		
Temperature / humidity assembly upper	Y	Y	Fan spins? Y / N <i>FORGOT TO CHECK BEFORE RAISE.</i> Sounds, OK? Y / N <i>NEW SENSOR</i>		
Temperature / humidity assembly lower	N	Y	Fan spins? ☒ Y / N Sounds, OK? ☒ Y / N		
Sonic ranger upper	Y	Y	Old sensor with new membrane? Y / ☒ N		
Sonic ranger lower	Y	Y	Old sensor with new membrane? Y / ☒ N		
Thermistor string	N	X N	REUSED		
Solar panel	N	Y	Clean? ☒ Y / N NB: is not effective when partially covered		
GPS antenna	N	N	At top of logger enclosure? ☒ Y / N		
Data logger	N	N	CR1000 or CR1000X2		
Logger enclosure	N	N	Replaced (including everything inside)? Y / ☒ N New desiccant bags? ☒ Y / N		
Battery box	Y	Y	New box? ☒ Y / N New desiccant bags? ☒ Y / N		
Mast extension inserted?	N	N	How many inserted? How long? Notes:		
Mast	Y	Y	New mast? ☒ Y / N New sensor boom? ☒ Y / N		

NEM

Metadata maintenance

	Arrival	Departure
Time difference between logger clock and UTC ($\pm$ mm:ss)		
Download data to PC and/or change SD card (wait for green light)	☒ Y / N	Y / N
Name of logger program		4CNET - C.R.W.
Screen dump of values in fast scan mode	Y / N	Y / N
Photos of mast, sensors, logger box wiring etc. (more is better)	☒ Y / N	Y / N
Mast tilt towards radiometer (- if looking up)	-1 °	0.7 °
Mast tilt across boom looking from radiometer (- if clockwise)	1 °	0.7° EAST °
Upper boom direction with radiometer relative to north	157° true/magn.	180 ° true/magn.
Lower boom perpendicular to upper boom. If not, measure.	☒ Y / N °	☒ Y / N °
Box on upper wind sensor exactly same direction as radiometer? If not, measure.	☒ Y / N °	☒ Y / N °
Box on lower wind sensor exactly same direction as radiometer? If not, measure.	☒ Y / N °	☒ Y / N °
Upper temperature / humidity height (bottom of casing – surface)	338 cm	440 cm
Lower temperature / humidity height (bottom of casing – surface)	210 cm	316 cm
Upper sonic ranger height (bottom of casing – surface)	310 cm	397 cm
Lower sonic ranger height (bottom of casing – surface)	192 cm	277 cm
Length of thermistor string on surface from surface marking	665 cm	665 cm
Apparent damage to sensors? If yes, which?	Y / ☒ N	Y / ☒ N

Notes:

GPS 0cm from mast

289
27
316

Must-do at next visit: