



GIB2A XICOY EMULATOR

FrSky Telemetry Sensor ID Reference

Adapted for GIB2A emulator demonstrations

XICOY
INNOVATION & TECHNOLOGY

JETPOWER DEMO REFERENCE

AVAILABLE SENSORS ACCORDING TO MODE



BASIC

Core 8 sensors
Always available



EXTENDED

Adds 4 advanced sensors
(Total 12)



MAXIMUM

Adds 4 additional sensors
(Total 16)

#	SENSOR	UNIT	APPID (FRSKY)			DESCRIPTION
			BASIC	EXTENDED	MAXIMUM	
1	Exhaust Temperature (EGT)	°C	0x400	0x4400	0x4400	Exhaust gas temperature
2	Turbine RPM	RPM	0x500	0x4401	0x4401	Turbine rotational speed
3	Throttle Position	%	0xA20	0x4402	0x4402	Throttle position (%)
4	Battery Voltage	V (0.1V)	0x900	0x4403	0x4403	ECU / Engine battery voltage
5	Pump RPM	RPM	0x910	0x4404	0x4404	Fuel pump rotational speed
6	Fuel Remaining	%	0xA10	0x4405	0x4405	Remaining fuel in tank (%)
7	Engine Status	–	0x410	0x4406	0x4406	Engine status / operating state
8	Heli / TP RPM	RPM	0xA30	0x4414	0x4414	Helicopter / Turboprop RPM
9	Ambient Temperature	°C	–	0x4407	0x4407	Ambient air temperature
10	Pressure	mBar	–	0x4408	0x4408	Ambient pressure
11	Altitude	m	–	0x4409	0x4409	Altitude above sea level
12	Fuel Flow	ml/min	–	0x440A	0x440A	Fuel consumption (per minute)
13	Serial Number	–	–	–	0x440B	Engine serial number
14	Battery Used	mAh	–	–	0x440C	Total battery capacity used
15	Engine Time	s	–	–	0x440D	Engine total run time (seconds)
16	Pump Amperage	A (0.1A)	–	–	0x440E	Fuel pump current consumption

PHYSICAL ID (LOGICAL ID): 0x0B

S.PORT POLL BYTE: 0xCB



Legend: – = not available in that telemetry mode.