

CUTOFF SHOE PACKAGE

DESCRIPTION	SCREED MODEL	SERIAL NUMBER PREFIX	PART NUMBER
Available for order through your Cat dealer only. ***Before ordering, provide machine serial number to your Cat dealer to identify compatible parts.***			
Reduces the minimum paving width. One plate for 305 mm (12 in) cut off and one plate for 609 mm (24 in) cut off. Plates can be repositioned in 152 mm (6 in) increments.	SE50 V, SE50 VT, SE60 V	B86, J6K, J97, JJ3	490-2550
	SE60 V XW, SE60 VT XW	E99, JS9, TLW	490-2560



PREVENTATIVE MAINTENANCE

FOR PEAK PERFORMANCE

Regular preventative maintenance to the engine, hydraulics and fuel systems is key to keeping your equipment running during the paving season. ***Please refer to your Operation and Maintenance Manual for recommended maintenance intervals and procedures.*** The following tables include common filters and components needed to perform regular service on your equipment.

AP300, AP355, AP300F, AP355F PREVENTATIVE MAINTENANCE

INTERVAL (HOURS)	SUBSYSTEM	DESCRIPTION	SERIAL NUMBER PREFIX	PART NUMBER
		Order quantity of one.		
500	Engine	Oil Filter	7P3, 7P5, 7P7, 7P8, 7P9, 7PF, FRA, END, NED, NEE, NRG, NRH, NNN, NNP, NTT, NTW, WH2, WHY, YES, YET	377-6969
	Fuel System	Fuel / Water Separator		363-5819
		Primary Element (in-line)		416-5884
1000	Hydraulics	Primary Element (in tank)	7P3, 7P5, 7P7, 7P8, 7P9, 7PF, FRA, END, NED, NEE, NRG, NRH, NNN, NNP, NTT, NTW, WH2, WHY, YES, YET	422-7912
1500	Engine	Crankcase Breather Filter	7P3, 7P9, FRA, END, NRG, NRH, WHY, WH2	421-1888
2000	Fuel System	Fuel Tank Cap with Breather Filter	7P3, 7P5, 7P7, 7P8, 7P9, 7PF, FRA, END, NED, NEE, NRG, NRH, NNN, NNP, NTT, NTW, WH2, WHY, YES, YET	350-7735
	Hydraulics	Tank Breather		507-0644
When Required	Air Filter	Primary Element	7P3, 7P5, 7P7, 7P8, 7P9, 7PF, FRA, END, NED, NEE, NRG, NRH, NNN, NNP, NTT, NTW, WH2, WHY, YES, YET	362-0107
		Secondary Element		362-0108

AP400, AP455
PREVENTATIVE MAINTENANCE

INTERVAL (HOURS)	SUBSYSTEM	DESCRIPTION	SERIAL NUMBER PREFIX	PART NUMBER
		Order quantity of one.		
500	Engine	Oil Filter	599, 676, A45, MN6, P45, R4N	569-8036
	Fuel System	Fuel / Water Separator	599, 676, P45	540-5119
			A45, MN6, R4N	523-6604
		Primary Element (in-line)	599, 676, P45	540-5119
			A45, MN6, R4N	360-8960
		Secondary Element		
1000	Hydraulics	Primary Element (in tank)	599, 676, A45, MN6, P45, R4N	422-7912
		Charge Oil Filter		192-0717
		Tank Return Filter		568-1558
1500	Diesel Exhaust Fluid (DEF)	DEF Filter	599, 676, P45	536-6756
2000	Fuel System	Fuel Tank Cap with Breather Filter	599, 676, A45, MN6, P45, R4N	338-0912
When Required	Air Filter	Primary Element	599, 676, A45, MN6, P45, R4N	222-9020
		Secondary Element		222-9021
	Uptime Kit	Critical spare parts to ensure maximum machine uptime. Items come packed in a lockable toolbox and each part is clearly identified. Kit includes: O-rings, relays, sensors, position sensors, and fuses.	599, 676, A45, MN6, P45, R4N	625-7642

AP500, AP555
PREVENTATIVE MAINTENANCE

INTERVAL (HOURS)	SUBSYSTEM	DESCRIPTION	SERIAL NUMBER PREFIX	PART NUMBER
		Order quantity of one.		
500	Engine	Oil Filter	4M6, 636, 678	7W-2326
			5P5, 637, 639	322-3155
	Fuel System	Fuel / Water Separator	4M6, 636, 678	558-4721
			5P5, 637, 639	439-5037
		Primary Element (in-line)	4M6, 5P5, 636, 637, 639, 678	360-8960
		Secondary Element	5P5, 637, 639	
1000	Hydraulics	Primary Element (in tank)	4M6, 5P5, 636, 637, 639, 678	568-1556
		Charge Oil Filter		192-0717
		Tank Return Filter		568-1558
1500	Diesel Exhaust Fluid (DEF)	DEF Filter	4M6, 636, 678	536-6756
	Engine	Crankcase Breather Filter		536-5156
2000	Fuel System	Fuel Tank Cap with Breather Filter	4M6, 5P5, 636, 637, 639, 678	338-0912
When Required	Air Filter	Primary Element	4M6, 5P5, 636, 637, 639, 678	222-9020
		Secondary Element		222-9021
	Uptime Kit	Critical spare parts to ensure maximum machine uptime. Items come packed in a lockable toolbox and each part is clearly identified. Kit includes: O-rings, relays, sensors, position sensors, and fuses.	4M6, 5P5, 636, 637, 639, 678	625-7642

AP500F, AP555F
PREVENTATIVE MAINTENANCE

INTERVAL (HOURS)	SUBSYSTEM	DESCRIPTION	SERIAL NUMBER PREFIX	PART NUMBER
		Order quantity of one.		
500	Engine	Oil Filter	449, 503, 5F5, A5F, AP5, F5M, M45, RBM	462-1171
	Fuel System	Fuel / Water Separator	449, AP5, F5M, M45	479-4133
		Fuel / Water Separator	503, 5F5, A5F, RBM	391-3764
		Primary Element (In-Line)	449, AP5, F5M, M45	525-6206
		Secondary Element	449, 503, 5F5, A5F, AP5, F5M, M45, RBM	360-8960
		Tertiary Element	449, AP5, F5M, M45	360-8960
1000	Hydraulics	Primary Element (in tank)	449, 503, 5F5, A5F, AP5, F5M, M45, RBM	281-4256
		Charge Oil Filter		1G-8878
		Tank Return Filter		054-1719
	Pump Drive	Filter		348-1862
1500	Diesel Exhaust Fluid (DEF)	DEF Filter	449, AP5, F5M, M45	495-1507
		In-tank Filter		461-9113
	Engine	Crankcase Breather Filter		339-1048
2000	Fuel System	Fuel Tank Cap with Breather Filter	449, 503, 5F5, A5F, AP5, F5M, M45, RBM	338-0912
	Hydraulics	Tank Breather		419-4904
	Pump Drive	Breather		258-2829
When Required	Air Filter	Primary Element	449, 503, 5F5, A5F, AP5, F5M, M45, RBM	222-9020
		Secondary Element		222-9021
	Uptime Kit	Critical spare parts to ensure maximum machine uptime. Items come packed in a lockable toolbox and each part is clearly identified. Kit includes: O-rings, relays, sensors, position sensors, and fuses.	449, 503, 5F5, A5F, AP5, F5M, M45, RBM	458-4087

AP600, AP655, AP655 L, AP600F, AP655F, AP655F L PREVENTATIVE MAINTENANCE

INTERVAL (HOURS)	SUBSYSTEM	DESCRIPTION	SERIAL NUMBER PREFIX	PART NUMBER
		Order quantity of one.		
500	Engine	Oil Filter	452, 453, 655, 668, 671, 698, A66, AP6, D6F, F67, F7T, MH6, N66, P7C, R66	7W-2326
			479, 480, AC6, JA6, LR6, ML6, P65	462-1171
	Fuel System	Fuel / Water Separator	452, 453, 655, 668, 671, 698, A66, AP6, D6F, F67, F7T, MH6, N66, P7C, R66	479-4133
			479, 480, AC6, JA6, LR6, ML6, P65	391-3764
		Primary Element (In-Line)	452, 453, 655, 668, 671, 698, A66, AP6, D6F, F67, F7T, MH6, N66, P7C, R66	525-6206
		Secondary Element	3A6, 452, 453, 479, 480, 655, 668, 671, 695, 696, 697, 6T5, 9P7, A66, AC6, AP6, D6F, F67, JA6, LR6, MH6, ML6, N66, P7C, P65, R66	360-8960
		Tertiary Element	479, 480, AC6, JA6, LR6, ML6, P65	
1000	Hydraulics	Primary Element (in tank)	3A6, 452, 453, 479, 480, 655, 668, 671, 695, 696, 697, 6T5, 9P7, A66, AC6, AP6, D6F, F67, JA6, LR6, MH6, ML6, N66, P7C, P65, R66	281-4256
		Charge Oil Filter		1G-8878
		Tank Return Filter		054-1719
	Pump Drive	Filter		348-1862
1500	DEF	DEF Filter	452, 453, 655, AP6, D6F, MH6	495-1507
			668, 671, A66, F67, N66, P7C, R66	378-3187
		In-tank Filter	452, 453, 655, AP6, D6F, MH6	461-9113
			668, 671, A66, F67, N66, P7C, R66	536-6756
	Engine	Crankcase Breather Filter	453, 452, 655, 668, 671, 698, A66, AP6, D6F, F67, F7T, MH6, N66, P7C, R66	339-1048
2000	Fuel System	Fuel Tank Cap with Breather Filter	3A6, 452, 453, 479, 480, 655, 668, 671, 695, 696, 697, 6T5, 9P7, A66, AC6, AP6, D6F, F67, JA6, LR6, MH6, ML6, N66, P7C, P65, R66	349-7059
	Hydraulics	Tank Breather		419-4904
	Pump Drive	Breather		258-2829
When Required	Air Filter	Primary Element	3A6, 452, 453, 479, 480, 655, 668, 671, 695, 696, 697, 6T5, 9P7, A66, AC6, AP6, D6F, F67, JA6, LR6, MH6, ML6, N66, P7C, P65, R66	539-6920
		Secondary Element		346-6694
	Uptime Kit	Critical spare parts to ensure maximum machine uptime. Items come packed in a lockable toolbox and each part is clearly identified. Kit includes: O-rings, relays, sensors, position sensors, and fuses.	3A6, 452, 453, 479, 480, 655, 668, 671, 695, 696, 697, 6T5, 9P7, A66, AC6, AP6, D6F, F67, JA6, LR6, MH6, ML6, N66, P7C, P65, R66	458-4087

AP1000 AP1055, AP1000F, AP1055F PREVENTATIVE MAINTENANCE

INTERVAL (HOURS)	SUBSYSTEM	DESCRIPTION	SERIAL NUMBER PREFIX	PART NUMBER
		Order quantity of one.		
500	Engine	Oil Filter	698, AC4, F7T, TJ5	1R-1808
			699, RLM	462-1171
	Fuel System	Fuel / Water Separator	698, AC4, F7T, TJ5	479-4131
			699, RLM	391-3764
		Primary Element (In-Line)	698, AC4, F7T, TJ5	525-6206
		Secondary Element	698, 699, AC4, F7T, RLM, TJ5	360-8960
		Tertiary Element		
1000	Hydraulics	Primary Element (in tank)	698, 699, AC4, F7T, RLM, TJ5	281-4256
		Charge Oil Filter		1G-8878
		Tank Return Filter		054-1719
	Pump Drive	Filter		348-1862
1500	Engine	Crankcase Breather Filter	698, AC4, F7T, TJ5	339-1048
2000	Fuel System	Fuel Tank Cap with Breather Filter	698, 699, AC4, F7T, RLM, TJ5	349-7059
	Hydraulics	Tank Breather		419-4904
	Pump Drive	Breather		258-2829
5000	DEF	DEF Filter	698, AC4, F7T, TJ5	378-3187
		In-tank Filter		584-8135
When Required	Air Filter	Primary Element	698, 699, AC4, F7T, RLM, TJ5	539-6920
		Secondary Element		346-6694
	Uptime Kit	Critical spare parts to ensure maximum machine uptime. Items come packed in a lockable toolbox and each part is clearly identified. Kit includes: O-rings, relays, sensors, position sensors, and fuses.	698, 699, AC4, F7T, RLM, TJ5	458-4087



VISIONLINK®

NEXT GENERATION ASSET MONITORING AND FLEET MANAGEMENT

View fleet information online with VisionLink® and use it to make informed decisions that boost productivity, lower costs, simplify maintenance, and improve safety on your job site. With different subscription level options, your Cat dealer can help configure exactly what you need to optimize your fleet and drive additional profit.

INCREASE PRODUCTION

+ Improve utilization by knowing if, when, where and how every asset is being used
+ Bid and schedule projects more accurately
+ Manage your entire jobsite via one interface

CONTROL COSTS

+ Monitor and reduce idle time and fuel burn
+ Eliminate assets that aren't earning their keep
+ Manage service to avoid downtime

IMPROVE OPERATOR PERFORMANCE

+ Improve operator performance by identifying training opportunities
+ Compare individuals' productivity and idle time numbers to motivate improvement

RUN A SAFE OPERATION

+ Know when unsafe actions occur, even when you're not there
+ Act quickly to prevent accidents and identify training opportunities



TURN CHALLENGES INTO OPPORTUNITIES

Contact your dealer or visit:
www.myvisionlink.com

Get to know more about VisionLink's three task-focused applications:

FLEET MANAGEMENT



UNIFIED FLEET: Manage fleet location and ensure assets are fueled and operating

+ Location
+ Hours
+ Idle time
+ Fuel utilization
+ Asset status and operation

MAINTENANCE MANAGEMENT



UNIFIED SERVICE: Manage equipment health, plan downtime for maintenance and ensure inspections are documented

+ Equipment health
+ Fault codes
+ Fluid analysis
+ Inspections documentation
+ Maintenance functions

PRODUCTIVITY MANAGEMENT



UNIFIED PRODUCTIVITY: Ensure machines are being operated at optimum efficiency. Measure and track payloads and volume

+ Utilization
+ Payload and volume
+ Cycle monitoring
+ Project productivity
+ Consolidated view

LET'S DO THE WORK.™

QEXQ3132-02 (08/2024)
Replaces QEXQ2832-01

© 2024 Caterpillar. All Rights Reserved. CAT, CATERPILLAR, LET'S DO THE WORK, their respective logos, "Caterpillar Corporate Yellow", the "Power Edge" and Cat "Modern Hex" trade dress as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.

VisionLink is a trademark of Caterpillar Inc., registered in the United States and in other countries.