
C-041-xx Road Marking		
 C-041-xx	Sign sizes (mm) C-041-xx (1200 x 1200)	The ROAD MARKING C-041 sign is a double-sided sign. The ROAD MARKING IN PROGRESS side of the C-041 sign should face approaching traffic in advance of conventional pavement marking operations on two-lane, two-way rural roads (see *Section 14.8: Conventional Long-Line Marking – Multilane Roadway* and *Section 14.9: Left-Turn Arrow Marking*). The WET PAINT side of the C-041 sign should be displayed towards traffic approaching freshly painted lines that have been marked with traffic cones. The maximum distance shown on the sign should be 10 kilometres.
C-042 Series Pass This Side / Traffic Control Person Operating		
 C-042-LR  C-042-SLR	Sign sizes (mm) C-042-LR (900 x 600) C-042-SLR (900 x 600)	The PASS THIS SIDE C-042-LR sign should be displayed on the rear of paint trucks and shadow vehicles, or as required on other vehicles involved in a pavement-marking operation where a flashing arrow board (FAB) in arrow mode is unavailable or not used. It is also available with a TRAFFIC CONTROL PERSON OPERATING C-042-SLR sign displayed on the reverse side of the C-42-LR sign. The C-042-SLR sign is to be displayed on the rear of the paint truck when a Traffic Control Person is controlling traffic from the back of that truck.

C-043 Caution – Paint Spray Truck Ahead		
 C-043	Sign sizes (mm) C-043 (1200 x 900)	The CAUTION – PAINT SPRAY TRUCK AHEAD C-043 sign should be displayed on the front of an escort vehicle that is preceding a working paint truck. The escort vehicle may straddle the line to be painted, thereby forcing opposing traffic away from the paint truck and minimizing collision risk and overspray problems.
C-044-xx Slow Vehicle Next X km		
 C-044-xx	Sign sizes (mm) C-044-xx (1200 x 1200)	The SLOW VEHICLE NEXT X km C-044-xx sign should be used in advance of continuously slow-moving work—such as hydro-seeding, flushing, sweeping, etc.—where a travel lane is or may be obstructed. The maximum distance between two opposing C-044-xx signs should not exceed 8 kilometres.
C-045 Slow Vehicle(s) Ahead		
 C-045-1A  C-045-2A	Sign sizes (mm) C-045-1A (750 x 750) C-045-1Axx (1200 x 1200) C-045-2A (750 x 750) C-045-2Axx (1200 x 1200)	When a shadow vehicle on the shoulder follows a work vehicle involved in continuously slow-moving work, the SLOW VEHICLE(S) AHEAD C-045 sign or another appropriate sign should be displayed prominently on the rear of the shadow vehicle. Examples of other signs are: • C-072 Grader Working • C-074 Mower Working • C-076 Sweeper Working The SLOW VEHICLES AHEAD C-045-2A sign should be displayed downstream of the initial ROAD MARKING C-041 sign for two-lane, two-way operations. Confirmatory ROAD MARKING C-041 and C-045-2A signs should also be displayed alternately at intervals throughout a road-marking work zone.

C-046 No Road Lines		
 C-046	Sign sizes (mm) C-046 (750 x 750) C-046-x (900 x 900)	The NO ROAD LINES C-046 sign should be used if a roadway that would normally have pavement markings has none. If there are temporary markings in place, the TEMPORARY ROAD LINES/PAVEMENT MARKINGS C-047 sign should be used instead. These scenarios typically occur in work zones that involve paving, seal coating, milling, centreline crack sealing, etc. If the section without permanent pavement markings is more than 2 kilometres long, an ADVISORY DISTANCE C-024 tab may be mounted below the C-046 or C-047 sign.
C-047 Series Temporary Road Lines/Pavement Markings		
 C-047-1  C-047-2	Sign sizes (mm) C-047-1 (750 x 750) C-047-1x (900 x 900) C-047-2 (750 x 750) C-047-2x (900 x 900)	The TEMPORARY ROAD LINES C-047-1 sign should be used where temporary markings are used to replace longitudinal lines. The TEMPORARY PAVEMENT MARKINGS C-047-2 sign may be more appropriate at intersections and at other complex locations where the temporary markings represent more than just longitudinal lines.

C-048-1-DS Pilot Car / Pilot Car – Do Not Pass		
 C-048-1-DS	Sign sizes (mm) C-048-1-DS (1200 x 900)	The PILOT CAR / PILOT CAR – DO NOT PASS C-048-1-DS sign is a double-sided sign. It should be mounted atop the pilot vehicle, with the PILOT CAR message facing forward and the PILOT CAR – DO NOT PASS message facing backward. The C-048-1-DS sign must be removed or folded down whenever the vehicle is not piloting traffic.
C-048-2 Pilot Car		
 C-048-2	Sign sizes (mm) C-048-2 (1830 x 305)	The PILOT CAR C-048-2 sign should be mounted above a pilot vehicle that is piloting vehicles through construction zones. This sign may be used instead of the PILOT CAR / PILOT CAR – DO NOT PASS C-048-1-DS sign, and used in one of two ways: • If it is to be used as a double-sided sign, the sign should be mounted atop of the pilot vehicle with the message displayed so that it is clear and visible from both the front and the rear. • If it is to be used as a back-lit sign, the sign material must allow light to pass through it so that it can be easily read in low-light and night applications. The sign should be removed or folded down whenever the vehicle is not piloting traffic.
C-049 Follow Pilot Car		
 C-049	Sign sizes (mm) C-049 (750 x 750) C-049-x (900 x 900)	The FOLLOW PILOT CAR C-049 sign should be placed in advance of work where traffic is piloted through a work activity area. It is also used intermittently through the work area as a reminder and warning to drivers who may be unable to see the pilot car because they are in a long platoon of vehicles.

C-050 Workers Below		
 C-050-1  C-050-2	Sign sizes (mm) C-050-1 (600 x 600) C-050-1x (900 x 900) C-050-2 (750 x 750)* C-050-2x (900 x 900)*	The WORKERS BELOW C-050-1 and C-050-2 signs should be used to indicate that workers are present below the main travelling surface. These signs may be used for bridge or overpass/underpass applications, and in other situations in which workers are below the highway elevation and not visible to passing motorists. Either version of the sign may be used to indicate workers below. Typically, the C-050-2 sign is used as a standalone sign and the C-050-1 sign is used as a tab below another sign.
C-051 Bridge Repair		
 C-051	Sign sizes (mm) C-051 (750 x 750) C-051-x (900 x 900)	The BRIDGE REPAIR C-051 sign may be used instead of the CREW WORKING AHEAD C-004 sign and the CONSTRUCTION AHEAD C-018 sign. It may also be used in advance of bridge repair projects when the structure is still open to traffic on a restricted basis.
C-052 Roadside Diversion Ahead		
 C-052-L  C-052-R	Sign sizes (mm) C-052-L (750 x 750) C-052-Lxx (1200 x 1200) C-052-R (750 x 750) C-052-Rxx (1200 x 1200)	A roadside diversion is a “mini-detour”—usually adjacent to the normal route—by which traffic is diverted around a short work activity area. The transition away from and back to the normal route should not be abrupt. The ROAD SIDE DIVERSION AHEAD C-052-L/R sign should be used in advance of the diversion to indicate the path for drivers to follow. Diversions can involve both lanes of a two-lane, two-way roadway or a one- or two-lane section on a multilane highway. In the latter case, if the multilane highway is divided and space is available for a sign in the median, C-052 signs should be placed on both sides of the roadway approaching the diversion.

C-053 Lane Closure Arrow		
 C-053	Sign sizes (mm) C-053 (750 x 750) C-053-xx (1200 x 1200)	The LANE CLOSURE ARROW C-053 sign may replace a flashing arrow board to indicate the closure of a lane on a low-speed roadway. The C-053 sign are also be used for lane shifts on multi-lane roadway. It is positioned just inside the closed-off area at the beginning of the lane closure taper, and should be mounted high enough above the taper devices to be seen clearly by approaching drivers. The sign is oriented with the arrow pointing 45 degrees above horizontal, in the direction of the shift. For a short-duration work activity area in the centre of a two-lane, two-way roadway where traffic moving in both directions is required to pass the site on the right, and flashing arrow boards (FABs) are not required, a C-053 sign may be provided for one or both directions if the intended paths for drivers are not self-evident.
C-057 Avalanche Control		
 C-057	Sign sizes (mm) C-057 (750 x 750) C-057-x (900 x 900)	The AVALANCHE CONTROL C-057 sign should be used in advance of road closures for avalanches and avalanche control works. All signs relating to avalanche closures must be removed or covered when not required.

C-058 Series Emergency Scene		
	Sign sizes (mm)	Emergency Scene C-058 series signs may be used in place of CREW WORKING AHEAD C-004 or CONSTRUCTION AHEAD C-018-1A signs when emergency personnel or first responders are responding to an incident.
 C-058-1A	C-058-1A (750 x 750) C-058-1Ax (900 x 900) C-058-1Axx (1200 x 1200)	• The ACCIDENT SCENE AHEAD C-058-1A sign may be used for motor vehicle incidents and recovery operations that could affect the normal movement of traffic. The C-058-1A sign may also be used by emergency services personnel. **This is the sign most frequently used by Ministry maintenance contractors.** The ACCIDENT SCENE C-058-1B sign may be used in conjunction with the ACCIDENT SCENE AHEAD C-058-1A sign to provide additional warning for motor vehicle incidents and recovery operations. **This is the sign most frequently used by Ministry maintenance contractors**.
 C-058-1B	C-058-1B (750 x 750) C-058-1Bx (900 x 900) C-058-1Bxx (1200 x 1200	• The EMERGENCY SCENE AHEAD C-058-2A sign may be used when there are first responders at an emergency scene, such as if there is a collision, fire, or vehicle breakdown. **This is the sign most frequently used by police, fire and ambulance.** The EMERGENCY SCENE C-058-2B sign may be used in conjunction with the EMERGENCY SCENE AHEAD C-058-2A sign to provide additional warning of the emergency scene ahead and to expect first responders. **This is the sign most frequently used by police, fire and ambulance.**
 C-058-2A	C-058-2A (750 x 750) C-058-2Ax (900 x 900) C-058-2Axx (1200 x 1200)	Signs in the C-058 series may be orange or fluorescent pink. See *Section 19.8 Emergency Response* for how these signs should be used.
 C-058-2B	C-058-2B (750 x 750) C-058-2Bx (900 x 900) C-058-2Bxx (1200 x 1200)	*Figure 19.8 Emergency Response* shows a recommended setup when responding to emergency situations. It uses ACCIDENT SCENE AHEAD C-058-1A and ACCIDENT SCENE C-058-1B signs, which represent the most commonly used signs for emergency situations. Any of the other signs in this series may be used as alternatives to better represent the situation.

continued →

C-058 Series Emergency Scene (continued)		
 C-058-3A	Sign sizes (mm) C-058-3A (750 x 750) C-058-3Ax (900 x 900) C-058-3Axx (1200 x 1200)	• The EMERGENCY INCIDENT AHEAD C-058-3A sign may be used when there are first responders at an emergency incident. **This is the sign most frequently used by police or HAZMAT responders.** The EMERGENCY INCIDENT C-058-3B sign may be used in conjunction with the EMERGENCY INCIDENT AHEAD C-058-3A sign to provide additional warning of the emergency incident ahead. **This is the sign most frequently used by police or HAZMAT responders.** • The POLICE INCIDENT AHEAD C-058-4A sign may be used when there are peace officers at a police incident. **This is the sign most frequently used by police.** The POLICE INCIDENT C-058-4B sign may be used in conjunction with the POLICE INCIDENT AHEAD C-058-4A sign to provide additional warning of the police incident ahead. **This is the sign most frequently used by police.**
 C-058-3B	C-058-3B (750 x 750) C-058-3Bx (900 x 900) C-058-3Bxx (1200 x 1200)	Signs in the C-058 series may be orange or fluorescent pink. See *Section 19.8 Emergency Response* for how these signs should be used. *Figure 19.8 Emergency Response* shows a recommended setup when responding to emergency situations. It uses ACCIDENT SCENE AHEAD C-058-1A and ACCIDENT SCENE C-058-1B signs, which represent the most commonly used signs for emergency situations. Any of the other signs in this series may be used as alternatives to better represent the situation.
 C-058-4A	C-058-4A (750 x 750) C-058-4Ax (900 x 900) C-058-4Axx (1200 x 1200)	
 C-058-4B	C-058-4B (750 x 750) C-058-4Bx (900 x 900) C-058-4Bxx (1200 x 1200)	

C-059 Road Flooded / Washout		
 C-059-1	Sign sizes (mm) C-059-1 (750 x 750) C-059-1x (900 x 900)	The ROAD FLOODED C-059-1 sign should be used where water extends into the travelled roadway. The WASHOUT C-059-2 sign should be used where part of the shoulder or part of the roadway has washed out. There may still be sufficient width for two vehicles to pass safely at a reduced speed. Where the washout has encroached far enough to require the closure of a lane, additional traffic control will be required.
 C-059-2	C-059-2 (750 x 750) C-059-2x (900 x 900)	
C-061 Closed		
 C-061	Sign sizes (mm) C-061 (750 x 300) C-061-x (900 x 350) C-061-xx (1200 x 450)	The CLOSED C-061 tab may be installed below a runaway or exit guide sign for a runaway lane or exit ramp that is closed and unavailable for use. See C-062 below if additional signage is needed for advance locations leading to runaway lanes and exit ramps.

C-062 Exit Closed		
 C-062	Sign sizes (mm) C-062 (1220 x 300) C-062-x (1444 x 350) C-062-xx (1905 x 450)	The EXIT CLOSED C-062 banner may be used on advance signing for a runaway lane or exit ramp that is closed and unavailable for use. The banner may be overlaid across the advance signing, typically at a 45-degree angle, to indicate the closure.
C-063 Traffic Pattern Changed		
 C-063	Sign sizes (mm) C-063 (750 x 750) C-063-xx (1200 x 1200)	The TRAFFIC PATTERN CHANGED C-063 sign should be used in advance of a work zone after the completion of construction to advise drivers of significant traffic pattern changes where: • the travel path has been altered; • lanes have been added or removed; and/or • traffic control has been changed at an intersection (e.g., signal added, two-way stop changed to four-way stop). The C-063 sign typically remains in place for three months following the change.

C-064 Signal Operation Changed		
 C-064	Sign sizes (mm) C-064 (750 x 750) C-064-xx (1200 x 1200)	The SIGNAL OPERATION CHANGED C-064 sign should be used in advance of the work zone after the completion of construction to advise drivers that the operation of an existing signalized intersection has been altered. Examples may include the addition of protected left turns or other changes to the signal phasing. The C-064 sign typically remains in place for three months following the change. Note: The use of this sign requires the approval of the Road Authority.
C-066 Signal Out of Order		
 C-066	Sign sizes (mm) C-066 (750 x 750) C-066-xx (1200 x 1200)	The SIGNAL OUT OF ORDER C-066 sign should be used in advance of an intersection where an existing signal has temporarily been set to flash or turned off because of construction activities. If traffic is still using the intersection, it should be controlled and directed safely through the intersection by Traffic Control Persons or police officers.

C-067 Runaway Lane Closed		
 C-067  C-067-T	Sign sizes (mm) C-067 (750 x 750) C-067-x (900 x 900) C-067-xx (1200 x 1200) C-067-T (450 x 600) C-067-Tx (600 x 750) C-067-Txx (750 x 900)	The RUNAWAY LANE CLOSED C-067 sign should be used in advance of any closure of a runaway lane. The C-067 sign and XXX m AHEAD C-067-Tab distance tab should typically be positioned at least 200 metres or Distance A—whichever is greater—in advance of the closed lane. Distance A values are those shown for Construction Sign Spacing in *Table B – Device Spacing Lengths*—see *Section 6.6 or Appendix F*. The C-067 sign should be covered or removed as soon as possible once the runaway lane is available again.
C-069 Barrier Removed		
 C-069	Sign sizes (mm) C-069 (750 x 750) C-069-x (900 x 900)	The BARRIER REMOVED C-069 sign should be used in advance of locations where an existing median or roadside barrier has been removed because of construction activity.

C-070 Towing Operation		
 C-070-1	Sign sizes (mm) C-070-1 (750 x 750) C-070-1x (900 x 900) C-070-1xx (1200 x 1200)	The TOWING OPERATION C-070-2 sign may be used during tow truck recovery operations to warn drivers of the presence of tow trucks and workers ahead. The TOWING OPERATION AHEAD C-070-1 or TOW TRUCK AHEAD C-071-1 sign may be used in conjunction with the TOW OPERATION C-070-2 sign to provide additional warning of tow truck recovery operations. See *Section 19.1 Tow Truck Recovery Operations* for additional guidance on tow truck recovery operations.
 C-070-2	C-070-2 (750 x 750) C-070-2x (900 x 900) C-070-2xx (1200 x 1200)	
C-071 Tow Truck		
 C-071-1	Sign sizes (mm) C-071-1 (750 x 750) C-071-1x (900 x 900) C-071-1xx (1200 x 1200)	The TOW TRUCK C-071-2 sign may be used during towing operations, or to indicate the presence of a tow truck ahead. The TOW TRUCK AHEAD C-071-1 or TOWING OPERATION AHEAD C-070-1 signs may be used in conjunction with the TOW TRUCK C-071-2 sign to provide additional warning. See *Section 19.1 Tow Truck Recovery Operations* for additional guidance on tow truck recovery operations.
 C-071-2	C-071-2 (750 x 750) C-071-2x (900 x 900) C-071-2xx (1200 x 1200)	

C-072 Grader Working		
 C-072	Sign sizes (mm) C-072 (750 x 750) C-072-xx (1200 x 1200)	The GRADER WORKING C-072 sign should be used in advance of a section where a grader is operating for roadway or shoulder gravelling. Where a roadway (rather than a shoulder) is being graded, a second C-072 sign should be erected to face opposing traffic beyond the end of the section being graded (maximum 8 kilometres), and a YIELD TO ONCOMING TRAFFIC R-056-1 sign should be displayed on the rear of the grader. If the grading operation uses a shadow vehicle on the shoulder behind the grader, the C-072 sign for traffic travelling in the direction of the operation may be displayed conspicuously on the rear of the shadow vehicle.
C-074 Mower Working		
 C-074	Sign sizes (mm) C-074 (750 x 750) C-074-x (900 x 900)	The MOWER WORKING C-074 sign should be used to warn drivers that a mower is working adjacent to the roadway and that the operator may encroach onto the shoulder—or even into the travel lane if the shoulder is narrow—to avoid obstructions like culvert ends, sign posts, delineators, etc. This is continuously slow-moving work, as shown in *Section 10: Traffic Control Layouts – Mobile Work*. The sign is not required if the mower is consistently working well clear of the travelled roadway and shoulder. If the mowing operation uses a shadow vehicle on the shoulder behind the mower, the C-074 sign for traffic travelling in the direction of the operation may be displayed conspicuously on the rear of the shadow vehicle.

C-076 Sweeper Working		
 C-076	Sign sizes (mm) C-076 (750 x 750) C-076-x (900 x 900)	The SWEEPER WORKING C-076 sign should be used in advance of a section where a mechanical sweeper is being used to clean a paved roadway or shoulder. This is continuously slow-moving work, as shown in *Section 10: Traffic Control Layouts – Mobile Work*. Where a travel lane (rather than a shoulder) is being swept on a two-lane, two-way roadway, a second C-076 sign should be erected to face opposing traffic beyond the end of the section being cleaned (maximum 8 kilometres), and a YIELD TO ONCOMING TRAFFIC R-056-1 sign must be displayed on the rear of the sweeper. If the sweeping operation uses a shadow vehicle on the shoulder behind the sweeper, the C-076 sign for traffic travelling in the direction of the operation may be displayed conspicuously on the rear of the shadow vehicle.
C-078 Snow Blower Ahead		
 C-078	Sign sizes (mm) C-078 (750 x 750) C-078-x (900 x 900)	The SNOW BLOWER AHEAD C-078 sign should be used in advance of a section where a snow blower is being used. This is continuously slow-moving work, as shown in *Section 10: Traffic Control Layouts – Mobile Work*. When the snow blower is on a two-lane, two-way roadway, a second C-078 sign should be erected to face opposing traffic beyond the end of the section being cleaned (maximum 8 kilometres), and a YIELD TO ONCOMING TRAFFIC R-056-1 sign must be displayed on the rear of the snow blower. If the snow blowing operation uses a shadow vehicle on the shoulder behind the snow blower, the C-078 sign for traffic travelling in the direction of the operation may be displayed conspicuously on the rear of the shadow vehicle.

C-079-1 Tree Work		
 C-079-1A	Sign sizes (mm) C-079-1A (750 x 750) C-079-1Ax (900 x 900) C-079-1Axx (1200 x 1200)	The TREE WORK C-079-1B sign may be used in advance of a section where tree work is being completed. This includes landscaping of trees or tree falling work. It warns motorists of the potential of debris and to exercise caution when driving through the landscaping or tree falling section. The TREE WORK AHEAD C-079-1A sign may be used as a supplement to the TREE WORK C-079-1B sign for additional warning of the work taking place.
 C-079-1B	C-079-1B (750 x 750) C-079-1Bx (900 x 900) C-079-1Bxx (1200 x 1200)	
C-079-2 Utility Work		
 C-079-2A	Sign sizes (mm) C-079-2A (750 x 750) C-079-2Ax (900 x 900) C-079-2Axx (1200 x 1200)	The UTLITY WORK C-079-2B sign may be used in advance of a section where utility work is being completed. This includes work being completed for, or by companies such as power, gas, water, sewer, telecommunications, television, etc. The UTILITY WORK AHEAD C-079-2A sign may be used as a supplement to the UTILITY WORK C-079-2B sign for additional warning of the work taking place.
 C-079-2B	C-079-2B (750 x 750) C-079-2Bx (900 x 900) C-079-2Bxx (1200 x 1200)	

C-079-3 Landscape Work		
 C-079-3A	Sign sizes (mm) C-079-3A (750 x 750) C-079-3Ax (900 x 900) C-079-3Axx (1200 x 1200)	The LANDSCAPE WORK C-079-3B sign may be used in advance of a section where landscaping is being completed. It warns motorists of the potential of workers close to the travelled roadway, debris, and to exercise caution when driving through the landscaping section. The LANDSCAPE WORK AHEAD C-079-3A sign may be used as a supplement to the LANDSCAPE WORK C-079-3B sign for additional warning of the landscaping taking place.
 C-079-3B	C-079-3B (750 x 750) C-079-3Bx (900 x 900) C-079-3Bxx (1200 x 1200)	

C-080-T Construction Speed Zone Tab		
 C-080-T	Sign sizes (mm) C-080-Ta (600 x 300) C-080-Tax (750 x 450) C-080-Taxx (900 x 450) C-080-Taxxx (1220 x 610)	**Construction Speed Zones may be installed only with the approval of the Road Authority.** The CONSTRUCTION SPEED ZONE C-080-T tab, when erected below the MAXIMUM SPEED AHEAD R-003 and MAXIMUM SPEED R-004 signs, establishes a legally lowered Construction Speed Zone. These signs are normally post-mounted. Construction Speed Zones are generally established for long-duration projects on which a reduction in the normal speed limit is considered necessary.
 C-080-Tb	C-080-Tb (600 x 300) C-080-Tbx (750 x 450) C-080-Tbxx (900 x 450) C-080-Tbxxx (1220 x 610)	The SPECIAL EVENT SPEED ZONE C-080-Tb tab may be used in place of a CONSTRUCTION SPEED ZONE C-080-Ta tab if there is a special event taking place. Special events (such as parades, races, fundraising events, and filming) are characterized as events which have been given a Special Event Permit by the Road Authority. If there are any R-003 or R-004 signs showing the normal maximum speed on the approach to, or within a Construction Speed Zone or Special Event Speed Zone, they are covered or removed whenever the lower speed limit is in effect. The end of a Construction Speed Zone or Special Event Speed Zone should be indicated by an R-004 sign showing the normal maximum speed. C-080-Taxxx and C-080-Tbxxx tabs are to be used on Variable Speed Limit System signs and require approval from the Road Authority.

C-082 Min $196 Fine –Speeding in Work Zones		
 C-082	Sign sizes (mm) C-082 (900 x 450) C-082-xx (1830 x 915)	The MINIMUM $196 FINE – SPEEDING IN WORK ZONES C-082 sign may be used as a speed management tool in areas where drivers have been failing to adjust speed or failing to adhere to the regulatory or construction speed limit. When used in work zones in which a Construction Speed Zone exists, the C-082 sign should be posted in the advance warning area ahead of the work activity area. C-082 signs may also be installed ahead of TCP locations. The C-082 sign may also be used as a standalone sign for speed management throughout the work zone.
C-084 Police Enforcement Ahead		
 C-084	Sign sizes (mm) C-084 (750 x 750)* C-084-x (900 x 900)*	The POLICE ENFORCEMENT AHEAD C-084 sign may be used when a police enforcement event is under way within or in close proximity to a work zone. It should be positioned 100 to 500 metres ahead of the enforcement location. The C-084 sign should be removed or covered when there is no police presence.

C-085 Road Closure Info		
 C-085-1	Sign sizes (mm) C-085-1 (900 x 900) C-085-1x (1200 x 1200)	The ROAD CLOSURE INFO C-085 directional signs are used to direct traffic to a pullout area which contains additional information (custom signs), regarding the road closure. Many Ministry rural road projects impact access to areas, such as recreational areas. Therefore, this type of road closure information gives the road authority the ability to provide additional information regarding the duration and operational impacts of the closure. This information is often provided prior to the commencement of the road closure to allow locals and other road users time to prepare accordingly. Depending on the complexity and amount of information provided for a project, this information may be more suited to a pullout area where plenty of time is available for drivers to read and understand. A limited amount of information can be relayed to drivers when vehicles are in motion and travelling through a work zone.
 C-085-2L	C-085-2L (900 x 900) C-085-2Lx (1200 x 1200)	
 C-085-2R	C-085-2R (900 x 900) C-085-2Rx (1200 x 1200)	
 C-085-3L	C-085-3L (900 x 900) C-085-3Lx (1200 x 1200)	
 C-085-3R	C-085-3R (900 x 900) C-085-3Rx (1200 x 1200)	

C-086 Thank You – Resume Speed		
 C-086-1  C-086-2	Sign sizes (mm) C-086-1 (450 x 900) C-086-2 (1830 x 1220)*	The THANK YOU – RESUME SPEED C-086-1 sign should be used to mark the end of a reduced speed zone that has been established as a Temporary Speed Zone or a Construction Speed Zone. It may also be used at the downstream end of a work activity area through which traffic has been warned to reduce speed by a REDUCE SPEED C-032 sign. On large projects where a CONSTRUCTION PROJECT C-035 sign is used, the END OF PROJECT – THANK YOU RESUME SPEED C-086-2 sign should be used at the end of the work zone if a lowered or reduced speed zone was in effect in the work zone.
C-088 Work Zone Ends		
 C-088	Sign sizes (mm) C-088 (600 x 600) C-088-x (900 x 900)	The WORK ZONE ENDS C-088 sign should be used to indicate the end of a work zone. This sign may be useful to identify the end of a large project that has multiple work activity areas within one large project area. The C-088 sign is generally not required for projects that are very short in length, or for projects for which the end of the work is self-evident.
C-089 Left Lane Must Turn Left		
 C-089	Sign sizes (mm) C-089 (750 x 750) C-089-x (900 x 900) C-089-xx (1200 x 1200)	The LEFT LANE MUST TURN LEFT C-089 sign is used in advance of a lane closure at a multilane intersection where the typical lane assignment is disrupted by a lane closure, and traffic in the left lane can now turn only left, whereas previously that lane may have been a left or through lane.

C-090 Temporary Slow Marker		
 C-090	Sign sizes (mm) C-090 (300 x 300)	The TEMPORARY SLOW C-090 marker is warranted for emergency use only in conjunction with the TEMPORARY HAZARD C-092 marker (see below). It may be erected in advance of temporary hazards such as shoulder washouts, fallen rock, potholes, frost heaves, etc. C-090 and C-092 markers are generally mounted on stakes driven into the shoulder so that each marker is approximately one metre above the level of the travelled roadway. Do not use the TEMPORARY SLOW C-090 marker if it appears that the hazard will not be removed promptly. Instead, erect an appropriate temporary warning sign, such as: • C-007 Broken Pavement • C-017 Bump or Rough Roadway Ahead • C-059-2 Washout If the severity or length of a hazard is such that either the ADVISORY SPEED C-022 tab or the ADVISORY DISTANCE C-024 tab is required, or both are required, use an appropriate temporary warning sign instead of the C-090 or C-092 marker.

C-092 Temporary Hazard Marker		
 C-092	Sign sizes (mm) C-092 (300 x 300)	The TEMPORARY HAZARD C-092 marker is used with the TEMPORARY SLOW C-090 marker (see above) and other temporary warning signs. It is erected on the shoulder to mark the actual site of a hazardous condition. C-090 and C-092 markers are generally mounted on stakes driven into the shoulder so that each marker is approximately one metre above the level of the travelled roadway. Individual bumps, potholes, or pavement breaks generally require only one C-092 marker for each direction of travel. In the case of a washout or minor rock fall, several C-092 markers may be required to delineate the hazard.
C-111 Stop Ahead		
 C-111	Sign sizes (mm) C-111 (750 x 750) C-111-x (900 x 900)*	The STOP AHEAD C-111 sign is used where the stopping sight distance to a temporary STOP sign is inadequate for the approach speed. It is also used where a STOP sign is temporarily required in a location where regular users of the route would not expect to stop.
C-112 Signal Ahead		
 C-112	Sign sizes (mm) C-112 (750 x 750) C-112-x (900 x 900)*	SIGNAL AHEAD C-112 signs should be used in advance of portable traffic signal installations. The sign is normally post-mounted.

C-114, C-115, and C-116 Checkerboards		
 C-114	Sign sizes (mm) C-114 (750 x 750) C-114-x (1200 x 1200)*	All CHECKERBOARD signs are diamond-shaped warning signs and should never be mounted as squares. The C-114 sign may be used in conjunction with Type III barricades and the ROAD CLOSED R-012 sign to mark roads that have been temporarily dead-ended and where no alternative route is available. The C-114 sign should be post-mounted in the centre of the closed roadway, just behind the barricades.
 C-115	C-115 (750 x 750) C-115-x (1200 x 1200)*	When alternative routes are available, the C-115 and C-116 signs are used as follows: • Where one alternative option to the closed road is available either to the right or the left, the C-115 sign is substituted for the C-114 sign and similarly positioned. The C-115 may also be used to mark the apex of a sharp temporary curve, in which case it should be post-mounted just off the shoulder on the outside of the curve, and directly in line with the path of approaching traffic.
 C-116	C-116 (750 x 750) C-116-x (1200 x 1200)*	• Where two alternative options to the closed road are available in the form of both a right turn and left turn, the C-116 sign is substituted for the C-114 sign, and similarly positioned. The C-116 sign may also be used to mark a temporary T-intersection by post-mounting the sign on the far side of the intersecting road to face traffic approaching from the stem of the T. It should be placed in line with the projected centreline of the stem roadway. If necessary, the mounting height of checkerboards may be adjusted above or below the normal height to allow for vertical curvature on the approach.

C-117, C-118, and C-119 Lane Shift		
 C-117-L	Sign sizes (mm)	A LANE SHIFT sign should be used to indicate the path vehicles should follow where the roadway alignment is changed because of a lane shift or diversion.
	C-117-L/R (750 x 750)	A LANE SHIFT sign should also be used again where the roadway shifts back to its original alignment if space allows and the sign is appropriate.
 C-117-R	C-117-L/Rx (900 x 900)	These signs must not be used to indicate a lane closure or a merge condition.
	C-117-L/Rxx (1200 x 1200)	The number of arrows shown on the sign should reflect the number of lanes being shifted.
		If the highway is divided and space is available for a sign in the median, LANE SHIFT signs should be placed on both sides of the roadway approaching the diversion.
 C-118-L	C-118-L/R (750 x 750)	
	C-118-L/Rx (900 x 900)	
 C-118-R	C-118-L/Rxx (1200 x 1200)	
 C-119-L	C-119-L/R (750 x 750)	
	C-119-L/Rx (900 x 900)	
 C-119-R	C-119-L/Rxx (1200 x 1200)	